

# Shop Manual

SHOP MANUAL BULLDOZER

D85EX-18E0

D85PX-18E0

SERIAL NUMBERS 25001 and up

**KOMATSU**



---

# 00 INDEX AND FOREWORD

---

# INDEX

00 INDEX AND FOREWORD .....	00-1
FOREWORD, SAFETY, BASIC INFORMATION .....	00-20
HOW TO READ THE SHOP MANUAL.....	00-20
SAFETY NOTICE FOR OPERATION.....	00-22
PRECAUTIONS TO PREVENT FIRE.....	00-30
ACTIONS IF FIRE OCCURS .....	00-32
PRECAUTIONS FOR DISPOSING OF WASTE MATERIALS .....	00-33
PRECAUTIONS FOR HANDLING HYDRAULIC EQUIPMENT .....	00-34
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF PIPINGS.....	00-37
PRECAUTIONS WHEN YOU HANDLE ELECTRICAL EQUIPMENT.....	00-43
PRECAUTIONS FOR HANDLING FUEL SYSTEM EQUIPMENT .....	00-45
PRECAUTIONS FOR HANDLING INTAKE SYSTEM EQUIPMENT .....	00-46
PRACTICAL USE OF KOMTRAX .....	00-47
DISCONNECT AND CONNECT PUSH-PULL TYPE COUPLER .....	00-48
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF CONNECTORS .....	00-52
METHOD FOR DISCONNECTING AND CONNECTING DEUTSCH CONNECTOR .....	00-56
METHOD FOR DISCONNECTING AND CONNECTING SLIDE LOCK TYPE CONNECTOR .....	00-57
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PULL ...	00-59
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PUSH ..	00-60
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH HOUSING TO ROTATE .	00-62
HOW TO READ ELECTRICAL WIRE CODE .....	00-63
EXPLANATION OF TERMS FOR MAINTENANCE STANDARD.....	00-67
STANDARD TIGHTENING TORQUE TABLE.....	00-70
CONVERSION TABLE .....	00-77
ABBREVIATION LIST .....	00-82
01 SPECIFICATIONS .....	01-1
CONTENTS .....	01-2
SPECIFICATIONS .....	01-3
SPECIFICATION DRAWING .....	01-3
SPECIFICATIONS .....	01-7
WEIGHT TABLE .....	01-19
FUEL, COOLANT, LUBRICANT .....	01-25
10 STRUCTURE AND FUNCTION .....	10-1
CONTENTS .....	10-2
UREA SCR SYSTEM.....	10-5
LAYOUT DRAWING OF UREA SCR SYSTEM .....	10-5
UREA SCR SYSTEM DIAGRAM .....	10-8
FUNCTION OF UREA SCR SYSTEM.....	10-9
COMPONENT PARTS OF UREA SCR SYSTEM.....	10-26
BOOT-UP SYSTEM .....	10-35
LAYOUT DRAWING OF BOOT-UP SYSTEM.....	10-35
SYSTEM OPERATING LAMP SYSTEM .....	10-36
BATTERY DISCONNECT SWITCH .....	10-37
ENGINE SYSTEM .....	10-39
LAYOUT DRAWING OF ENGINE SYSTEM.....	10-39
ENGINE CONTROL SYSTEM .....	10-41
AUTOMATIC IDLE STOP SYSTEM .....	10-46
COMPONENT PARTS OF ENGINE SYSTEM .....	10-49
COOLING SYSTEM.....	10-68
LAYOUT DRAWING OF COOLING SYSTEM .....	10-68
COOLING FAN CONTROL SYSTEM.....	10-70
COMPONENT PARTS OF COOLING SYSTEM.....	10-73
CONTROL SYSTEM.....	10-90
LAYOUT DRAWING OF CONTROL SYSTEM .....	10-90
MACHINE MONITOR SYSTEM .....	10-91

KOMTRAX SYSTEM.....	10-93
COMPONENT PARTS OF CONTROL SYSTEM.....	10-94
HYDRAULIC SYSTEM.....	10-126
LAYOUT DRAWING OF HYDRAULIC SYSTEM.....	10-126
CLSS.....	10-127
COMPONENT PARTS OF HYDRAULIC SYSTEM.....	10-130
POWER TRAIN SYSTEM.....	10-181
LAYOUT DRAWING OF POWER TRAIN SYSTEM.....	10-181
OPERATION OF POWER TRAIN SYSTEM.....	10-183
TRANSMISSION, STEERING, AND BRAKE CONTROL.....	10-184
PALM COMMAND CONTROL SYSTEM.....	10-187
HSS SYSTEM.....	10-191
CENTRALIZED PRESSURE PICKUP PORT.....	10-194
COMPONENT PARTS OF POWER TRAIN SYSTEM.....	10-196
WORK EQUIPMENT SYSTEM.....	10-257
WORK EQUIPMENT CONTROL.....	10-257
LAYOUT DRAWING OF FRONT WORK EQUIPMENT.....	10-260
LAYOUT OF FIXED MULTI-SHANK RIPPER.....	10-261
LAYOUT OF VARIABLE MULTI-SHANK RIPPER.....	10-262
COMPONENT PARTS OF WORK EQUIPMENT SYSTEM.....	10-263
UNDERCARRIAGE AND FRAME.....	10-286
MAIN FRAME.....	10-286
SUSPENSION.....	10-287
TRACK FRAME AND IDLER CUSHION.....	10-291
WORK EQUIPMENT.....	10-293
STRUCTURE OF FRONT WORK EQUIPMENT.....	10-293
STRUCTURE OF CYLINDER STAY.....	10-295
STRUCTURE OF FIXED MULTI-SHANK RIPPER.....	10-296
STRUCTURE OF VARIABLE MULTI-SHANK RIPPER.....	10-297
CAB AND ITS ATTACHMENTS.....	10-298
ROPS CAB.....	10-298
CAB MOUNT.....	10-300
20 STANDARD VALUE TABLE.....	20-1
CONTENTS.....	20-2
STANDARD VALUE TABLE FOR ENGINE.....	20-3
STANDARD VALUE TABLE FOR ENGINE: D85EX-18E0.....	20-3
STANDARD VALUE TABLE FOR ENGINE: D85PX-18E0.....	20-6
STANDARD VALUE TABLE FOR MACHINE.....	20-9
STANDARD VALUE TABLE FOR MACHINE: D85EX-18E0.....	20-9
STANDARD VALUE TABLE FOR MACHINE: D85PX-18E0.....	20-26
MACHINE POSTURE AND PROCEDURE FOR MEASURING PERFORMANCE.....	20-41
30 TESTING AND ADJUSTING.....	30-1
CONTENTS.....	30-2
RELATED INFORMATION ON TESTING AND ADJUSTING.....	30-5
TOOLS FOR TESTING AND ADJUSTING.....	30-5
SKETCH OF TOOLS FOR TESTING AND ADJUSTING.....	30-12
ENGINE AND COOLING SYSTEM.....	30-13
TEST ENGINE SPEED.....	30-13
TEST BOOST PRESSURE.....	30-17
TEST EXHAUST GAS TEMPERATURE.....	30-19
TEST EXHAUST GAS COLOR.....	30-21
TEST AND ADJUST VALVE CLEARANCE.....	30-24
TEST COMPRESSION PRESSURE.....	30-26
TEST BLOWBY PRESSURE.....	30-30
TEST ENGINE OIL PRESSURE.....	30-33
TEST EGR VALVE AND KVGT OIL PRESSURE.....	30-35
TEST FUEL PRESSURE.....	30-37
TEST FUEL DISCHARGE, RETURN AND LEAKAGE.....	30-39

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$