

Shop Manual

HYDRAULIC
EXCAVATOR

PC138US-11

SERIAL NUMBERS PC138US-11 F50001 and up

KOMATSU

00 INDEX AND FOREWORD

INDEX

00 INDEX AND FOREWORD	00-1
ABBREVIATION LIST	00-18
FOREWORD, SAFETY, BASIC INFORMATION	00-24
HOW TO READ THE SHOP MANUAL.....	00-24
SAFETY NOTICE FOR OPERATION.....	00-26
PRECAUTIONS TO PREVENT FIRE.....	00-34
ACTIONS IF FIRE OCCURS	00-36
PRECAUTIONS FOR DISPOSING OF WASTE MATERIALS	00-37
PRECAUTIONS FOR HANDLING HYDRAULIC EQUIPMENT	00-38
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF PIPINGS.....	00-41
PRECAUTIONS FOR HANDLING ELECTRICAL EQUIPMENT.....	00-48
PRECAUTIONS FOR HANDLING FUEL SYSTEM EQUIPMENT	00-50
PRECAUTIONS FOR HANDLING INTAKE SYSTEM EQUIPMENT	00-51
PRACTICAL USE OF KOMTRAX	00-52
DISCONNECT AND CONNECT PUSH-PULL TYPE COUPLER	00-53
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF CONNECTORS	00-57
METHOD FOR DISCONNECTING AND CONNECTING DEUTSCH CONNECTOR	00-61
METHOD FOR DISCONNECTING AND CONNECTING SLIDE LOCK TYPE CONNECTOR	00-62
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PULL ..	00-64
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PUSH ..	00-65
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH HOUSING TO ROTATE .	00-67
HOW TO READ ELECTRICAL WIRE CODE	00-68
EXPLANATION OF TERMS FOR MAINTENANCE STANDARD.....	00-72
STANDARD TIGHTENING TORQUE TABLE.....	00-75
CONVERSION TABLE	00-82
01 SPECIFICATIONS	01-1
CONTENTS	01-2
ABBREVIATION LIST	01-3
SPECIFICATIONS	01-9
SPECIFICATION DRAWING	01-9
WORKING RANGE DRAWINGS	01-11
SPECIFICATIONS	01-14
WEIGHT TABLE	01-18
TABLE OF FUEL, COOLANT, AND LUBRICANTS	01-20
10 STRUCTURE AND FUNCTION	10-1
CONTENTS	10-2
ABBREVIATION LIST	10-5
UREA SCR SYSTEM.....	10-11
LAYOUT DRAWING OF UREA SCR SYSTEM	10-11
UREA SCR SYSTEM DIAGRAM	10-13
FUNCTION OF UREA SCR SYSTEM.....	10-14
COMPONENT PARTS OF UREA SCR SYSTEM.....	10-30
BOOT-UP SYSTEM	10-39
LAYOUT DRAWING OF BOOT-UP SYSTEM.....	10-39
SYSTEM OPERATING LAMP SYSTEM	10-40
BATTERY DISCONNECT SWITCH	10-41
ENGINE SYSTEM	10-42
LAYOUT DRAWING OF ENGINE SYSTEM.....	10-42
ENGINE CONTROL SYSTEM	10-44
AUTO-DECELERATION SYSTEM.....	10-47
ENGINE AUTOMATIC WARM-UP SYSTEM.....	10-49
OVERHEAT PREVENTION SYSTEM.....	10-51
TURBOCHARGER PROTECTION SYSTEM.....	10-53
AUTOMATIC IDLE STOP SYSTEM	10-54
COMPONENT PARTS OF ENGINE SYSTEM	10-57

COOLING SYSTEM.....	10-73
LAYOUT DRAWING OF COOLING SYSTEM	10-73
CONTROL SYSTEM.....	10-75
LAYOUT DRAWING OF CONTROL SYSTEM	10-75
MACHINE MONITOR SYSTEM	10-77
KomVision SYSTEM	10-79
KOMTRAX SYSTEM.....	10-83
COMPONENT PARTS OF CONTROL SYSTEM.....	10-84
HYDRAULIC SYSTEM.....	10-117
LAYOUT DRAWING OF HYDRAULIC SYSTEM	10-117
CLSS	10-119
ENGINE AND PUMP COMBINED CONTROL SYSTEM.....	10-122
COMPONENT PARTS OF HYDRAULIC SYSTEM	10-127
WORK EQUIPMENT SYSTEM	10-209
LAYOUT DRAWING OF WORK EQUIPMENT SYSTEM	10-209
STRUCTURE OF VALVE CONTROL.....	10-212
PPC LOCK SYSTEM	10-213
WORK EQUIPMENT AND TRAVEL AUTOMATIC LOCK SYSTEM	10-214
OIL FLOW ADJUSTER SYSTEM FOR ATTACHMENT.....	10-216
COMPONENT PARTS OF WORK EQUIPMENT SYSTEM.....	10-218
SWING SYSTEM	10-242
LAYOUT DRAWING OF SWING SYSTEM	10-242
SWING CONTROL SYSTEM DIAGRAM	10-244
COMPONENT PARTS OF SWING SYSTEM.....	10-247
TRAVEL SYSTEM.....	10-259
LAYOUT DRAWING OF TRAVEL SYSTEM.....	10-259
TRAVEL CONTROL SYSTEM DIAGRAM.....	10-261
COMPONENT PARTS OF TRAVEL SYSTEM	10-265
UNDERCARRIAGE AND FRAME.....	10-281
LAYOUT DRAWING OF UNDERCARRIAGE	10-281
IDLER CUSHION.....	10-282
WORK EQUIPMENT.....	10-283
STRUCTURE OF WORK EQUIPMENT	10-283
FUNCTION OF WORK EQUIPMENT	10-284
WORK EQUIPMENT CLEARANCE ADJUSTMENT SHIM.....	10-285
BUCKET CLEARANCE ADJUSTMENT SHIM	10-286
CAB AND ITS ATTACHMENTS	10-287
ROPS CAB	10-287
CAB MOUNT	10-288
TAKE WIRING HARNESS OUT OF CAB.....	10-290
20 STANDARD VALUE TABLE	20-1
CONTENTS	20-2
ABBREVIATION LIST	20-3
STANDARD VALUE TABLE FOR ENGINE	20-9
STANDARD VALUE TABLE FOR ENGINE:PC138US-11.....	20-9
STANDARD VALUE TABLE FOR MACHINE.....	20-13
STANDARD VALUE TABLE FOR MACHINE:PC138US-11	20-13
MACHINE POSTURE AND PROCEDURE FOR MEASURING PERFORMANCE	20-28
30 TESTING AND ADJUSTING	30-1
CONTENTS	30-2
ABBREVIATION LIST	30-5
RELATED INFORMATION ON TESTING AND ADJUSTING	30-11
TOOLS FOR TESTING AND ADJUSTING.....	30-11
SKETCH OF TOOLS FOR TESTING AND ADJUSTING	30-18
ENGINE AND COOLING SYSTEM.....	30-20
TEST ENGINE SPEED	30-20
TEST EXHAUST GAS COLOR.....	30-23
TEST THE CLEARANCE OF THE EXHAUST THROTTLE VALVE.....	30-25

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$