

Shop Manual

**HYDRAULIC
EXCAVATOR**

PC490 -11E0

PC490LC -11E0

PC490HRD-11E0

SERIAL NUMBERS

PC490LC-11E0 - K75001-K75095

PC490LCD-11E0 - K75001-K75152

PC490HRD-11E0 - K75001-K75229

KOMATSU

00 INDEX AND FOREWORD

INDEX

00 INDEX AND FOREWORD	00-1
ABBREVIATION LIST	00-21
FOREWORD, SAFETY, BASIC INFORMATION	00-27
HOW TO READ THE SHOP MANUAL.....	00-27
SAFETY NOTICE FOR OPERATION.....	00-29
PRECAUTIONS TO PREVENT FIRE.....	00-37
ACTIONS IF FIRE OCCURS	00-39
PRECAUTIONS FOR DISPOSING OF WASTE MATERIALS	00-40
ACTIONS TAKEN TO MEET EXHAUST GAS REGULATIONS.....	00-41
METHOD FOR CHECKING ENGINE TYPE	00-42
PRECAUTIONS FOR DEF.....	00-44
STORE AdBlue/DEF	00-45
PRECAUTIONS FOR HANDLING HYDRAULIC EQUIPMENT	00-46
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF PIPINGS.....	00-49
PRECAUTIONS FOR HANDLING ELECTRICAL EQUIPMENT.....	00-56
PRECAUTIONS FOR HANDLING FUEL SYSTEM EQUIPMENT	00-58
PRECAUTIONS FOR HANDLING INTAKE SYSTEM EQUIPMENT	00-59
PRACTICAL USE OF KOMTRAX	00-60
DISCONNECT AND CONNECT PUSH-PULL TYPE COUPLER	00-61
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF CONNECTORS	00-65
METHOD FOR DISCONNECTING AND CONNECTING DEUTSCH CONNECTOR	00-69
METHOD FOR DISCONNECTING AND CONNECTING SLIDE LOCK TYPE CONNECTOR	00-70
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PULL ...	00-72
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PUSH ..	00-73
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH HOUSING TO ROTATE .	00-75
HOW TO READ ELECTRICAL WIRE CODE	00-76
EXPLANATION OF TERMS FOR MAINTENANCE STANDARD.....	00-80
STANDARD TIGHTENING TORQUE TABLE.....	00-83
CONVERSION TABLE	00-90
01 SPECIFICATIONS	01-1
CONTENTS	01-2
ABBREVIATION LIST	01-3
SPECIFICATIONS	01-9
SPECIFICATION DRAWING	01-9
WORKING RANGE DRAWINGS	01-11
SPECIFICATIONS	01-12
WEIGHT TABLE	01-15
TABLE OF FUEL, COOLANT, AND LUBRICANTS	01-17
SPECIFICATIONS - PC490HRD-11E0.....	01-18
SPECIFICATION DRAWING.....	01-18
SPECIFICATIONS	01-22
WEIGHT TABLE	01-24
10 STRUCTURE AND FUNCTION	10-1
CONTENTS	10-2
ABBREVIATION LIST	10-6
UREA SCR SYSTEM.....	10-12
LAYOUT DRAWING OF UREA SCR SYSTEM	10-12
UREA SCR SYSTEM DIAGRAM	10-16
FUNCTION OF UREA SCR SYSTEM.....	10-17
COMPONENT PARTS OF UREA SCR SYSTEM.....	10-38
BOOT-UP SYSTEM.....	10-47
LAYOUT DRAWING OF BOOT-UP SYSTEM.....	10-47
SYSTEM OPERATING LAMP SYSTEM	10-49
BATTERY DISCONNECT SWITCH	10-51
ENGINE SYSTEM	10-52

LAYOUT DRAWING OF ENGINE SYSTEM	10-52
ENGINE CONTROL SYSTEM	10-55
AUTO-DECELERATION SYSTEM	10-58
ENGINE AUTOMATIC WARM-UP SYSTEM	10-60
OVERHEAT PREVENTION SYSTEM	10-62
TURBOCHARGER PROTECTION SYSTEM	10-65
AUTOMATIC IDLE STOP SYSTEM	10-67
COMPONENT PARTS OF ENGINE SYSTEM	10-70
COOLING SYSTEM.....	10-86
LAYOUT DRAWING OF COOLING SYSTEM	10-86
FAN SPEED CONTROL SYSTEM OF HYDRAULIC FAN.....	10-89
ENGINE OUTPUT CONTROL SYSTEM OF HYDRAULIC FAN.....	10-91
FAN REVERSE ROTATION SYSTEM OF HYDRAULIC FAN.....	10-94
COMPONENT PARTS OF COOLING SYSTEM.....	10-95
CONTROL SYSTEM.....	10-109
LAYOUT DRAWING OF CONTROL SYSTEM	10-109
MACHINE MONITOR SYSTEM	10-112
KomVision SYSTEM	10-113
KOMTRAX SYSTEM.....	10-117
PPC LEVERS	10-118
AUTOMATIC GREASE SYSTEM.....	10-120
COMPONENT PARTS OF CONTROL SYSTEM.....	10-134
SENSOR.....	10-170
HYDRAULIC SYSTEM.....	10-173
LAYOUT DRAWING OF HYDRAULIC SYSTEM	10-173
CLSS	10-175
ENGINE AND PUMP COMBINED CONTROL SYSTEM.....	10-195
PUMP AND VALVE CONTROL SYSTEM	10-202
COMPONENT PARTS OF HYDRAULIC SYSTEM	10-205
HYDRAULIC SYSTEM - PC490HRD-11E0	10-295
LAYOUT DRAWING OF HYDRAULIC SYSTEM.....	10-295
COMPONENT PARTS OF HYDRAULIC SYSTEM	10-298
WORK EQUIPMENT SYSTEM	10-318
LAYOUT DRAWING OF WORK EQUIPMENT SYSTEM	10-318
STRUCTURE OF VALVE CONTROL	10-323
ONE-TOUCH POWER MAXIMIZING SYSTEM	10-324
MACHINE PUSH-UP SYSTEM.....	10-326
PPC LOCK SYSTEM	10-328
WORK EQUIPMENT AND TRAVEL AUTOMATIC LOCK SYSTEM	10-329
OIL FLOW ADJUSTER SYSTEM FOR ATTACHMENT.....	10-331
TOOL CONTROL SYSTEM	10-333
COMPONENT PARTS OF WORK EQUIPMENT SYSTEM.....	10-335
WORK EQUIPMENT SYSTEM - PC490HRD-11E0	10-358
LAYOUT DRAWING OF WORK EQUIPMENT SYSTEM	10-358
SWING SYSTEM.....	10-362
LAYOUT DRAWING OF SWING SYSTEM	10-362
SWING CONTROL SYSTEM DIAGRAM	10-368
COMPONENT PARTS OF SWING SYSTEM.....	10-372
TRAVEL SYSTEM.....	10-387
LAYOUT DRAWING OF TRAVEL SYSTEM.....	10-387
TRAVEL CONTROL SYSTEM DIAGRAM.....	10-391
COMPONENT PARTS OF TRAVEL SYSTEM	10-393
UNDERCARRIAGE AND FRAME.....	10-415
LAYOUT DRAWING OF UNDERCARRIAGE	10-415
WORK EQUIPMENT.....	10-417
STRUCTURE OF WORK EQUIPMENT	10-417
FUNCTION OF WORK EQUIPMENT	10-418
WORK EQUIPMENT CLEARANCE ADJUSTMENT SHIM.....	10-419

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$