

Shop Manual

**HYDRAULIC
EXCAVATOR**

PC700LC-11E0

SERIAL NUMBERS K75001 and up

KOMATSU

00 INDEX AND FOREWORD

INDEX

00 INDEX AND FOREWORD	00-1
ABBREVIATION LIST	00-19
FOREWORD, SAFETY, BASIC INFORMATION	00-25
HOW TO READ THE SHOP MANUAL	00-25
SAFETY NOTICE FOR OPERATION	00-27
PRECAUTIONS TO PREVENT FIRE	00-35
ACTIONS IF FIRE OCCURS	00-37
PRECAUTIONS FOR DISPOSING OF WASTE MATERIALS	00-38
ACTIONS TAKEN TO MEET EXHAUST GAS REGULATIONS	00-39
METHOD FOR CHECKING ENGINE TYPE	00-40
PRECAUTIONS FOR DEF	00-42
STORE AdBlue/DEF	00-43
PRECAUTIONS FOR HANDLING HYDRAULIC EQUIPMENT	00-44
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF PIPINGS	00-47
PRECAUTIONS FOR HANDLING ELECTRICAL EQUIPMENT	00-54
PRECAUTIONS FOR HANDLING FUEL SYSTEM EQUIPMENT	00-56
PRECAUTIONS FOR HANDLING INTAKE SYSTEM EQUIPMENT	00-57
PRACTICAL USE OF KOMTRAX	00-58
DISCONNECT AND CONNECT PUSH-PULL TYPE COUPLER	00-59
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF CONNECTORS	00-63
METHOD FOR DISCONNECTING AND CONNECTING DEUTSCH CONNECTOR	00-67
METHOD FOR DISCONNECTING AND CONNECTING SLIDE LOCK TYPE CONNECTOR	00-68
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PULL ...	00-70
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PUSH ..	00-71
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH HOUSING TO ROTATE .	00-73
HOW TO READ ELECTRICAL WIRE CODE	00-74
EXPLANATION OF TERMS FOR MAINTENANCE STANDARD	00-78
STANDARD TIGHTENING TORQUE TABLE	00-81
CONVERSION TABLE	00-88
01 SPECIFICATIONS	01-1
CONTENTS	01-2
ABBREVIATION LIST	01-3
SPECIFICATIONS	01-9
SPECIFICATION DRAWING	01-9
WORKING RANGE DRAWINGS	01-12
SPECIFICATIONS	01-14
WEIGHT TABLE	01-20
TABLE OF FUEL, COOLANT, AND LUBRICANTS	01-23
10 STRUCTURE AND FUNCTION	10-1
CONTENTS	10-2
ABBREVIATION LIST	10-5
UREA SCR SYSTEM	10-11
LAYOUT DRAWING OF UREA SCR SYSTEM	10-11
UREA SCR SYSTEM DIAGRAM	10-16
FUNCTION OF UREA SCR SYSTEM	10-17
COMPONENT PARTS OF UREA SCR SYSTEM	10-38
BOOT-UP SYSTEM	10-47
LAYOUT DRAWING OF BOOT-UP SYSTEM	10-47
SYSTEM OPERATING LAMP SYSTEM	10-48
BATTERY DISCONNECT SWITCH	10-50
ENGINE SYSTEM	10-51
LAYOUT DRAWING OF ENGINE SYSTEM	10-51
ENGINE CONTROL SYSTEM	10-53
AUTO-DECELERATION SYSTEM	10-56
AUTOMATIC LOW IDLE SYSTEM	10-58

ENGINE AUTOMATIC WARM-UP SYSTEM	10-60
OVERHEAT PREVENTION SYSTEM	10-63
TURBOCHARGER PROTECTION SYSTEM	10-65
AUTOMATIC IDLE STOP SYSTEM	10-67
COMPONENT PARTS OF ENGINE SYSTEM	10-70
COOLING SYSTEM.....	10-88
LAYOUT DRAWING OF COOLING SYSTEM	10-88
FAN SPEED CONTROL SYSTEM OF HYDRAULIC FAN.....	10-90
ENGINE OUTPUT CONTROL SYSTEM OF HYDRAULIC FAN.....	10-92
FAN REVERSE ROTATION SYSTEM OF HYDRAULIC FAN.....	10-94
COMPONENT PARTS OF COOLING SYSTEM.....	10-95
CONTROL SYSTEM.....	10-110
LAYOUT DRAWING OF CONTROL SYSTEM	10-110
MACHINE MONITOR SYSTEM	10-112
KomVision SYSTEM	10-114
KOMTRAX SYSTEM.....	10-118
COMPONENT PARTS OF CONTROL SYSTEM.....	10-119
HYDRAULIC SYSTEM.....	10-155
LAYOUT DRAWING OF HYDRAULIC SYSTEM	10-155
OLSS	10-158
ENGINE AND PUMP COMBINED CONTROL SYSTEM.....	10-170
COMPONENT PARTS OF HYDRAULIC SYSTEM	10-175
WORK EQUIPMENT SYSTEM	10-227
LAYOUT DRAWING OF WORK EQUIPMENT SYSTEM	10-227
ONE-TOUCH POWER MAXIMIZING SYSTEM	10-233
MACHINE PUSH-UP SYSTEM.....	10-235
PPC LOCK SYSTEM	10-237
WORK EQUIPMENT AND TRAVEL AUTOMATIC LOCK SYSTEM	10-238
COMPONENT PARTS OF WORK EQUIPMENT SYSTEM.....	10-240
SWING SYSTEM.....	10-259
LAYOUT DRAWING OF SWING SYSTEM	10-259
SWING CONTROL SYSTEM DIAGRAM	10-262
COMPONENT PARTS OF SWING SYSTEM.....	10-266
TRAVEL SYSTEM.....	10-280
LAYOUT DRAWING OF TRAVEL SYSTEM.....	10-280
TRAVEL CONTROL SYSTEM DIAGRAM.....	10-284
COMPONENT PARTS OF TRAVEL SYSTEM	10-287
UNDERCARRIAGE AND FRAME.....	10-305
LAYOUT DRAWING OF UNDERCARRIAGE	10-305
WORK EQUIPMENT.....	10-306
STRUCTURE OF WORK EQUIPMENT.....	10-306
FUNCTION OF WORK EQUIPMENT	10-307
WORK EQUIPMENT CLEARANCE ADJUSTMENT SHIM.....	10-308
BUCKET CLEARANCE ADJUSTMENT SHIM	10-309
CAB AND ITS ATTACHMENTS	10-310
ROPS CAB	10-310
CAB MOUNT	10-311
CAB TIPPING STOPPER	10-312
20 STANDARD VALUE TABLE	20-1
CONTENTS	20-2
ABBREVIATION LIST	20-3
STANDARD VALUE TABLE FOR ENGINE	20-9
STANDARD VALUE TABLE FOR ENGINE: PC700LC-11E0.....	20-9
STANDARD VALUE TABLE FOR MACHINE.....	20-14
STANDARD VALUE TABLE FOR MACHINE: PC700LC-11E0	20-14
MACHINE POSTURE AND PROCEDURE FOR MEASURING PERFORMANCE	20-31
30 TESTING AND ADJUSTING.....	30-1
CONTENTS	30-2

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$