

Shop Manual

WHEELED EXCAVATOR

PW98MR-11E0 SERIAL NUMBERS F30003 and up

KOMATSU

00 Index and Foreword

Index

00 Index and Foreword	00-1
Foreword, Safety, Basic Information	00-16
How to Read the Shop Manual	00-16
Safety Notice for Operation	00-18
Precautions to Prevent Fire	00-26
Procedures If Fire Occurs	00-28
Precautions When You Discard Waste Materials	00-29
Precautions When You Handle Hydraulic Equipment	00-30
Precautions When You Disconnect and Connect Pipings	00-33
Precautions When You Handle Electrical Equipment	00-40
Precautions When You Handle Fuel System Equipment	00-42
Precautions When You Handle Intake System Equipment	00-43
Practical Use of KOMTRAX	00-44
Disconnect and Connect Push-Pull Type Coupler	00-45
Precautions for Disconnection and Connection of Connectors	00-49
Disconnect and Connect Deutsch Connector	00-53
How to Disconnect and Connect Slide Lock Type Connector	00-54
Disconnect and Connect Connector with Lock to Pull	00-56
Disconnect and Connect Connector with Lock to Push	00-57
Disconnect and Connect Connector with Housing to Rotate	00-59
How to Read the Codes for Electric Cable	00-60
Explanation of Terms for Maintenance Standard	00-64
Standard Tightening Torque Table	00-67
Conversion Table	00-74
Abbreviation List	00-79
01 Specification	01-1
Table of Contents	01-2
Specifications	01-3
Specification Drawing	01-3
Working Range Drawings	01-4
Specifications	01-6
Weight Table	01-11
Fuel, Coolant, Lubricants (For European Union)	01-13
10 Structure and Function	10-1
Table of Contents	10-2
Boot-up System	10-5
Layout Drawing of Boot-up System	10-5
System Operating Lamp System	10-6
Battery Disconnect Switch	10-7
Engine System	10-8
Layout Drawing of Engine System	10-8
Engine Control System	10-10
Auto-Deceleration System	10-14
Engine Automatic Warm-up System	10-16
Overheat Prevention System	10-18
Turbocharger Protection System	10-19
Automatic Idle Stop System	10-20
Component Parts of Engine System	10-23
Cooling System	10-40
Layout Drawing of Cooling System	10-40
Control System	10-42
Layout Drawing of Control System	10-42
Machine Monitor System	10-44
KOMTRAX System	10-46
Component Parts of Control System	10-47
Hydraulic System	10-86

Layout Drawing of Hydraulic System.....	10-86
CLSS	10-89
Engine and Pump Combined Control System	10-92
Component Parts of Hydraulic System.....	10-97
Work Equipment System.....	10-133
Layout Drawing of Work Equipment System	10-133
PPC Lock System	10-135
Work Equipment Automatic Lock System.....	10-136
Overload Caution System	10-138
Attachment Oil Flow Adjuster System	10-140
Component Parts of Work Equipment System	10-142
Swing System	10-168
Layout Drawing of Swing System.....	10-168
Swing Control System Diagram	10-170
Component Parts of Swing System.....	10-172
Power Train System.....	10-185
Layout Drawing of Power Train System	10-185
Component Parts of Power Train System.....	10-187
Travel Motor.....	10-202
Braking System.....	10-205
Steering System.....	10-207
Axle Locking Cylinder.....	10-211
Steering Unit	10-213
Work Equipment	10-215
Structure of Work Equipment	10-215
Work Equipment Clearance Adjustment Shim.....	10-216
Bucket Clearance Adjustment Shim	10-217
CAB Related Parts.....	10-218
ROPS CAB	10-218
CAB Mount	10-219
20 Standard Value Table	20-1
Table of Contents	20-2
Standard Value Table for Engine	20-3
Standard Value Table for Engine: PW98MR-11E0.....	20-3
Standard Value Table for Machine.....	20-6
Standard Value Table for Machine: PW98MR-11E0	20-6
Machine Posture and Procedures to Measure Performance	20-18
30 Testing and Adjusting	30-1
Table of Contents	30-2
Related Information on Testing and Adjusting	30-5
Sketch of Tools for Testing and Adjusting	30-5
Engine and Cooling System	30-7
Examine Engine Speed.....	30-7
Examine Exhaust Gas Color	30-10
Examine and Adjust Valve Clearance.....	30-13
Examine Compression Pressure	30-15
Examine Blowby Pressure	30-18
Examine Engine Oil Pressure	30-20
Visual Check Inside of EGR Valve	30-22
Clean Inside of EGR Valve.....	30-24
Examine Fuel Pressure.....	30-27
Examine Fuel Return Rate and Leakage.....	30-29
Bleed Air from Fuel System.....	30-34
Examine Fuel Circuit for Leakage	30-36
Handle Cylinder Cut-out Mode Operation.....	30-38
Handle No-Injection Cranking Operation	30-39
Examine Fan Belt.....	30-40
Examine Automatic Tensioner.....	30-41

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$