

# Shop Manual

WHEEL LOADER

**WA1200-6**

SERIAL NUMBERS 60001 and up

**KOMATSU**



# **WHEEL LOADER WA1200-6**

<b>Machine model</b>	<b>Serial number</b>
WA1200-6	60001 and up

---

## **00 Index and foreword**

---

---

## Table of Contents

00 Index and foreword	
Table of contents .....	00 - 2
Table of contents .....	00 - 2
Foreword and general information .....	00- 16
Safety notice .....	00- 16
How to read the shop manual .....	00- 21
Explanation of terms for maintenance standard .....	00- 23
Handling of hydraulic components.....	00- 25
Method of disconnecting and connecting push-pull type coupler .....	00- 27
Handling of electric equipment.....	00- 30
How to read electric wire code.....	00- 40
Precautions when performing work.....	00- 43
Standard tightening torque table.....	00- 46
List of abbreviation.....	00- 50
Conversion table.....	00- 54
01 Specification	
Specification.....	01- 3
Specification dimension drawing.....	01- 3
Specifications.....	01- 4
Weight table .....	01- 7
Table of fuel, coolant and lubricants .....	01- 9
10 Structure and function	
Engine and cooling system .....	10- 4
Damper .....	10- 4
Cooling system .....	10- 5
Cooling fan motor.....	10- 6
Power train.....	10- 11
Power train.....	10- 11
Hydraulic piping drawing of torque converter and transmission .....	10- 13
Torque converter.....	10- 15
Main relief valve and torque converter relief valve.....	10- 24
Torque converter regulator valve .....	10- 27
ECMV.....	10- 29
Transmission.....	10- 35
Transmission control valve .....	10- 46
Transmission lubricating oil relief valve .....	10- 56
Transfer.....	10- 57
Torque converter oil cooler .....	10- 59
Center support .....	10- 60
Axle .....	10- 61
Final drive .....	10- 66
Steering system .....	10- 67
Steering equipment layout drawing.....	10- 67
AJSS.....	10- 68
Steering pump.....	10- 70
Switch pump .....	10- 72
Steering demand valve .....	10- 89
Rotary valve.....	10- 99
EPC valve (for steering).....	10-102

Diverter valve .....	10- 103
Emergency steering relief valve.....	10- 106
Steering lock valve.....	10- 107
Brake system .....	10- 108
Brake equipment layout drawing .....	10- 108
Brake valve .....	10- 109
Charge valve.....	10- 115
Accumulator (for brake) .....	10- 119
Slack adjuster .....	10- 120
Brake .....	10- 122
Parking brake.....	10- 123
Parking brake solenoid valve.....	10- 124
Emergency parking brake release valve.....	10- 125
Check valve of parking brake circuit .....	10- 126
Undercarriage and frame .....	10- 129
Axle mount.....	10- 129
Center hinge pin .....	10- 131
Jack-up point .....	10- 132
Hydraulic system .....	10- 133
Hydraulic piping layout drawing.....	10- 133
Work equipment control lever linkage.....	10- 135
Hydraulic tank.....	10- 136
Work equipment pump No.1 .....	10- 139
Work equipment pump No.2 .....	10- 152
EPC valve (for work equipment).....	10- 175
Neutral cutoff solenoid valve (NC valve).....	10- 177
Relief valve .....	10- 179
Accumulator (for EPC valve) .....	10- 180
Work equipment control valve .....	10- 181
Work equipment.....	10- 194
Work equipment linkage .....	10- 194
Electrical system.....	10- 196
Machine monitor system.....	10- 196
Multi-function monitor .....	10- 224
Work equipment and AJSS control system .....	10- 277
Work equipment control lever .....	10- 312
Transmission control system .....	10- 315
Engine starting circuit .....	10- 341
Engine stopping circuit.....	10- 343
Electric parking brake control .....	10- 347
Sensor .....	10- 357
 20 Standard value table	
Standard value table .....	20- 3
Standard value table for engine.....	20- 3
Standard value table for chassis.....	20- 4
 30 Testing and adjusting	
Precautions Before Work.....	30- 3-1
Tool for testing, adjusting and troubleshooting .....	30- 4
Tools for testing, adjusting, and troubleshooting .....	30- 4
Safety precautions to follow before starting work .....	30- 9
Engine and cooling system.....	30- 13
Testing engine speed .....	30- 13

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$