

Please cut where indicated and insert the label into the plastic pocket on the spine of the binder.



**SKID-STEER  
REPAIR  
LS140, LS150**

Vol. 1  
87036977



**SKID-STEER  
REPAIR  
LS140, LS150**

Vol. 1  
87036977



---

# LS140, LS150 REPAIR MANUAL

## COMPLETE CONTENTS

SECTION 00 - GENERAL INFORMATION .....	2
SECTION 10 - ENGINE .....	3
SECTION 29 - HYDROSTATIC TRANSMISSION .....	7
SECTION 33 - BRAKES AND CONTROLS .....	9
SECTION 35 - HYDRAULIC SYSTEM .....	9
SECTION 37 - TOWING HOOKS AND BALLASTING .....	11
SECTION 39 - FRAMES .....	12
SECTION 44 - AXLES AND WHEELS .....	12
SECTION 50 - CAB CLIMATE CONTROL .....	13
SECTION 55 - ELECTRICAL SYSTEM .....	13
SECTION 82 - FRONT LOADER (BOOM AND MOUNTING PLATE) .....	19
SECTION 88 - ACCESSORIES .....	20
SECTION 90 - PLATFORMS, CAB, BODYWORK, AND DECALS .....	20

The following pages are the collation of the contents pages from each section and chapter of the LS140, LS150 Repair manual. Complete Repair part # 87036977.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the LS140, LS150 Skid Steer.

---

# SECTION 00 - GENERAL INFORMATION

BOOK 1 - 87042550

## CONTENTS

Section	Description	Page
	Introduction .....	2
	About Improvements .....	2
	Company Policy .....	3
	Parts and Accessories .....	3
	Model Codes .....	3
	Precautionary Statements .....	4
	Safety Precaution Information .....	5
	General Safety Information .....	7
	Machine Model and Serial Number Location .....	9
	Engine Model and Serial Number Location .....	9
	Hardware Torque Specifications .....	10
	Installation of Adjustable Fittings in Straight Thread O Ring Bosses .....	12
	Standard Torque Data for Hydraulic Tubes and Fittings .....	12
	Pipe Thread Fitting Torque .....	13
	Lubricants and Coolants .....	13
	Sealants .....	13
	Properly Support a Raised Machine .....	14
	Properly Support Boom on Boom Lock Pins .....	14
	Raising Boom Without Hydraulic Oil Flow .....	14
	Raising Boom Without Battery Voltage (12V) .....	15
	Reattaching Cylinders After Repair with Boom Resting on Boom Lock Pins .....	17
	Major Unit Overhaul .....	18
	Cab and Boom Tilt Procedure .....	19
	Craning the Skid Steer .....	26
	Special Tools .....	29
	Specifications .....	30
	Dimensions .....	33

---

## SECTION 10 - ENGINE

BOOK 1 - 87042550

### Chapter 1 - LS140-N843 (Before Engine S/N 93206) LS150-N843H (Before Engine S/N 91509)

#### CONTENTS

Section	Description	Page
10 000	General Engine Information .....	3
	General Description .....	3
	Engine Component Descriptions .....	3
	Engine Model and Serial Number Location .....	5
	Safety Precautions .....	6
	General Engine Specifications .....	7
	Troubleshooting .....	9
	Specifications - Service Standards .....	12
	Torque Specifications .....	17
	Engine Components Electrical Diagram .....	18
10 001 10	Engine Removal .....	19
	Engine Disassembly Sequence .....	25
	Engine Component Maintenance .....	33
10 101 55	Valve Seat .....	36
10 101 56	Cylinder Block .....	39
10 105 22	Piston and Piston Rings .....	40
	Connecting Rod .....	44
10 103 10	Bearing Holder .....	48
	Front Crankshaft Bearing (Bushing) .....	50
10 103 30	Crankshaft .....	52
10 103 76	Flywheel and Ring Gear .....	54
10 106 40	Camshaft Assembly .....	55
10 106 66	Camshaft Gear and Bearing Assembly .....	55
	Timing Gear .....	56
10 304 41	Oil Pump .....	56
	Port Block .....	57
10 304 10	Oil Filter .....	58
10 402 28	Water Pump Assembly and Thermostat Housing .....	59
10 402 30	Thermostat .....	59
10 230 24	Governor .....	60
	Governor Operation .....	61
10 304 38	Engine Reassembly Sequence .....	63
	Crankshaft and Bearing Holder Assembly .....	64

---

## SECTION 10 - ENGINE

BOOK 1 - 87042550

### Chapter 1 - LS140-N843 (Before Engine S/N 93206) LS150-N843H (Before Engine S/N 91509) (Continued)

#### CONTENTS

Section	Description	Page
	Rear Oil Seal .....	65
	Backplate/Flywheel Housing .....	65
	Flywheel .....	65
	Piston and Connecting Rod .....	66
	Oil Intake and Oil Strainer .....	66
	Oil Sump .....	66
	Dipstick and Tube .....	66
	Front Plate .....	67
	Idler Gear and Oil Pump Assembly .....	67
	Timing Gear Case Installation .....	68
	Crankshaft Pulley .....	69
	Injection Pump Installation .....	69
	Spill Timing Procedure .....	70
29 100 50	Reinstallation of Engine into Skid Steer Frame .....	79
	How to Operate the Engine After Overhaul .....	81
	Cooling System .....	82
	Cooling System Operation .....	82
	Water Pump Assembly and Thermostat Housing .....	83
	Radiator .....	85
	Fuel System .....	86
	Fuel Specifications .....	86
	Diesel Fuel .....	86
	Diesel Fuel Storage .....	86
	Fuel System Components .....	87
	Fuel Guage .....	88
	Cold Start Aid .....	89
	Fuel Filter System .....	89
	Priming the Fuel System .....	90
	Fuel System Testing .....	91
	Fuel System Components .....	94
10 236 08	Fuel Injection Timing .....	102
	Miscellaneous Engine Electrical .....	105
	Special Tools .....	107

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$