

# Shop Manual

BULLDOZER

***D155AX-8***  
***D155PX-8***

SERIAL NUMBERS    D155AX-100001    and up  
                                 D155PX-170001

**KOMATSU**



---

# 00 Index and Foreword

---

# Index

00 Index and Foreword .....	00-1
Abbreviation List .....	00-22
Foreword, Safety, Basic Information .....	00-25
How to Read the Shop Manual .....	00-25
Safety Notice for Operation .....	00-27
Precautions to Prevent Fire .....	00-35
Procedures If Fire Occurs .....	00-37
Precautions for Disposing of Waste Materials .....	00-38
Procedures for Exhaust Gas Regulations .....	00-39
Precautions for DEF .....	00-40
Store DEF .....	00-41
Precautions When You Handle Hydraulic Equipment .....	00-42
Precautions When You Disconnect and Connect Pipings .....	00-45
Precautions When You Handle Electrical Equipment .....	00-52
Precautions When You Handle Fuel System Equipment .....	00-54
Precautions When You Handle Intake System Equipment .....	00-55
Practical Use of KOMTRAX .....	00-56
Disconnect and Connect Push-Pull Type Coupler .....	00-57
Precautions for Disconnection and Connection of Connectors .....	00-61
How to Disconnect and Connect Deutsch Connector .....	00-65
How to Disconnect and Connect Slide Lock Type Connector .....	00-66
How to Disconnect and Connect Connector with Lock to Pull .....	00-68
How to Disconnect and Connect Connector with Lock to Push .....	00-69
How to Disconnect and Connect Connector with Housing to Rotate .....	00-71
How to Read the Codes for Electric Cable .....	00-72
Explanation of Terms for Maintenance Standard .....	00-76
Standard Tightening Torque Table .....	00-79
Conversion Table .....	00-86
01 Specifications .....	01-1
Table of Contents .....	01-2
Specifications .....	01-3
Specification Drawing .....	01-3
Specifications .....	01-6
Weight Table .....	01-18
Table of Fuel, Coolant, and Lubricants .....	01-23
10 Structure and Function .....	10-1
Table of Contents .....	10-2
Urea SCR System .....	10-5
Layout Drawing of Urea SCR System .....	10-5
Urea SCR System Diagram .....	10-7
Function of Urea SCR System .....	10-8
Component Parts of Urea SCR System .....	10-25
Boot-up System .....	10-34
Layout Drawing of Boot-up System (Machine with Gateway Function Controller) .....	10-34
System Operating Lamp System .....	10-35
Battery Disconnect Switch .....	10-38
Engine System .....	10-40
Layout Drawing of Engine System .....	10-40
Engine Control System .....	10-42
Automatic Idle Stop System .....	10-48
Component Parts of Engine System .....	10-52
Cooling System .....	10-72
Layout Drawing of Cooling System .....	10-72
Component Parts of Cooling System .....	10-74
Control System .....	10-90
Layout Drawing of Control System (Machine with KOMTRAX Terminal) .....	10-90

Layout Drawing of Control System (Machine with Gateway Function Controller) .....	10-91
Machine Monitor System.....	10-92
KOMTRAX System .....	10-96
Component Parts of Control System .....	10-98
Hydraulic System .....	10-137
Layout Drawing of Hydraulic System.....	10-137
CLSS .....	10-138
Component Parts of Hydraulic System.....	10-141
Power Train System.....	10-204
Layout Drawing of Power Train System .....	10-204
Operation of Power Train System .....	10-207
Layout of Power Train System (D155PX-8).....	10-209
Operation of Power Train System (D155PX-8).....	10-212
Transmission, Steering, and Brake Control .....	10-213
Palm Command Control System .....	10-216
HSS System.....	10-220
Centralized Pressure Pickup Port.....	10-223
Component Parts of Power Train System.....	10-225
Work Equipment System.....	10-308
Work Equipment Control .....	10-308
Layout Drawing of Front Work Equipment.....	10-310
Layout Drawing of Variable Giant Ripper.....	10-311
Layout Drawing of Variable Multi-Shank Ripper .....	10-312
Component Parts of Work Equipment System .....	10-313
Undercarriage and Frame .....	10-330
Main Frame.....	10-330
Suspension .....	10-331
Track Frame and Idler Cushion .....	10-334
Work Equipment .....	10-336
Structure of Front Work Equipment .....	10-336
Structure of Cylinder Stay .....	10-338
Structure of Variable Giant Ripper.....	10-339
Structure of Variable Multi-Shank Ripper.....	10-340
CAB Related Parts.....	10-341
ROPS CAB .....	10-341
CAB Mount .....	10-342
20 Standard Value Table .....	20-1
Table of Contents .....	20-2
Standard Value Table for Engine .....	20-3
Standard Value Table for Engine: D155AX-8.....	20-3
Standard Value Table for Engine: D155PX-8.....	20-8
Standard Value Table for Machine.....	20-13
Standard Value Table for Machine: D155AX-8 .....	20-13
Standard Value Table for Machine: D155PX-8 .....	20-30
Machine Posture and Procedures to Measure Performance .....	20-46
Standard Value Table for Electricity.....	20-48
Standard Value Table for Electricity.....	20-48
30 Testing and Adjusting .....	30-1
Table of Contents .....	30-2
Precautions Before Work .....	30-5
Related Information on Testing and Adjusting .....	30-6
Tools for Testing and Adjusting.....	30-6
Sketch of Tools for Testing and Adjusting .....	30-14
Engine and Cooling System .....	30-17
Examine Engine Speed.....	30-17
Examine Boost Pressure.....	30-22
Examine Exhaust Gas Temperature.....	30-24
Examine Exhaust Gas Color .....	30-27

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$