

Shop Manual

BULLDOZER

D375Ai-8

SERIAL NUMBERS 80001 and up

KOMATSU

00 Index and Foreword

Index

00 Index and Foreword	00-1
Abbreviation List	00-23
Foreword, Safety, Basic Information	00-26
How to Read the Shop Manual	00-26
Safety Notice for Operation	00-28
Precautions to Prevent Fire	00-36
Procedures If Fire Occurs	00-38
Precautions When You Discard Waste Materials	00-39
Precautions for DEF	00-40
Store DEF	00-41
Precautions When You Handle Hydraulic Equipment	00-42
Precautions When You Disconnect and Connect Pipings	00-45
Precautions When You Handle Electrical Equipment	00-51
Precautions When You Handle Fuel System Equipment	00-53
Precautions When You Handle Intake System Equipment	00-54
Practical Use of KOMTRAX	00-55
Disconnect and Connect Push-Pull Type Coupler	00-56
Precautions for Disconnection and Connection of Connectors	00-60
How to Disconnect and Connect Deutsch Connector	00-64
How to Disconnect and Connect Slide Lock Type Connector	00-65
How to Disconnect and Connect Connector with Lock to Pull	00-67
How to Disconnect and Connect Connector with Lock to Push	00-68
How to Disconnect and Connect Connector with Housing to Rotate	00-70
How to Read the Codes for Electric Cable	00-71
Explanation of Terms for Maintenance Standard	00-75
Standard Tightening Torque Table	00-78
Conversion Table	00-85
01 Specifications	01-1
Table of Contents	01-2
Specifications	01-3
Specification Drawing	01-3
Specifications	01-5
Weight Table	01-11
Fuel, Coolant, Lubricants (For North America)	01-13
10 Structure and Function	10-1
Table of Contents	10-2
Boot-up System	10-6
System Operating Lamp System	10-6
Battery Isolator	10-8
Engine System	10-10
Layout Drawing of Engine System	10-10
Engine Control System	10-12
Automatic Idle Stop System	10-14
Component Parts of Engine System	10-17
Fuel System	10-36
Cooling System	10-42
Layout Drawing of Cooling System	10-42
Component Parts of Cooling System	10-44
Control System	10-72
Layout Drawing of Control System	10-72
Machine Monitor System	10-73
KOMTRAX Plus System	10-76
Component Parts of Control System	10-78
Hydraulic System	10-130
Layout Drawing of Hydraulic System	10-130
CLSS	10-131

Component Parts of Hydraulic System.....	10-134
Power Train System.....	10-165
Layout Drawing of Power Train System	10-165
Operation of Power Train System	10-168
Transmission, Steering, and Brake Control	10-169
Palm Command Control System	10-174
Centralized Pressure Pickup Port.....	10-178
Component Parts of Power Train System.....	10-180
Work Equipment System.....	10-236
Work Equipment Control	10-236
Layout Drawing of Front Work Equipment.....	10-238
Layout Drawing of Variable Giant Ripper.....	10-239
Layout Drawing of Variable Multi-Shank Ripper	10-240
Shoe Slip Control System	10-241
Component Parts of Work Equipment System	10-242
ICT System	10-255
Layout Drawing of ICT System.....	10-255
System Diagram of ICT Control System.....	10-256
Blade Control System	10-258
Smooth Start System	10-264
Slip Control System.....	10-266
Assist Control System	10-268
Straight Travel Correction System.....	10-270
Smooth Carry System.....	10-272
Component Parts of ICT System.....	10-274
Lifting System	10-288
Power Ladder System.....	10-288
Component Parts of Lifting System	10-291
Radio Control System	10-294
Layout Drawing of Radio Control System.....	10-294
Specifications of Radio Control System.....	10-295
Component Parts of Radio Control System.....	10-296
Undercarriage and Frame	10-301
Main Frame.....	10-301
Suspension	10-303
Track Frame and Idler Cushion	10-306
Work Equipment	10-308
Structure of Front Work Equipment	10-308
Structure of Cylinder Stay	10-310
Structure of Variable Giant Ripper.....	10-311
Structure of Variable Multi-Shank Ripper.....	10-312
CAB Related Parts.....	10-313
ROPS.....	10-313
CAB	10-314
CAB Mount	10-315
20 Standard Value Table	20-1
Table of Contents	20-2
Standard Value Table for Engine	20-3
Standard Value Table for Engine: D375AI-8	20-3
Standard Value Table for Machine.....	20-9
Standard Value Table for Machine: D375AI-8.....	20-9
Machine Posture and Procedures to Measure Performance	20-36
30 Testing and Adjusting	30-1
Table of Contents	30-2
Precautions Before Work	30-6
Related Information on Testing and Adjusting	30-7
Tools for Testing and Adjusting.....	30-7
Sketch of Tools for Testing and Adjusting	30-13

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$