

Shop Manual

BULLDOZER

D375Ai-8E0

SERIAL NUMBERS 80063 and up

KOMATSU

00 Index and Foreword

Index

00 Index and Foreword	00-1
Abbreviation List	00-23
Foreword, Safety, Basic Information	00-26
How to Read the Shop Manual	00-26
Safety Notice for Operation	00-28
Precautions to Prevent Fire	00-36
Procedures If Fire Occurs	00-38
Precautions When You Discard Waste Materials	00-39
Engine Technology to Conform Exhaust Gas Emission	00-40
Precautions for DEF	00-41
Store DEF	00-42
Precautions When You Handle Hydraulic Equipment	00-43
Precautions When You Disconnect and Connect Pipings	00-46
Precautions When You Handle Electrical Equipment	00-52
Precautions When You Handle Fuel System Equipment	00-54
Precautions When You Handle Intake System Equipment	00-55
Practical Use of KOMTRAX	00-56
Disconnect and Connect Push-Pull Type Coupler	00-57
Precautions for Disconnection and Connection of Connectors	00-61
How to Disconnect and Connect Deutsch Connector	00-65
How to Disconnect and Connect Slide Lock Type Connector	00-66
How to Disconnect and Connect Connector with Lock to Pull	00-68
How to Disconnect and Connect Connector with Lock to Push	00-69
How to Disconnect and Connect Connector with Housing to Rotate	00-71
How to Read the Codes for Electric Cable	00-72
Explanation of Terms for Maintenance Standard	00-76
Standard Tightening Torque Table	00-79
Conversion Table	00-86
01 Specifications	01-1
Table of Contents	01-2
Specifications	01-3
Specification Drawing	01-3
Specifications	01-5
Weight Table	01-11
Fuel, Coolant, Lubricants (For North America)	01-13
10 Structure and Function	10-1
Table of Contents	10-2
NOx Control System	10-6
Function of NOx Control System	10-6
Boot-up System	10-9
System Operating Lamp System	10-9
Battery Isolator	10-11
Engine System	10-13
Layout Drawing of Engine System	10-13
Engine Control System	10-15
Automatic Idle Stop System	10-17
Component Parts of Engine System	10-20
Fuel System	10-39
Cooling System	10-45
Layout Drawing of Cooling System	10-45
Component Parts of Cooling System	10-47
Control System	10-75
Layout Drawing of Control System	10-75
Machine Monitor System	10-76
KOMTRAX Plus System	10-79
Component Parts of Control System	10-81

Hydraulic System	10-133
Layout Drawing of Hydraulic System.....	10-133
CLSS	10-134
Component Parts of Hydraulic System.....	10-137
Power Train System.....	10-168
Layout Drawing of Power Train System	10-168
Operation of Power Train System	10-171
Transmission, Steering, and Brake Control	10-172
Palm Command Control System	10-177
Centralized Pressure Pickup Port.....	10-181
Component Parts of Power Train System.....	10-183
Work Equipment System.....	10-239
Work Equipment Control	10-239
Layout Drawing of Front Work Equipment.....	10-241
Layout Drawing of Variable Giant Ripper.....	10-242
Layout Drawing of Variable Multi-Shank Ripper	10-243
Shoe Slip Control System	10-244
Component Parts of Work Equipment System	10-245
ICT System	10-258
Layout Drawing of ICT System.....	10-258
System Diagram of ICT Control System.....	10-259
Blade Control System	10-261
Smooth Start System	10-267
Slip Control System.....	10-269
Assist Control System	10-271
Straight Travel Correction System.....	10-273
Smooth Carry System.....	10-275
Component Parts of ICT System.....	10-277
Lifting System	10-291
Power Ladder System.....	10-291
Component Parts of Lifting System	10-294
Radio Control System	10-297
Layout Drawing of Radio Control System.....	10-297
Specifications of Radio Control System.....	10-298
Component Parts of Radio Control System.....	10-299
Undercarriage and Frame	10-304
Main Frame.....	10-304
Suspension	10-306
Track Frame and Idler Cushion	10-309
Work Equipment	10-311
Structure of Front Work Equipment.....	10-311
Structure of Cylinder Stay	10-313
Structure of Variable Giant Ripper.....	10-314
Structure of Variable Multi-Shank Ripper.....	10-315
CAB Related Parts.....	10-316
ROPS.....	10-316
CAB	10-317
CAB Mount	10-318
20 Standard Value Table	20-1
Table of Contents	20-2
Standard Value Table for Engine	20-3
Standard Value Table for Engine: D375AI-8E0.....	20-3
Standard Value Table for Machine.....	20-10
Standard Value Table for Machine: D375AI-8E0	20-10
Machine Posture and Procedures to Measure Performance	20-37
30 Testing and Adjusting	30-1
Table of Contents	30-2
Precautions Before Work	30-6

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$