

Shop Manual

**HYDRAULIC
EXCAVATOR**

PC240LC -11E0

PC240NLC -11E0

SERIAL NUMBERS K75001 and up

KOMATSU

00 INDEX AND FOREWORD

INDEX

00 INDEX AND FOREWORD	00-1
ABBREVIATION LIST	00-20
FOREWORD, SAFETY, BASIC INFORMATION	00-26
HOW TO READ THE SHOP MANUAL.....	00-26
SAFETY NOTICE FOR OPERATION.....	00-28
PRECAUTIONS TO PREVENT FIRE.....	00-36
ACTIONS IF FIRE OCCURS	00-38
PRECAUTIONS FOR DISPOSING OF WASTE MATERIALS	00-39
ACTIONS TAKEN TO MEET EXHAUST GAS REGULATIONS.....	00-40
PRECAUTIONS FOR DEF.....	00-41
STORE AdBlue/DEF	00-42
PRECAUTIONS FOR HANDLING HYDRAULIC EQUIPMENT	00-43
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF PIPINGS.....	00-46
PRECAUTIONS FOR HANDLING ELECTRICAL EQUIPMENT.....	00-53
PRECAUTIONS FOR HANDLING FUEL SYSTEM EQUIPMENT	00-55
PRECAUTIONS FOR HANDLING INTAKE SYSTEM EQUIPMENT	00-56
PRACTICAL USE OF KOMTRAX	00-57
DISCONNECT AND CONNECT PUSH-PULL TYPE COUPLER	00-58
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF CONNECTORS	00-62
METHOD FOR DISCONNECTING AND CONNECTING DEUTSCH CONNECTOR	00-66
METHOD FOR DISCONNECTING AND CONNECTING SLIDE LOCK TYPE CONNECTOR	00-67
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PULL ...	00-69
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PUSH ..	00-70
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH HOUSING TO ROTATE .	00-72
HOW TO READ ELECTRICAL WIRE CODE	00-73
EXPLANATION OF TERMS FOR MAINTENANCE STANDARD.....	00-77
STANDARD TIGHTENING TORQUE TABLE.....	00-80
CONVERSION TABLE	00-87
01 SPECIFICATIONS	01-1
CONTENTS	01-2
ABBREVIATION LIST	01-3
SPECIFICATIONS	01-9
SPECIFICATION DRAWING.....	01-9
WORKING RANGE DRAWINGS	01-10
SPECIFICATIONS	01-11
WEIGHT TABLE	01-14
TABLE OF FUEL, COOLANT, AND LUBRICANTS	01-16
10 STRUCTURE AND FUNCTION	10-1
CONTENTS	10-2
ABBREVIATION LIST	10-6
UREA SCR SYSTEM.....	10-12
LAYOUT DRAWING OF UREA SCR SYSTEM	10-13
UREA SCR SYSTEM DIAGRAM	10-18
FUNCTION OF UREA SCR SYSTEM.....	10-19
COMPONENT PARTS OF UREA SCR SYSTEM.....	10-29
BOOT-UP SYSTEM	10-38
LAYOUT DRAWING OF BOOT-UP SYSTEM.....	10-38
SYSTEM OPERATING LAMP SYSTEM	10-40
BATTERY DISCONNECT SWITCH	10-42
ENGINE SYSTEM	10-43
LAYOUT DRAWING OF ENGINE SYSTEM.....	10-43
ENGINE CONTROL SYSTEM	10-45
AUTO-DECELERATION SYSTEM.....	10-48
ENGINE AUTOMATIC WARM-UP SYSTEM.....	10-50
OVERHEAT PREVENTION SYSTEM.....	10-52

TURBOCHARGER PROTECTION SYSTEM	10-55
AUTOMATIC IDLE STOP SYSTEM	10-57
COMPONENT PARTS OF ENGINE SYSTEM	10-60
COOLING SYSTEM.....	10-78
LAYOUT DRAWING OF COOLING SYSTEM	10-78
CONTROL SYSTEM.....	10-80
LAYOUT DRAWING OF CONTROL SYSTEM	10-80
MACHINE MONITOR SYSTEM	10-83
KomVision SYSTEM	10-84
KOMTRAX SYSTEM.....	10-88
PPC LEVERS	10-89
AUTOMATIC GREASE SYSTEM	10-91
COMPONENT PARTS OF CONTROL SYSTEM.....	10-106
SENSOR.....	10-140
HYDRAULIC SYSTEM.....	10-152
LAYOUT DRAWING OF HYDRAULIC SYSTEM	10-152
CLSS	10-158
ENGINE AND PUMP COMBINED CONTROL SYSTEM.....	10-177
PUMP AND VALVE CONTROL SYSTEM	10-183
COMPONENT PARTS OF HYDRAULIC SYSTEM	10-186
WORK EQUIPMENT SYSTEM	10-271
LAYOUT DRAWING OF WORK EQUIPMENT SYSTEM	10-271
STRUCTURE OF VALVE CONTROL	10-276
ONE-TOUCH POWER MAXIMIZING SYSTEM	10-278
PPC LOCK SYSTEM	10-280
WORK EQUIPMENT AND TRAVEL AUTOMATIC LOCK SYSTEM	10-281
OIL FLOW ADJUSTER SYSTEM FOR ATTACHMENT.....	10-283
TOOL CONTROL SYSTEM	10-286
COMPONENT PARTS OF WORK EQUIPMENT SYSTEM.....	10-288
SWING SYSTEM	10-317
LAYOUT DRAWING OF SWING SYSTEM	10-317
SWING CONTROL SYSTEM DIAGRAM	10-321
COMPONENT PARTS OF SWING SYSTEM.....	10-325
TRAVEL SYSTEM.....	10-339
LAYOUT DRAWING OF TRAVEL SYSTEM.....	10-339
TRAVEL CONTROL SYSTEM DIAGRAM.....	10-343
COMPONENT PARTS OF TRAVEL SYSTEM	10-345
UNDERCARRIAGE AND FRAME.....	10-366
LAYOUT DRAWING OF UNDERCARRIAGE	10-366
WORK EQUIPMENT.....	10-368
STRUCTURE OF WORK EQUIPMENT	10-368
FUNCTION OF WORK EQUIPMENT	10-369
WORK EQUIPMENT CLEARANCE ADJUSTMENT SHIM.....	10-370
BUCKET CLEARANCE ADJUSTMENT SHIM	10-371
CAB AND ITS ATTACHMENTS	10-372
ROPS CAB	10-372
CAB MOUNT	10-373
CAB TIPPING STOPPER	10-374
20 STANDARD VALUE TABLE	20-1
CONTENTS	20-2
ABBREVIATION LIST	20-3
STANDARD VALUE TABLE FOR ENGINE	20-9
STANDARD VALUE TABLE FOR ENGINE: PC240LC-11E0, PC240NLC-11E0.....	20-9
STANDARD VALUE TABLE FOR MACHINE.....	20-13
STANDARD VALUE TABLE FOR MACHINE: PC240LC-11E0, PC240NLC-11E0	20-13
MACHINE POSTURE AND PROCEDURE FOR MEASURING PERFORMANCE	20-27
STANDARD VALUE TABLE FOR ELECTRICAL	20-31
STANDARD VALUE TABLE FOR ELECTRICAL	20-31

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$