

Shop Manual

**HYDRAULIC
EXCAVATOR**

PC290LC -11

PC290NLC -11

SERIAL NUMBERS 35001 and up

K70001 and up

KOMATSU

00 INDEX AND FOREWORD

INDEX

00 INDEX AND FOREWORD	00-1
ABBREVIATION LIST	00-19
FOREWORD, SAFETY, BASIC INFORMATION	00-24
HOW TO READ THE SHOP MANUAL	00-24
SAFETY NOTICE FOR OPERATION	00-26
PRECAUTIONS TO PREVENT FIRE	00-34
ACTIONS IF FIRE OCCURS	00-36
PRECAUTIONS FOR DISPOSING OF WASTE MATERIALS	00-37
ACTIONS TAKEN TO MEET EXHAUST GAS REGULATIONS	00-38
PRECAUTIONS FOR DEF	00-39
STORE AdBlue/DEF	00-40
PRECAUTIONS FOR HANDLING HYDRAULIC EQUIPMENT	00-41
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF PIPINGS	00-43
PRECAUTIONS FOR HANDLING ELECTRICAL EQUIPMENT	00-49
PRECAUTIONS FOR HANDLING FUEL SYSTEM EQUIPMENT	00-51
PRECAUTIONS FOR HANDLING INTAKE SYSTEM EQUIPMENT	00-52
PRACTICAL USE OF KOMTRAX	00-53
DISCONNECT AND CONNECT PUSH-PULL TYPE COUPLER	00-54
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF CONNECTORS	00-58
METHOD FOR DISCONNECTING AND CONNECTING DEUTSCH CONNECTOR	00-62
METHOD FOR DISCONNECTING AND CONNECTING SLIDE LOCK TYPE CONNECTOR	00-63
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PULL ..	00-65
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PUSH ..	00-66
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH HOUSING TO ROTATE .	00-68
HOW TO READ ELECTRICAL WIRE CODE	00-69
EXPLANATION OF TERMS FOR MAINTENANCE STANDARD	00-73
STANDARD TIGHTENING TORQUE TABLE	00-76
CONVERSION TABLE	00-83
01 SPECIFICATIONS	01-1
CONTENTS	01-2
ABBREVIATION LIST	01-3
SPECIFICATIONS	01-8
SPECIFICATION DRAWING	01-8
WORKING RANGE DRAWINGS	01-9
SPECIFICATIONS	01-10
WEIGHT TABLE	01-13
TABLE OF FUEL, COOLANT, AND LUBRICANTS	01-15
10 STRUCTURE AND FUNCTION	10-1
CONTENTS	10-2
ABBREVIATION LIST	10-5
UREA SCR SYSTEM	10-10
LAYOUT DRAWING OF UREA SCR SYSTEM	10-11
UREA SCR SYSTEM DIAGRAM	10-16
FUNCTION OF UREA SCR SYSTEM	10-17
COMPONENT PARTS OF UREA SCR SYSTEM	10-26
BOOT-UP SYSTEM	10-35
LAYOUT DRAWING OF BOOT-UP SYSTEM	10-35
SYSTEM OPERATING LAMP SYSTEM	10-37
BATTERY DISCONNECT SWITCH	10-38
ENGINE SYSTEM	10-39
LAYOUT DRAWING OF ENGINE SYSTEM	10-39
ENGINE CONTROL SYSTEM	10-41
AUTO-DECELERATION SYSTEM	10-44
ENGINE AUTOMATIC WARM-UP SYSTEM	10-46
OVERHEAT PREVENTION SYSTEM	10-48

TURBOCHARGER PROTECTION SYSTEM	10-51
AUTOMATIC IDLE STOP SYSTEM	10-53
COMPONENT PARTS OF ENGINE SYSTEM	10-56
COOLING SYSTEM.....	10-73
LAYOUT DRAWING OF COOLING SYSTEM	10-73
CONTROL SYSTEM.....	10-75
LAYOUT DRAWING OF CONTROL SYSTEM	10-75
MACHINE MONITOR SYSTEM	10-78
KOMTRAX SYSTEM.....	10-79
PPC LEVERS	10-80
AUTOMATIC GREASE SYSTEM	10-82
COMPONENT PARTS OF CONTROL SYSTEM.....	10-97
.....	10-126
HYDRAULIC SYSTEM.....	10-130
LAYOUT DRAWING OF HYDRAULIC SYSTEM	10-130
CLSS	10-136
ENGINE AND PUMP COMBINED CONTROL SYSTEM.....	10-154
PUMP AND VALVE CONTROL SYSTEM	10-160
COMPONENT PARTS OF HYDRAULIC SYSTEM	10-163
WORK EQUIPMENT SYSTEM	10-248
LAYOUT DRAWING OF WORK EQUIPMENT SYSTEM	10-248
STRUCTURE OF VALVE CONTROL.....	10-253
ONE-TOUCH POWER MAXIMIZING SYSTEM	10-255
PPC LOCK SYSTEM	10-257
WORK EQUIPMENT AND TRAVEL AUTOMATIC LOCK SYSTEM	10-258
OIL FLOW ADJUSTER SYSTEM FOR ATTACHMENT.....	10-260
COMPONENT PARTS OF WORK EQUIPMENT SYSTEM.....	10-263
SWING SYSTEM.....	10-289
LAYOUT DRAWING OF SWING SYSTEM	10-289
SWING CONTROL SYSTEM DIAGRAM	10-293
COMPONENT PARTS OF SWING SYSTEM.....	10-297
TRAVEL SYSTEM.....	10-311
LAYOUT DRAWING OF TRAVEL SYSTEM.....	10-311
TRAVEL CONTROL SYSTEM DIAGRAM.....	10-315
COMPONENT PARTS OF TRAVEL SYSTEM	10-317
UNDERCARRIAGE AND FRAME.....	10-337
LAYOUT DRAWING OF UNDERCARRIAGE	10-337
WORK EQUIPMENT.....	10-339
STRUCTURE OF WORK EQUIPMENT	10-339
FUNCTION OF WORK EQUIPMENT	10-340
WORK EQUIPMENT CLEARANCE ADJUSTMENT SHIM.....	10-341
BUCKET CLEARANCE ADJUSTMENT SHIM	10-342
CAB AND ITS ATTACHMENTS	10-343
ROPS CAB	10-343
CAB MOUNT	10-344
CAB TIPPING STOPPER	10-345
20 STANDARD VALUE TABLE	20-1
CONTENTS	20-2
ABBREVIATION LIST	20-3
STANDARD VALUE TABLE FOR ENGINE	20-8
STANDARD VALUE TABLE FOR ENGINE: PC290LC-11, PC290NLC-11.....	20-8
STANDARD VALUE TABLE FOR MACHINE.....	20-12
STANDARD VALUE TABLE FOR MACHINE: PC290LC-11, PC290NLC-11	20-12
MACHINE POSTURE AND PROCEDURE FOR MEASURING PERFORMANCE	20-25
STANDARD VALUE TABLE FOR ELECTRICAL	20-29
STANDARD VALUE TABLE FOR ELECTRICAL	20-29
30 TESTING AND ADJUSTING	30-1
CONTENTS	30-2

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$