

# Shop Manual

BULLDOZER

**D155AX-8EO**

SERIAL NUMBERS 100358 and up

**KOMATSU**



---

## **00 Index and Foreword**

---

# Index

00 Index and Foreword .....	00-1
Abbreviation List .....	00-22
Foreword, Safety, Basic Information.....	00-25
How to Read the Shop Manual .....	00-25
Safety Notice for Operation .....	00-27
Precautions to Prevent Fire.....	00-35
Procedures If Fire Occurs .....	00-37
Precautions When You Discard Waste Materials.....	00-38
Procedures for Exhaust Gas Regulations.....	00-39
Precautions for DEF.....	00-40
Store DEF .....	00-41
Precautions When You Handle Hydraulic Equipment.....	00-42
Precautions When You Disconnect and Connect Pipings.....	00-45
Precautions When You Handle Electrical Equipment .....	00-52
Precautions When You Handle Fuel System Equipment .....	00-54
Precautions When You Handle Intake System Equipment .....	00-55
Practical Use of KOMTRAX .....	00-56
Disconnect and Connect Push-Pull Type Coupler .....	00-57
Precautions for Disconnection and Connection of Connectors .....	00-61
Disconnect and Connect Deutsch Connector .....	00-65
How to Disconnect and Connect Slide Lock Type Connector .....	00-66
Disconnect and Connect Connector with Lock to Pull .....	00-68
Disconnect and Connect Connector with Lock to Push .....	00-69
Disconnect and Connect Connector with Housing to Rotate .....	00-71
How to Read the Codes for Electric Cable .....	00-72
Explanation of Terms for Maintenance Standard .....	00-76
Standard Tightening Torque Table.....	00-79
Conversion Table .....	00-86
01 Specification.....	01-1
Table of Contents .....	01-2
Specifications .....	01-3
Specification Drawing.....	01-3
Specifications.....	01-5
Weight Table .....	01-13
Table of Fuel, Coolant, and Lubricants .....	01-16
10 Structure and Function .....	10-1
Table of Contents .....	10-2
Urea SCR System.....	10-5
Layout Drawing of Urea SCR System .....	10-5
Urea SCR System Diagram .....	10-7
Function of Urea SCR System .....	10-8
Component Parts of Urea SCR System .....	10-25
Boot-up System .....	10-34
Layout Drawing of Boot-up System (Machine with Gateway Function Controller) .....	10-34
System Operating Lamp System.....	10-35
Battery Disconnect Switch.....	10-38
Engine System.....	10-40
Layout Drawing of Engine System .....	10-40
Engine Control System .....	10-42
Automatic Idle Stop System .....	10-48
Component Parts of Engine System .....	10-52
Cooling System.....	10-72
Layout Drawing of Cooling System .....	10-72
Component Parts of Cooling System .....	10-74
Control System .....	10-90
Layout Drawing of Control System (Machine with KOMTRAX Terminal) .....	10-90

Layout Drawing of Control System (Machine with Gateway Function Controller) .....	10-91
Machine Monitor System.....	10-92
KOMTRAX System .....	10-96
Component Parts of Control System .....	10-98
Hydraulic System .....	10-137
Layout Drawing of Hydraulic System.....	10-137
CLSS .....	10-138
Component Parts of Hydraulic System.....	10-141
Power Train System .....	10-204
Layout Drawing of Power Train System .....	10-204
Operation of Power Train System .....	10-207
Transmission, Steering, and Brake Control .....	10-209
Palm Command Control System .....	10-212
HSS System.....	10-216
Centralized Pressure Pickup Port.....	10-219
Component Parts of Power Train System.....	10-221
Work Equipment System .....	10-301
Work Equipment Control .....	10-301
Layout Drawing of Front Work Equipment.....	10-303
Layout Drawing of Variable Giant Ripper.....	10-304
Layout Drawing of Variable Multi-Shank Ripper .....	10-305
Component Parts of Work Equipment System .....	10-306
Undercarriage and Frame .....	10-323
Main Frame.....	10-323
Suspension .....	10-324
Track Frame and Idler Cushion .....	10-327
Work Equipment .....	10-329
Structure of Front Work Equipment .....	10-329
Structure of Cylinder Stay .....	10-331
Structure of Variable Giant Ripper.....	10-332
Structure of Variable Multi-Shank Ripper.....	10-333
CAB Related Parts .....	10-334
ROPS CAB .....	10-334
CAB Mount .....	10-335
20 Standard Value Table .....	20-1
Table of Contents .....	20-2
Standard Value Table for Engine .....	20-3
Standard Value Table for Engine: D155AX-8E0 .....	20-3
Standard Value Table for Machine.....	20-8
Standard Value Table for Machine: D155AX-8E0 .....	20-8
Machine Posture and Procedures to Measure Performance .....	20-25
Standard Value Table for Electricity .....	20-27
Standard Value Table for Electricity .....	20-27
30 Testing and Adjusting .....	30-1
Table of Contents .....	30-2
Precautions Before Work .....	30-5
Related Information on Testing and Adjusting .....	30-6
Tools for Testing and Adjusting.....	30-6
Sketch of Tools for Testing and Adjusting .....	30-14
Engine and Cooling System .....	30-17
Examine Engine Speed.....	30-17
Examine Boost Pressure.....	30-22
Examine Exhaust Gas Temperature .....	30-24
Examine Exhaust Gas Color .....	30-27
Examine Mass Air Flow and Temperature Sensor.....	30-29
Examine and Adjust Valve Clearance.....	30-31
Examine Compression Pressure.....	30-34
Examine Blowby Pressure .....	30-37

It's a preview. You can download the full file by  
clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$