

Shop Manual

BULLDOZER

D155AXi-8E0

SERIAL NUMBERS 100358 and up

KOMATSU

00 Index and Foreword

Index

00 Index and Foreword	00-1
Abbreviation List	00-23
Foreword, Safety, Basic Information	00-26
How to Read the Shop Manual	00-26
Safety Notice for Operation	00-28
Precautions to Prevent Fire	00-36
Procedures If Fire Occurs	00-38
Precautions for Disposing of Waste Materials	00-39
Procedures for Exhaust Gas Regulations	00-40
Precautions for DEF	00-41
Store DEF	00-42
Precautions When You Handle Hydraulic Equipment	00-43
Precautions When You Disconnect and Connect Pipings	00-46
Precautions When You Handle Electrical Equipment	00-53
Precautions When You Handle Fuel System Equipment	00-55
Precautions When You Handle Intake System Equipment	00-56
Practical Use of KOMTRAX	00-57
Disconnect and Connect Push-Pull Type Coupler	00-58
Precautions for Disconnection and Connection of Connectors	00-62
How to Disconnect and Connect Deutsch Connector	00-66
How to Disconnect and Connect Slide Lock Type Connector	00-67
How to Disconnect and Connect Connector with Lock to Pull	00-69
How to Disconnect and Connect Connector with Lock to Push	00-70
How to Disconnect and Connect Connector with Housing to Rotate	00-72
How to Read the Codes for Electric Cable	00-73
Explanation of Terms for Maintenance Standard	00-77
Standard Tightening Torque Table	00-80
Conversion Table	00-87
01 Specifications	01-1
Table of Contents	01-2
Specifications	01-3
Specification Drawing	01-3
Specifications	01-5
Weight Table	01-12
Table of Fuel, Coolant, and Lubricants	01-14
10 Structure and Function	10-1
Table of Contents	10-2
Urea SCR System	10-6
Layout Drawing of Urea SCR System	10-6
Urea SCR System Diagram	10-8
Function of Urea SCR System	10-9
Component Parts of Urea SCR System	10-25
Boot-up System	10-34
Layout Drawing of Boot-up System (Machine with Gateway Function Controller)	10-34
System Operating Lamp System	10-35
Battery Disconnect Switch	10-38
Engine System	10-40
Layout Drawing of Engine System	10-40
Engine Control System	10-42
Automatic Idle Stop System	10-48
Component Parts of Engine System	10-52
Cooling System	10-72
Layout Drawing of Cooling System	10-72
Component Parts of Cooling System	10-74
Control System	10-90
Layout Drawing of Control System (Machine with KOMTRAX Terminal)	10-90

Layout Drawing of Control System (Machine with Gateway Function Controller)	10-91
Machine Monitor System.....	10-92
KOMTRAX System	10-96
Component Parts of Control System	10-98
Hydraulic System	10-137
Layout Drawing of Hydraulic System.....	10-137
CLSS	10-138
Component Parts of Hydraulic System.....	10-141
Power Train System.....	10-204
Layout Drawing of Power Train System	10-204
Operation of Power Train System	10-207
Transmission, Steering, and Brake Control	10-209
Palm Command Control System	10-212
HSS System.....	10-216
Centralized Pressure Pickup Port.....	10-219
Component Parts of Power Train System.....	10-221
Work Equipment System.....	10-301
Work Equipment Control	10-301
Layout Drawing of Front Work Equipment.....	10-303
Layout Drawing of Variable Giant Ripper.....	10-304
Layout Drawing of Variable Multi-Shank Ripper	10-305
Component Parts of Work Equipment System	10-306
ICT System	10-323
Layout Drawing of ICT System.....	10-323
System Diagram of ICT Control System.....	10-325
Blade Control System	10-327
Smooth Start System	10-333
Slip Control System.....	10-335
Assist Control System.....	10-336
Component Parts of ICT System.....	10-338
Undercarriage and Frame	10-350
Main Frame.....	10-350
Suspension	10-351
Track Frame and Idler Cushion	10-354
Work Equipment	10-356
Structure of Front Work Equipment.....	10-356
Structure of Cylinder Stay	10-358
Structure of Variable Giant Ripper.....	10-359
Structure of Variable Multi-Shank Ripper.....	10-360
CAB Related Parts.....	10-361
ROPS CAB	10-361
CAB Mount	10-362
20 Standard Value Table	20-1
Table of Contents	20-2
Standard Value Table for Engine	20-3
Standard Value Table for Engine: D155AXI-8E0	20-3
Standard Value Table for Machine.....	20-8
Standard Value Table for Machine: D155AXI-8E0	20-8
Machine Posture and Procedures to Measure Performance	20-28
Standard Value Table for Electricity.....	20-30
Standard Value Table for Electricity.....	20-30
30 Testing and Adjusting	30-1
Table of Contents	30-2
Precautions Before Work	30-6
Related Information on Testing and Adjusting	30-7
Tools for Testing and Adjusting.....	30-7
Sketch of Tools for Testing and Adjusting	30-15
Engine and Cooling System	30-18

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$