

Shop Manual

BULLDOZER

D375A-8

SERIAL NUMBERS 80001 and up

KOMATSU

00 Index and Foreword

Index

00 Index and Foreword	00-1
Abbreviation List	00-22
Foreword, Safety, Basic Information	00-25
How to Read the Shop Manual	00-25
Safety Notice for Operation	00-27
Precautions to Prevent Fire	00-35
Procedures If Fire Occurs	00-37
Precautions When You Discard Waste Materials	00-38
Precautions for DEF	00-39
Store DEF	00-40
Precautions When You Handle Hydraulic Equipment	00-41
Precautions When You Disconnect and Connect Pipings	00-44
Precautions When You Handle Electrical Equipment	00-50
Precautions When You Handle Fuel System Equipment	00-52
Precautions When You Handle Intake System Equipment	00-53
Practical Use of KOMTRAX	00-54
Disconnect and Connect Push-Pull Type Coupler	00-55
Precautions for Disconnection and Connection of Connectors	00-59
How to Disconnect and Connect Deutsch Connector	00-63
How to Disconnect and Connect Slide Lock Type Connector	00-64
How to Disconnect and Connect Connector with Lock to Pull	00-66
How to Disconnect and Connect Connector with Lock to Push	00-67
How to Disconnect and Connect Connector with Housing to Rotate	00-69
How to Read the Codes for Electric Cable	00-70
Explanation of Terms for Maintenance Standard	00-74
Standard Tightening Torque Table	00-77
Conversion Table	00-84
01 Specifications	01-1
Table of Contents	01-2
Specifications	01-3
Specification Drawing	01-3
Specifications	01-5
Weight Table	01-12
Fuel, Coolant, Lubricants (For North America)	01-15
10 Structure and Function	10-1
Table of Contents	10-2
Boot-up System	10-5
System Operating Lamp System	10-5
Battery Disconnect Switch	10-7
Battery Isolator	10-9
Engine System	10-11
Layout Drawing of Engine System	10-11
Engine Control System	10-13
Automatic Idle Stop System	10-16
Component Parts of Engine System	10-20
Fuel System	10-40
Cooling System	10-46
Layout Drawing of Cooling System	10-46
Component Parts of Cooling System	10-48
Control System	10-76
Layout Drawing of Control System	10-76
Machine Monitor System	10-77
KOMTRAX Plus System	10-80
Component Parts of Control System	10-82
Hydraulic System	10-138
Layout Drawing of Hydraulic System	10-138

CLSS	10-139
Component Parts of Hydraulic System.....	10-142
Power Train System.....	10-175
Layout Drawing of Power Train System	10-175
Operation of Power Train System	10-178
Transmission, Steering, and Brake Control	10-179
Palm Command Control System	10-184
Centralized Pressure Pickup Port.....	10-188
Component Parts of Power Train System.....	10-190
Work Equipment System.....	10-254
Work Equipment Control	10-254
Layout Drawing of Front Work Equipment.....	10-256
Layout Drawing of Variable Giant Ripper.....	10-257
Layout Drawing of Variable Multi-Shank Ripper	10-258
Shoe Slip Control System	10-259
Component Parts of Work Equipment System	10-260
Lifting System	10-274
Power Ladder System.....	10-274
Component Parts of Lifting System	10-277
Radio Control System	10-280
Layout Drawing of Radio Control System.....	10-280
Specifications of Radio Control System.....	10-281
Component Parts of Radio Control System.....	10-282
Undercarriage and Frame	10-287
Main Frame.....	10-287
Suspension	10-289
Track Frame and Idler Cushion	10-292
Work Equipment	10-294
Structure of Front Work Equipment.....	10-294
Structure of Cylinder Stay	10-296
Structure of Variable Giant Ripper.....	10-297
Structure of Variable Multi-Shank Ripper.....	10-298
CAB Related Parts.....	10-299
ROPS.....	10-299
CAB	10-300
CAB Mount	10-301
20 Standard Value Table	20-1
Table of Contents	20-2
Standard Value Table for Engine.....	20-3
Standard Value Table for Engine: D375A-8	20-3
Standard Value Table for Machine.....	20-9
Standard Value Table for Machine: D375A-8.....	20-9
Machine Posture and Procedures to Measure Performance	20-33
30 Testing and Adjusting	30-1
Table of Contents	30-2
Precautions Before Work	30-5
Related Information on Testing and Adjusting	30-6
Tools for Testing and Adjusting.....	30-6
Sketch of Tools for Testing and Adjusting	30-12
Engine and Cooling System	30-15
Examine Engine Speed.....	30-15
Examine Boost Pressure.....	30-19
Examine Exhaust Gas Temperature.....	30-22
Examine Exhaust Gas Color	30-26
Examine Mass Air Flow and Temperature Sensor.....	30-30
Examine and Adjust Valve Clearance.....	30-32
Examine Compression Pressure	30-35
Examine Blowby Pressure	30-39

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$