

Shop Manual

BULLDOZER

D375Ai-8

SERIAL NUMBERS 80001 and up

KOMATSU

00 INDEX AND FOREWORD

INDEX

00 INDEX AND FOREWORD	00-1
ABBREVIATION LIST	00-24
FOREWORD, SAFETY, BASIC INFORMATION	00-30
HOW TO READ THE SHOP MANUAL.....	00-30
SAFETY NOTICE FOR OPERATION.....	00-32
PRECAUTIONS TO PREVENT FIRE.....	00-40
ACTIONS IF FIRE OCCURS	00-42
PRECAUTIONS FOR DISPOSING OF WASTE MATERIALS	00-43
.....	00-43
PRECAUTIONS FOR HANDLING HYDRAULIC EQUIPMENT	00-45
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF PIPINGS.....	00-48
PRECAUTIONS FOR HANDLING ELECTRICAL EQUIPMENT.....	00-54
PRECAUTIONS FOR HANDLING FUEL SYSTEM EQUIPMENT	00-56
PRECAUTIONS FOR HANDLING INTAKE SYSTEM EQUIPMENT	00-57
PRACTICAL USE OF KOMTRAX	00-58
DISCONNECT AND CONNECT PUSH-PULL TYPE COUPLER	00-59
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF CONNECTORS	00-63
METHOD FOR DISCONNECTING AND CONNECTING DEUTSCH CONNECTOR	00-67
METHOD FOR DISCONNECTING AND CONNECTING SLIDE LOCK TYPE CONNECTOR	00-68
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PULL ...	00-70
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PUSH ..	00-71
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH HOUSING TO ROTATE .	00-73
.....	00-73
HOW TO READ ELECTRICAL WIRE CODE	00-74
EXPLANATION OF TERMS FOR MAINTENANCE STANDARD.....	00-78
STANDARD TIGHTENING TORQUE TABLE.....	00-81
CONVERSION TABLE	00-88
01 SPECIFICATIONS	01-1
CONTENTS	01-2
ABBREVIATION LIST	01-3
SPECIFICATIONS	01-9
SPECIFICATION DRAWING	01-9
SPECIFICATIONS	01-11
WEIGHT TABLE	01-17
FUEL, COOLANT, LUBRICANTS (FOR NORTH AMERICA)	01-19
10 STRUCTURE AND FUNCTION	10-1
CONTENTS	10-2
ABBREVIATION LIST	10-6
BOOT-UP SYSTEM	10-12
SYSTEM OPERATING LAMP SYSTEM	10-12
BATTERY ISOLATOR	10-14
ENGINE SYSTEM	10-16
LAYOUT DRAWING OF ENGINE SYSTEM.....	10-16
ENGINE CONTROL SYSTEM	10-18
AUTOMATIC IDLE STOP SYSTEM	10-20
COMPONENT PARTS OF ENGINE SYSTEM	10-23
FUEL SYSTEM.....	10-42
COOLING SYSTEM.....	10-48
LAYOUT DRAWING OF COOLING SYSTEM	10-48
COMPONENT PARTS OF COOLING SYSTEM.....	10-50
CONTROL SYSTEM.....	10-77
LAYOUT DRAWING OF CONTROL SYSTEM	10-77
MACHINE MONITOR SYSTEM	10-78
KOMTRAX Plus SYSTEM.....	10-81
COMPONENT PARTS OF CONTROL SYSTEM.....	10-83
HYDRAULIC SYSTEM.....	10-131

LAYOUT DRAWING OF HYDRAULIC SYSTEM	10-131
CLSS	10-132
COMPONENT PARTS OF HYDRAULIC SYSTEM	10-135
POWER TRAIN SYSTEM	10-166
LAYOUT OF POWER TRAIN SYSTEM	10-166
OPERATION OF POWER TRAIN SYSTEM.....	10-169
TRANSMISSION, STEERING, AND BRAKE CONTROL	10-170
PALM COMMAND CONTROL SYSTEM.....	10-173
CENTRALIZED PRESSURE PICKUP PORT.....	10-177
COMPONENT PARTS OF POWER TRAIN SYSTEM.....	10-179
WORK EQUIPMENT SYSTEM	10-233
WORK EQUIPMENT CONTROL	10-233
LAYOUT DRAWING OF FRONT WORK EQUIPMENT	10-235
LAYOUT OF VARIABLE GIANT RIPPER.....	10-236
LAYOUT OF VARIABLE MULTI-SHANK RIPPER	10-237
SHOE SLIP CONTROL SYSTEM	10-238
COMPONENT PARTS OF WORK EQUIPMENT SYSTEM.....	10-239
ICT SYSTEM	10-252
LAYOUT DRAWING OF ICT SYSTEM.....	10-252
ICT CONTROL SYSTEM DIAGRAM.....	10-253
BLADE CONTROL SYSTEM	10-255
SMOOTH START SYSTEM	10-260
SLIP CONTROL SYSTEM	10-262
ASSIST CONTROL SYSTEM	10-264
DIRECTION CONTROL SYSTEM	10-266
SMOOTH CARIY SYSTEM.....	10-268
COMPONENT PARTS OF ICT SYSTEM	10-270
LIFTING SYSTEM	10-284
POWER LADDER SYSTEM	10-284
COMPONENT PARTS OF LIFTING SYSTEM	10-287
RADIO CONTROL SYSTEM.....	10-290
LAYOUT DRAWING OF RADIO CONTROL SYSTEM.....	10-290
SPECIFICATIONS OF RADIO CONTROL SYSTEM.....	10-291
COMPONENT PARTS OF RADIO CONTROL SYSTEM	10-292
UNDERCARRIAGE AND FRAME.....	10-297
MAIN FRAME	10-297
SUSPENSION	10-299
TRACK FRAME AND IDLER CUSHION	10-302
WORK EQUIPMENT.....	10-304
STRUCTURE OF FRONT WORK EQUIPMENT.....	10-304
STRUCTURE OF CYLINDER STAY	10-306
STRUCTURE OF VARIABLE GIANT RIPPER.....	10-307
STRUCTURE OF VARIABLE MULTI-SHANK RIPPER	10-308
CAB AND ITS ATTACHMENTS	10-309
ROPS.....	10-309
CAB	10-310
CAB MOUNT	10-311
20 STANDARD VALUE TABLE	20-1
CONTENTS	20-2
ABBREVIATION LIST	20-3
STANDARD VALUE TABLE FOR ENGINE	20-9
STANDARD VALUE TABLE FOR ENGINE: D375AI-8	20-9
STANDARD VALUE TABLE FOR MACHINE.....	20-15
STANDARD VALUE TABLE FOR MACHINE: D375AI-8.....	20-15
MACHINE POSTURE AND PROCEDURE FOR MEASURING PERFORMANCE	20-42
30 TESTING AND ADJUSTING	30-1
CONTENTS	30-2
ABBREVIATION LIST	30-6

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$