

Shop Manual

BULLDOZER

D51EXi -24E0
D51PXi -24E0

SERIAL NUMBERS D51EXi-20001 and up
 D51PXi-20001

00 Index and Foreword

Index

00 Index and Foreword	00-1
Foreword, Safety, Basic Information	00-21
How to Read the Shop Manual	00-21
Safety Notice for Operation	00-23
Precautions to Prevent Fire	00-31
Procedures If Fire Occurs	00-33
Precautions for Disposing of Waste Materials	00-34
Procedures for Exhaust Gas Regulations	00-35
Precautions for DEF	00-36
Store DEF	00-37
Precautions When You Handle Hydraulic Equipment	00-38
Precautions When You Disconnect and Connect Pipings	00-41
Precautions When You Handle Electrical Equipment	00-48
Precautions When You Handle Fuel System Equipment	00-50
Precautions When You Handle Intake System Equipment	00-51
Practical Use of KOMTRAX	00-52
Disconnect and Connect Push-Pull Type Coupler	00-53
Precautions for Disconnection and Connection of Connectors	00-57
How to Disconnect and Connect Deutsch Connector	00-61
How to Disconnect and Connect Slide Lock Type Connector	00-62
How to Disconnect and Connect Connector with Lock to Pull	00-64
How to Disconnect and Connect Connector with Lock to Push	00-65
How to Disconnect and Connect Connector with Housing to Rotate	00-67
How to Read the Codes for Electric Cable	00-68
Explanation of Terms for Maintenance Standard	00-72
Standard Tightening Torque Table	00-75
Conversion Table	00-82
Abbreviation List	00-87
01 Specifications	01-1
Table of Contents	01-2
Specifications	01-3
Specification Drawing	01-3
Specifications	01-7
Weight Table	01-18
Fuel, Coolant, Lubricant	01-22
10 Structure and Function	10-1
Table of Contents	10-2
Urea SCR System	10-6
Layout Drawing of Urea SCR System	10-6
Urea SCR System Diagram (Divided Type)	10-8
Function of Urea SCR System	10-9
Component Parts of Urea SCR System	10-18
Boot-up System	10-27
Layout Drawing of Boot-up System	10-27
System Operating Lamp System	10-28
Battery Disconnect Switch	10-30
Engine System	10-31
Layout Drawing of Engine System	10-31
Engine Control System	10-33
Automatic Idle Stop System	10-39
Component Parts of Engine System	10-42
Cooling System	10-52
Layout Drawing of Cooling System	10-52
Cooling Fan Control System	10-54
Component Parts of Cooling System	10-57
Control System	10-66

Layout Drawing of Control System	10-66
Machine Monitor System.....	10-67
KOMTRAX System	10-68
Component Parts of Control System	10-69
Hydraulic System	10-107
Layout Drawing of Hydraulic System.....	10-107
CLSS	10-108
Component Parts of Hydraulic System.....	10-111
Power Train System.....	10-143
Layout Drawing of HST System	10-143
Operation of HST System	10-144
Steering and Brake Control System	10-146
HST Control System	10-148
Parking Brake Control System	10-159
Component Parts of Power Train System.....	10-162
Work Equipment System.....	10-198
Work Equipment Control	10-198
Layout Drawing of Front Work Equipment.....	10-200
Layout Drawing of Fixed Multi-Shank Ripper	10-201
Component Parts of Work Equipment System	10-202
ICT System	10-218
Layout Drawing of ICT System.....	10-218
System Diagram of ICT Control System.....	10-220
Blade Control System	10-222
Assist Control System	10-227
Back Grade Mode System	10-229
Cut Control System.....	10-231
Smooth Start System	10-244
Slip Control System.....	10-246
Speed Control System	10-248
Straight Travel Correction System.....	10-250
Quick Surface Control System	10-254
System of Triangulated Surface from AS-BUILT.....	10-256
2 Surfaces Selection Control System	10-258
Lift Layer Control System	10-260
2D Laser Machine Control System.....	10-263
Component Parts of ICT System.....	10-265
Undercarriage and Frame	10-291
Main Frame.....	10-291
Suspension	10-292
Track Frame and Idler Cushion	10-295
Work Equipment	10-298
Structure of Front Work Equipment.....	10-298
Structure of Fixed Multi-Shank Ripper.....	10-299
CAB Related Parts.....	10-300
ROPS CAB	10-300
CAB Mount	10-302
20 Standard Value Table	20-1
Table of Contents	20-2
Standard Value Table for Engine	20-3
Standard Value Table for Engine: D51EXI-24E0	20-3
Standard Value Table for Engine: D51PXI-24E0	20-7
Standard Value Table for Machine.....	20-11
Standard Value Table for Machine: D51EXI-24E0	20-11
Standard Value Table for Machine: D51PXI-24E0	20-28
Machine Posture and Procedures to Measure Performance	20-43
30 Testing and Adjusting	30-1
Table of Contents	30-2

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$