

Shop Manual

BULLDOZER

D71EX -24
D71EX -24EO
D71PX-24
D71PX-24EO

SERIAL NUMBERS

D71EX-70002 and up
D71PX-70002

KOMATSU

00 Index and Foreword

Index

00 Index and Foreword	00-1
Foreword, Safety, Basic Information	00-21
How to Read the Shop Manual	00-21
Safety Notice for Operation	00-23
Precautions to Prevent Fire	00-31
Procedures If Fire Occurs	00-33
Precautions for Disposing of Waste Materials	00-34
Procedures for Exhaust Gas Regulations	00-35
Precautions for DEF	00-36
Store DEF	00-37
Precautions When You Handle Hydraulic Equipment	00-38
Precautions When You Disconnect and Connect Pipings	00-41
Precautions When You Handle Electrical Equipment	00-48
Precautions When You Handle Fuel System Equipment	00-50
Precautions When You Handle Intake System Equipment	00-51
Practical Use of KOMTRAX	00-52
Disconnect and Connect Push-Pull Type Coupler	00-53
Precautions for Disconnection and Connection of Connectors	00-57
How to Disconnect and Connect Deutsch Connector	00-61
How to Disconnect and Connect Slide Lock Type Connector	00-62
How to Disconnect and Connect Connector with Lock to Pull	00-64
How to Disconnect and Connect Connector with Lock to Push	00-65
How to Disconnect and Connect Connector with Housing to Rotate	00-67
How to Read the Codes for Electric Cable	00-68
Explanation of Terms for Maintenance Standard	00-72
Standard Tightening Torque Table	00-75
Conversion Table	00-82
Abbreviation List	00-87
01 Specifications	01-1
Table of Contents	01-2
Specifications	01-3
Specification Drawing	01-3
Specifications	01-9
Weight Table	01-24
Fuel, Coolant, Lubricants (For North America)	01-30
Fuel, Coolant, Lubricants (For European Union)	01-32
10 Structure and Function	10-1
Table of Contents	10-2
Urea SCR System	10-5
Layout Drawing of Urea SCR System	10-5
Urea SCR System Diagram	10-7
Function of Urea SCR System	10-8
Component Parts of Urea SCR System	10-26
Boot-up System	10-35
Layout Drawing of Boot-up System	10-35
System Operating Lamp System	10-36
Battery Disconnect Switch	10-39
Assistance Valve for Startup	10-41
Engine System	10-42
Layout Drawing of Engine System	10-42
Engine Control System	10-44
Engine Automatic Warm-up System	10-49
Automatic Idle Stop System	10-50
Component Parts of Engine System	10-53
Cooling System	10-72
Layout Drawing of Cooling System	10-72

Cooling Fan Control System	10-74
Component Parts of Cooling System	10-76
Control System	10-87
Layout Drawing of Control System	10-87
Machine Monitor System	10-88
KOMTRAX System	10-90
Component Parts of Control System	10-91
Hydraulic System	10-134
Layout Drawing of Hydraulic System	10-134
CLSS	10-135
Component Parts of Hydraulic System	10-139
Power Train System	10-176
Layout Drawing of HST System	10-176
Operation of HST System	10-177
Steering and Brake Control System	10-179
HST Control System	10-181
Parking Brake Control System	10-192
Component Parts of Power Train System	10-196
Work Equipment System	10-238
Work Equipment Control	10-238
Layout Drawing of Front Work Equipment	10-240
Layout Drawing of Fixed Multi-Shank Ripper	10-241
Component Parts of Work Equipment System	10-242
Undercarriage and Frame	10-263
Main Frame	10-263
Suspension	10-264
Track Frame and Idler Cushion	10-267
Work Equipment	10-270
Structure of Front Work Equipment	10-270
Structure of Fixed Multi-Shank Ripper	10-271
CAB Related Parts	10-272
ROPS CAB	10-272
CAB Mount	10-274
20 Standard Value Table	20-1
Table of Contents	20-2
Standard Value Table for Engine	20-3
Standard Value Table for Engine: D71EX-24	20-3
Standard Value Table for Engine: D71EX-24E0	20-7
Standard Value Table for Engine: D71PX-24	20-11
Standard Value Table for Engine: D71PX-24E0	20-15
Standard Value Table for Machine	20-19
Standard Value Table for Machine: D71EX-24	20-19
Standard Value Table for Machine: D71EX-24E0	20-33
Standard Value Table for Machine: D71PX-24	20-47
Standard Value Table for Machine: D71PX-24E0	20-61
Machine Posture and Procedures to Measure Performance	20-75
30 Testing and Adjusting	30-1
Table of Contents	30-2
Precautions Before Work	30-5
Related Information on Testing and Adjusting	30-6
Differences In Machine Monitor Symbols	30-6
Tools for Testing and Adjusting	30-7
Sketch of Tools for Testing and Adjusting	30-15
Engine and Cooling System	30-17
Examine Engine Speed	30-17
Examine Boost Pressure	30-20
Examine Exhaust Gas Temperature	30-22
Examine Exhaust Gas Color	30-25

It's a preview. You can download the full file by
clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$