

Shop Manual

HYDRAULIC
EXCAVATOR

PC238USLC-11

SERIAL NUMBERS 5001 and up

KOMATSU

00 Index and Foreword

Index

00 Index and Foreword	00-1
Abbreviation List	00-20
Foreword, Safety, Basic Information	00-23
How to Read the Shop Manual	00-23
Safety Notice for Operation	00-25
Precautions to Prevent Fire	00-33
Procedures If Fire Occurs	00-35
Precautions for Disposing of Waste Materials	00-36
Procedures for Exhaust Gas Regulations	00-37
Precautions for DEF	00-38
Precautions When You Handle Hydraulic Equipment	00-39
Precautions When You Disconnect and Connect Pipings	00-42
Precautions When You Handle Electrical Equipment	00-49
Precautions When You Handle Fuel System Equipment	00-51
Precautions When You Handle Intake System Equipment	00-52
Practical Use of KOMTRAX	00-53
Disconnect and Connect Push-Pull Type Coupler	00-54
Precautions for Disconnection and Connection of Connectors	00-58
How to Disconnect and Connect Deutsch Connector	00-62
How to Disconnect and Connect Slide Lock Type Connector	00-63
How to Disconnect and Connect Connector with Lock to Pull	00-65
How to Disconnect and Connect Connector with Lock to Push	00-66
How to Disconnect and Connect Connector with Housing to Rotate	00-68
How to Read the Codes for Electric Cable	00-69
Explanation of Terms for Maintenance Standard	00-73
Standard Tightening Torque Table	00-76
Conversion Table	00-83
01 Specifications	01-1
Table of Contents	01-2
Specifications	01-3
Specification Drawing	01-3
Working Range Drawings	01-5
Specifications	01-6
Weight Table	01-9
Fuel, Coolant, Lubricants (For North America)	01-11
10 Structure and Function	10-1
Table of Contents	10-2
Urea SCR System	10-6
Layout Drawing of Urea SCR System	10-6
Urea SCR System Diagram	10-11
Function of Urea SCR System	10-12
Component Parts of Urea SCR System	10-22
Boot-up System	10-31
Layout Drawing of Boot-up System (Machine with KOMTRAX Terminal)	10-31
Layout Drawing of Boot-up System (Machine with Gateway Function Controller)	10-33
System Operating Lamp System	10-35
Battery Disconnect Switch	10-38
Engine System	10-39
Layout Drawing of Engine System	10-39
Engine Control System	10-41
Auto-Deceleration System	10-47
Engine Automatic Warm-up System	10-49
Overheat Prevention System	10-51
Turbocharger Protection System	10-54
Automatic Idle Stop System	10-56
Component Parts of Engine System	10-60

Cooling System.....	10-79
Layout Drawing of Cooling System	10-79
Fan Speed Control System of Fan Clutch	10-81
Engine Output Control System of Fan Clutch.....	10-83
Component Parts of Cooling System	10-85
Control System	10-86
Layout Drawing of Control System (Machine with KOMTRAX Terminal)	10-86
Layout Drawing of Control System (Machine with Gateway Function Controller)	10-89
Machine Monitor System.....	10-92
KomVision System.....	10-94
KOMTRAX System	10-98
Component Parts of Control System	10-100
Hydraulic System	10-144
Layout Drawing of Hydraulic System.....	10-144
CLSS	10-148
Engine and Pump Combined Control System	10-171
Pump and Valve Control System.....	10-178
Component Parts of Hydraulic System.....	10-181
Work Equipment System.....	10-271
Layout Drawing of Work Equipment System	10-271
One-Touch Power Maximizing System	10-276
PPC Lock System	10-278
Work Equipment and Travel Automatic Lock System	10-279
Attachment Oil Flow Adjuster System	10-281
Tool Control System.....	10-283
Component Parts of Work Equipment System	10-285
Swing System	10-314
Layout Drawing of Swing System.....	10-314
Swing Control System Diagram	10-318
Component Parts of Swing System.....	10-322
Travel System	10-338
Layout Drawing of Travel System.....	10-338
System Diagram of Travel Control System.....	10-342
Component Parts of Travel System.....	10-344
Undercarriage and Frame	10-366
Layout Drawing of Undercarriage.....	10-366
Work Equipment	10-368
Structure of Work Equipment	10-368
Function of Work Equipment.....	10-369
Work Equipment Clearance Adjustment Shim.....	10-370
Bucket Clearance Adjustment Shim	10-371
CAB Related Parts.....	10-372
ROPS CAB	10-372
CAB Mount	10-374
CAB Tipping Stopper	10-375
Remove Wiring Harness Out of Cab	10-376
20 Standard Value Table	20-1
Table of Contents	20-2
Standard Value Table for Engine	20-3
Standard Value Table for Engine: PC238USLC-11	20-3
Standard Value Table for Machine.....	20-8
Standard Value Table for Machine: PC238USLC-11.....	20-8
Machine Posture and Procedures to Measure Performance	20-22
30 Testing and Adjusting	30-1
Table of Contents	30-2
Precautions Before Work	30-6
Related Information on Testing and Adjusting	30-7
Tools for Testing and Adjusting.....	30-7

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$