

# Shop Manual

BASE TRACTOR

***D155CX-8***

SERIAL NUMBERS 150001 and up

**KOMATSU**



---

# 00 Index and Foreword

---

# Index

00 Index and Foreword .....	00-1
Abbreviation List .....	00-20
Foreword, Safety, Basic Information .....	00-23
How to Read the Shop Manual .....	00-23
Safety Notice for Operation .....	00-25
Precautions to Prevent Fire .....	00-33
Procedures If Fire Occurs .....	00-35
Precautions for Disposing of Waste Materials .....	00-36
Procedures for Exhaust Gas Regulations .....	00-37
Precautions for DEF .....	00-38
Store DEF .....	00-39
Precautions When You Handle Hydraulic Equipment .....	00-40
Precautions When You Disconnect and Connect Pipings .....	00-43
Precautions When You Handle Electrical Equipment .....	00-50
Precautions When You Handle Fuel System Equipment .....	00-52
Precautions When You Handle Intake System Equipment .....	00-53
Practical Use of KOMTRAX .....	00-54
Disconnect and Connect Push-Pull Type Coupler .....	00-55
Precautions for Disconnection and Connection of Connectors .....	00-59
How to Disconnect and Connect Deutsch Connector .....	00-63
How to Disconnect and Connect Slide Lock Type Connector .....	00-64
How to Disconnect and Connect Connector with Lock to Pull .....	00-66
How to Disconnect and Connect Connector with Lock to Push .....	00-67
How to Disconnect and Connect Connector with Housing to Rotate .....	00-69
How to Read the Codes for Electric Cable .....	00-70
Explanation of Terms for Maintenance Standard .....	00-74
Standard Tightening Torque Table .....	00-77
Conversion Table .....	00-84
01 Specifications .....	01-1
Table of Contents .....	01-2
Specifications .....	01-3
Specification Drawing .....	01-3
Specifications .....	01-5
Weight Table .....	01-9
How to Use Fuel, Coolant and Lubricants by Ambient Temperature .....	01-11
10 Structure and Function .....	10-1
Table of Contents .....	10-2
Urea SCR System .....	10-5
Layout Drawing of Urea SCR System .....	10-5
Urea SCR System Diagram .....	10-7
Function of Urea SCR System .....	10-8
Component Parts of Urea SCR System .....	10-18
Boot-up System .....	10-27
Layout Drawing of Boot-up System .....	10-27
System Operating Lamp System .....	10-28
Battery Disconnect Switch .....	10-30
Engine System .....	10-32
Layout Drawing of Engine System .....	10-32
Engine Control System .....	10-34
Automatic Idle Stop System .....	10-37
Component Parts of Engine System .....	10-40
Cooling System .....	10-60
Layout Drawing of Cooling System .....	10-60
Component Parts of Cooling System .....	10-62
Control System .....	10-78
Layout Drawing of Control System .....	10-78

Machine Monitor System.....	10-79
KOMTRAX System .....	10-82
Component Parts of Control System .....	10-83
Hydraulic System .....	10-119
Layout Drawing of Hydraulic System.....	10-119
CLSS .....	10-120
Component Parts of Hydraulic System.....	10-123
Power Train System.....	10-178
Layout Drawing of Power Train System .....	10-178
Transmission, Steering, and Brake Control .....	10-181
Palm Command Control System .....	10-183
HSS System.....	10-185
Centralized Pressure Pickup Port.....	10-188
Component Parts of Power Train System.....	10-190
Work Equipment System.....	10-270
Work Equipment Control .....	10-270
Component Parts of Work Equipment System .....	10-272
Undercarriage and Frame .....	10-283
Main Frame.....	10-283
Suspension .....	10-284
Track Frame and Idler Cushion .....	10-287
CAB Related Parts.....	10-289
ROPS CAB .....	10-289
CAB Mount .....	10-290
20 Standard Value Table .....	20-1
Table of Contents .....	20-2
Standard Value Table for Engine .....	20-3
Standard Value Table for Engine: D155CX-8.....	20-3
Standard Value Table for Machine.....	20-7
Standard Value Table for Machine: D155CX-8 .....	20-7
30 Testing and Adjusting .....	30-1
Table of Contents .....	30-2
Precautions Before Work .....	30-5
Related Information on Testing and Adjusting .....	30-6
Tools for Testing and Adjusting.....	30-6
Sketch of Tools for Testing and Adjusting .....	30-14
Engine and Cooling System .....	30-17
Examine Engine Speed.....	30-17
Examine Boost Pressure.....	30-23
Examine Exhaust Gas Temperature .....	30-25
Examine Exhaust Gas Color .....	30-30
Examine Mass Air Flow and Temperature Sensor .....	30-33
Examine and Adjust Valve Clearance.....	30-35
Examine Compression Pressure .....	30-38
Examine Blowby Pressure .....	30-41
Examine Engine Oil Pressure .....	30-43
Examine EGR Valve and VGT Oil Pressure .....	30-45
Examine Fuel Pressure.....	30-47
Examine Fuel Return Rate and Leakage.....	30-49
Bleed Air from Fuel System.....	30-55
Examine Fuel Circuit for Leakage .....	30-57
Handle Cylinder Cut-out Mode Operation.....	30-59
Handle No-Injection Cranking Operation .....	30-60
Clean Fuel Doser .....	30-61
Write Injector Compensation Value to Engine Controller .....	30-63
Write Correction for Ash in Soot Accumulation to Engine Controller.....	30-69
Examine SCR Related Functions .....	30-70
Clean DEF Tank.....	30-98

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$