

Shop Manual

BULLDOZER

D51EX -24
D51PX -24

SERIAL NUMBERS D51EX-10001 and up
 D51PX-10001

KOMATSU

00 Index and Foreword

Index

00 Index and Foreword	00-1
Abbreviation List	00-18
Foreword, Safety, Basic Information	00-24
How to Read the Shop Manual	00-24
Safety Notice for Operation	00-26
Precautions to Prevent Fire	00-34
Procedures If Fire Occurs	00-36
Precautions When You Discard Waste Materials	00-37
Procedures for Exhaust Gas Regulations	00-38
Precautions for DEF	00-39
Store DEF	00-40
Precautions When You Handle Hydraulic Equipment	00-41
Precautions When You Disconnect and Connect Pipings	00-44
Precautions When You Handle Electrical Equipment	00-51
Precautions When You Handle Fuel System Equipment	00-53
Precautions When You Handle Intake System Equipment	00-54
Practical Use of KOMTRAX	00-55
Disconnect and Connect Push-Pull Type Coupler	00-56
Precautions for Disconnection and Connection of Connectors	00-60
Disconnect and Connect Deutsch Connector	00-64
How to Disconnect and Connect Slide Lock Type Connector	00-65
Disconnect and Connect Connector with Lock to Pull	00-67
Disconnect and Connect Connector with Lock to Push	00-68
Disconnect and Connect Connector with Housing to Rotate	00-70
How to Read the Codes for Electric Cable	00-71
Explanation of Terms for Maintenance Standard	00-75
Standard Tightening Torque Table	00-78
Conversion Table	00-85
01 Specification	01-1
Table of Contents	01-2
Abbreviation List	01-3
Specifications	01-9
Specification Drawing	01-9
Specifications	01-13
Weight Table	01-23
Fuel, Coolant, Lubricants (For North America)	01-27
Fuel, Coolant, Lubricants (For European Union)	01-29
10 Structure and Function	10-1
Table of Contents	10-2
Abbreviation List	10-5
Urea SCR System	10-11
Layout Drawing of Urea SCR System	10-11
Urea SCR System Diagram	10-13
Function of Urea SCR System	10-14
Component Parts of Urea SCR System	10-31
Boot-up System	10-40
Layout Drawing of Boot-up System (Machine with KOMTRAX Terminal)	10-40
Layout Drawing of Boot-up System (Machine with Gateway Function Controller)	10-41
System Operating Lamp System	10-42
Battery Disconnect Switch	10-45
Engine System	10-46
Layout Drawing of Engine System	10-46
Engine Control System	10-48
Automatic Idle Stop System	10-60
Component Parts of Engine System	10-64
Cooling System	10-81

Layout Drawing of Cooling System	10-81
Cooling Fan Control System	10-83
Component Parts of Cooling System	10-86
Control System	10-95
Layout Drawing of Control System (Machine with KOMTRAX Terminal)	10-95
Layout Drawing of Control System (Machine with Gateway Function Controller)	10-96
Machine Monitor System.....	10-97
KOMTRAX System	10-99
Component Parts of Control System	10-101
Hydraulic System	10-138
Layout Drawing of Hydraulic System.....	10-138
CLSS	10-139
Component Parts of Hydraulic System.....	10-142
Power Train System.....	10-174
Layout Drawing of HST System	10-174
Operation of HST System	10-175
Steering and Brake Control System	10-177
HST Control System	10-179
Parking Brake Control System	10-190
Component Parts of Power Train System.....	10-193
Work Equipment System.....	10-229
Work Equipment Control	10-229
Layout Drawing of Front Work Equipment.....	10-231
Layout Drawing of Fixed Multi-Shank Ripper	10-232
Component Parts of Work Equipment System	10-233
Undercarriage and Frame	10-249
Main Frame.....	10-249
Suspension	10-250
Track Frame and Idler Cushion	10-253
Work Equipment	10-255
Structure of Front Work Equipment.....	10-255
Structure of Fixed Multi-Shank Ripper.....	10-256
CAB Related Parts.....	10-257
ROPS CAB	10-257
CAB Mount	10-260
20 Standard Value Table	20-1
Table of Contents	20-2
Abbreviation List	20-3
Standard Value Table for Engine	20-9
Standard Value Table for Engine: D51EX-24.....	20-9
Standard Value Table for Engine: D51PX-24.....	20-13
Standard Value Table for Machine.....	20-17
Standard Value Table for Machine: D51EX-24	20-17
Standard Value Table for Machine: D51PX-24	20-33
Machine Posture and Procedures to Measure Performance	20-47
30 Testing and Adjusting	30-1
Table of Contents	30-2
Precautions Before Work	30-5
Abbreviation List	30-6
Related Information on Testing and Adjusting	30-12
Tools for Testing and Adjusting.....	30-12
Sketch of Tools for Testing and Adjusting	30-19
Engine and Cooling System	30-22
Examine Engine Speed.....	30-22
Examine Boost Pressure.....	30-24
Examine Exhaust Gas Color	30-25
Examine and Adjust Valve Clearance.....	30-27
Examine Compression Pressure.....	30-29

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$