

Shop Manual

BULLDOZER

D51EX -24
D51PX -24

SERIAL NUMBERS D51EX-15001 and up
 D51PX-15001

00 Index and Foreword

Index

00 Index and Foreword	00-1
Foreword, Safety, Basic Information	00-18
How to Read the Shop Manual	00-18
Safety Notice for Operation	00-20
Precautions to Prevent Fire	00-28
Procedures If Fire Occurs	00-30
Precautions for Disposing of Waste Materials	00-31
Procedures for Exhaust Gas Regulations	00-32
Precautions for DEF	00-33
Store DEF	00-34
Precautions When You Handle Hydraulic Equipment	00-35
Precautions When You Disconnect and Connect Pipings	00-38
Precautions When You Handle Electrical Equipment	00-45
Precautions When You Handle Fuel System Equipment	00-47
Precautions When You Handle Intake System Equipment	00-48
Practical Use of KOMTRAX	00-49
Disconnect and Connect Push-Pull Type Coupler	00-50
Precautions for Disconnection and Connection of Connectors	00-54
How to Disconnect and Connect Deutsch Connector	00-58
How to Disconnect and Connect Slide Lock Type Connector	00-59
How to Disconnect and Connect Connector with Lock to Pull	00-61
How to Disconnect and Connect Connector with Lock to Push	00-62
How to Disconnect and Connect Connector with Housing to Rotate	00-64
How to Read the Codes for Electric Cable	00-65
Explanation of Terms for Maintenance Standard	00-69
Standard Tightening Torque Table	00-72
Conversion Table	00-79
Abbreviation List	00-84
01 Specifications	01-1
Table of Contents	01-2
Specifications	01-3
Specification Drawing	01-3
Specifications	01-7
Weight Table	01-17
Fuel, Coolant, Lubricant	01-21
10 Structure and Function	10-1
Table of Contents	10-2
Urea SCR System	10-5
Layout Drawing of Urea SCR System	10-5
Urea SCR System Diagram	10-7
Function of Urea SCR System	10-8
Component Parts of Urea SCR System	10-25
Boot-up System	10-34
Layout Drawing of Boot-up System	10-34
System Operating Lamp System	10-35
Battery Disconnect Switch	10-37
Engine System	10-38
Layout Drawing of Engine System	10-38
Engine Control System	10-40
Automatic Idle Stop System	10-46
Component Parts of Engine System	10-49
Cooling System	10-67
Layout Drawing of Cooling System	10-67
Cooling Fan Control System	10-69
Component Parts of Cooling System	10-72
Control System	10-81

Layout Drawing of Control System	10-81
Machine Monitor System.....	10-82
KOMTRAX System	10-83
Component Parts of Control System	10-84
Hydraulic System	10-121
Layout Drawing of Hydraulic System.....	10-121
CLSS	10-122
Component Parts of Hydraulic System.....	10-125
Power Train System.....	10-157
Layout Drawing of HST System	10-157
Operation of HST System	10-158
Steering and Brake Control System	10-160
HST Control System	10-162
Parking Brake Control System	10-173
Component Parts of Power Train System.....	10-176
Work Equipment System.....	10-212
Work Equipment Control	10-212
Layout Drawing of Front Work Equipment.....	10-214
Layout Drawing of Fixed Multi-Shank Ripper	10-215
Component Parts of Work Equipment System	10-216
Undercarriage and Frame	10-232
Main Frame.....	10-232
Suspension	10-233
Track Frame and Idler Cushion	10-236
Work Equipment	10-238
Structure of Front Work Equipment (Serial No.: 15001 to 15600).....	10-238
Structure of Front Work Equipment (Serial No.: 15601 and up).....	10-239
Structure of Fixed Multi-Shank Ripper.....	10-240
CAB Related Parts.....	10-241
ROPS CAB	10-241
CAB Mount	10-243
20 Standard Value Table	20-1
Table of Contents	20-2
Standard Value Table for Engine	20-3
Standard Value Table for Engine: D51EX-24.....	20-3
Standard Value Table for Engine: D51PX-24.....	20-7
Standard Value Table for Machine.....	20-11
Standard Value Table for Machine: D51EX-24	20-11
Standard Value Table for Machine: D51PX-24	20-27
Machine Posture and Procedures to Measure Performance	20-41
30 Testing and Adjusting	30-1
Table of Contents	30-2
Precautions Before Work	30-5
Related Information on Testing and Adjusting	30-6
Differences In Machine Monitor Symbols	30-6
Tools for Testing and Adjusting.....	30-7
Sketch of Tools for Testing and Adjusting	30-14
Engine and Cooling System	30-17
Examine Engine Speed.....	30-17
Examine Boost Pressure.....	30-19
Examine Exhaust Gas Color	30-20
Examine and Adjust Valve Clearance.....	30-22
Examine Compression Pressure	30-24
Examine Blowby Pressure	30-29
Examine Engine Oil Pressure	30-31
Visual Check Inside of EGR Valve	30-32
Clean Inside of EGR Valve.....	30-34
Examine Fuel Pressure	30-37

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$