

Shop Manual

BULLDOZER

D65EXi -18
D65PXi -18

SERIAL NUMBERS D65EXi-90997 and up
 D65PXi-90997

00 Index and Foreword

Index

00 Index and Foreword	00-1
Abbreviation List	00-22
Foreword, Safety, Basic Information	00-28
How to Read the Shop Manual	00-28
Safety Notice for Operation	00-30
Precautions to Prevent Fire	00-38
Procedures If Fire Occurs	00-40
Precautions When You Discard Waste Materials	00-41
Procedures for Exhaust Gas Regulations	00-42
Precautions for DEF	00-43
Store DEF	00-44
Precautions When You Handle Hydraulic Equipment	00-45
Precautions When You Disconnect and Connect Pipings	00-48
Precautions When You Handle Electrical Equipment	00-55
Precautions When You Handle Fuel System Equipment	00-57
Precautions When You Handle Intake System Equipment	00-58
Practical Use of KOMTRAX	00-59
Disconnect and Connect Push-Pull Type Coupler	00-60
Precautions for Disconnection and Connection of Connectors	00-64
Disconnect and Connect Deutsch Connector	00-68
How to Disconnect and Connect Slide Lock Type Connector	00-69
Disconnect and Connect Connector with Lock to Pull	00-71
Disconnect and Connect Connector with Lock to Push	00-72
Disconnect and Connect Connector with Housing to Rotate	00-74
How to Read the Codes for Electric Cable	00-75
Explanation of Terms for Maintenance Standard	00-79
Standard Tightening Torque Table	00-82
Conversion Table	00-89
01 Specification	01-1
Table of Contents	01-2
Abbreviation List	01-3
Specifications	01-9
Specification Drawing	01-9
Specifications	01-13
Weight Table	01-25
Table of Fuel, Coolant, and Lubricants	01-31
10 Structure and Function	10-1
Table of Contents	10-2
Abbreviation List	10-6
Urea SCR System	10-12
Layout Drawing of Urea SCR System	10-12
Urea SCR System Diagram	10-14
Function of Urea SCR System	10-15
Component Parts of Urea SCR System	10-31
Boot-up System	10-40
Layout Drawing of Boot-up System (Machine with KOMTRAX Terminal)	10-40
System Operating Lamp System	10-42
Battery Disconnect Switch	10-44
Engine System	10-46
Layout Drawing of Engine System	10-46
Engine Control System	10-48
Automatic Idle Stop System	10-53
Component Parts of Engine System	10-56
Cooling System	10-76
Layout Drawing of Cooling System	10-76
Cooling Fan Control System	10-78

Component Parts of Cooling System	10-81
Control System	10-98
Layout Drawing of Control System (Machine with KOMTRAX Terminal)	10-98
Machine Monitor System.....	10-99
KOMTRAX System	10-101
Component Parts of Control System	10-102
Hydraulic System	10-131
Layout Drawing of Hydraulic System.....	10-131
CLSS	10-132
Component Parts of Hydraulic System.....	10-135
Power Train System.....	10-187
Layout Drawing of Power Train System	10-187
Operation of Power Train System	10-189
Transmission, Steering, and Brake Control	10-190
Palm Command Control System	10-192
HSS System.....	10-196
Centralized Pressure Pickup Port.....	10-199
Component Parts of Power Train System.....	10-200
Work Equipment System.....	10-270
Work Equipment Control	10-270
Layout of Tilt Dozer and Power Tilt Pitch Dozer Series	10-273
Layout of Power Angle Power Tilt Dozer Series	10-274
Layout Drawing of Fixed Multi-Shank Ripper	10-275
Component Parts of Work Equipment System	10-276
ICT System	10-305
Layout Drawing of ICT System.....	10-305
System Diagram of ICT Control System.....	10-308
Blade Control System	10-310
Smooth Start System	10-316
Slip Control System.....	10-318
Assist Control System.....	10-320
Component Parts of ICT System.....	10-322
Undercarriage and Frame	10-353
Main Frame.....	10-353
Suspension	10-355
Track Frame and Idler Cushion	10-358
Work Equipment	10-361
Structure of Front Work Equipment (For Tilt Dozer and Power Tilt Pitch Dozer Series).....	10-361
Structure of Front Work Equipment (For Power Angle Power Tilt Dozer Series).....	10-362
Structure of Fixed Multi-Shank Ripper.....	10-363
CAB Related Parts.....	10-364
ROPS CAB	10-364
CAB Mount	10-366
20 Standard Value Table	20-1
Table of Contents	20-2
Abbreviation List	20-3
Standard Value Table for Engine	20-9
Standard Value Table for Engine: D65EXI-18.....	20-9
Standard Value Table for Engine: D65PXI-18.....	20-14
Standard Value Table for Machine.....	20-19
Standard Value Table for Machine: D65EXI-18	20-19
Standard Value Table for Machine: D65PXI-18	20-35
Machine Posture and Procedures to Measure Performance	20-52
Standard Value Table for Electricity.....	20-54
Standard Value Table for Electricity.....	20-54
30 Testing and Adjusting	30-1
Table of Contents	30-2
Precautions Before Work	30-6

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$