

Shop Manual

BULLDOZER

D65EXi -18
D65PXi -18

SERIAL NUMBERS D65EXi-96001 and up
 D65PXi-96001

00 Index and Foreword

Index

00 Index and Foreword	00-1
Foreword, Safety, Basic Information	00-23
How to Read the Shop Manual	00-23
Safety Notice for Operation	00-25
Precautions to Prevent Fire	00-33
Procedures If Fire Occurs	00-35
Precautions for Disposing of Waste Materials	00-36
Procedures for Exhaust Gas Regulations	00-37
Precautions for DEF	00-38
Store DEF	00-39
Precautions When You Handle Hydraulic Equipment	00-40
Precautions When You Disconnect and Connect Pipings	00-43
Precautions When You Handle Electrical Equipment	00-50
Precautions When You Handle Fuel System Equipment	00-52
Precautions When You Handle Intake System Equipment	00-53
Practical Use of KOMTRAX	00-54
Disconnect and Connect Push-Pull Type Coupler	00-55
Precautions for Disconnection and Connection of Connectors	00-59
How to Disconnect and Connect Deutsch Connector	00-63
How to Disconnect and Connect Slide Lock Type Connector	00-64
How to Disconnect and Connect Connector with Lock to Pull	00-66
How to Disconnect and Connect Connector with Lock to Push	00-67
How to Disconnect and Connect Connector with Housing to Rotate	00-69
How to Read the Codes for Electric Cable	00-70
Explanation of Terms for Maintenance Standard	00-74
Standard Tightening Torque Table	00-77
Conversion Table	00-84
Abbreviation List	00-89
01 Specifications	01-1
Table of Contents	01-2
Specifications	01-3
Specification Drawing	01-3
Specifications	01-7
Weight Table	01-18
Fuel, Coolant, Lubricant	01-23
10 Structure and Function	10-1
Table of Contents	10-2
Urea SCR System	10-6
Layout Drawing of Urea SCR System	10-6
Urea SCR System Diagram	10-8
Function of Urea SCR System	10-9
Component Parts of Urea SCR System	10-28
Boot-up System	10-38
Layout Drawing of Boot-up System	10-38
System Operating Lamp System	10-40
Battery Disconnect Switch	10-42
Engine System	10-44
Layout Drawing of Engine System	10-44
Engine Control System	10-46
Automatic Idle Stop System	10-52
Component Parts of Engine System	10-55
Cooling System	10-75
Layout Drawing of Cooling System	10-75
Cooling Fan Control System	10-77
Component Parts of Cooling System	10-80
Control System	10-97

Layout Drawing of Control System	10-97
Machine Monitor System.....	10-98
KOMTRAX System	10-100
Component Parts of Control System	10-101
Hydraulic System	10-134
Layout Drawing of Hydraulic System.....	10-134
CLSS	10-135
Component Parts of Hydraulic System.....	10-138
Power Train System.....	10-190
Layout Drawing of Power Train System	10-190
Operation of Power Train System	10-193
Transmission, Steering, and Brake Control	10-194
Palm Command Control System	10-196
HSS System.....	10-200
Centralized Pressure Pickup Port.....	10-203
Component Parts of Power Train System.....	10-204
Work Equipment System.....	10-275
Work Equipment Control	10-275
Layout of Tilt Dozer and Power Tilt Pitch Dozer Series	10-278
Layout Drawing of Fixed Multi-Shank Ripper	10-279
Component Parts of Work Equipment System	10-280
ICT System	10-303
Layout Drawing of ICT System.....	10-303
System Diagram of ICT Control System.....	10-305
Blade Control System	10-307
Cut Control System.....	10-312
Smooth Start System	10-325
Slip Control System.....	10-327
Assist Control System	10-329
Back Grade Mode System	10-331
Straight Travel Correction System.....	10-333
Quick Surface Control System	10-337
System of Triangulated Surface from AS-BUILT.....	10-339
2 Surfaces Selection Control System	10-341
Lift Layer Control System	10-343
Component Parts of ICT System.....	10-345
Undercarriage and Frame	10-373
Main Frame.....	10-373
Suspension	10-375
Track Frame and Idler Cushion	10-378
Work Equipment	10-381
Structure of Front Work Equipment (For Tilt Dozer and Power Tilt Pitch Dozer Series).....	10-381
Structure of Fixed Multi-Shank Ripper.....	10-382
CAB Related Parts.....	10-383
ROPS CAB	10-383
CAB Mount	10-385
20 Standard Value Table	20-1
Table of Contents	20-2
Standard Value Table for Engine	20-3
Standard Value Table for Engine: D65EXI-18.....	20-3
Standard Value Table for Engine: D65PXI-18.....	20-8
Standard Value Table for Machine.....	20-13
Standard Value Table for Machine: D65EXI-18	20-13
Standard Value Table for Machine: D65PXI-18	20-29
Machine Posture and Procedures to Measure Performance	20-44
30 Testing and Adjusting	30-1
Table of Contents	30-2
Precautions Before Work	30-6

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$