

Shop Manual

BULLDOZER

D85EX*i* -18
D85PX*i*-18

SERIAL NUMBERS 22083 and up

KOMATSU

00 Index and Foreword

Index

00 Index and Foreword	00-1
Abbreviation List	00-21
Foreword, Safety, Basic Information.....	00-24
How to Read the Shop Manual	00-24
Safety Notice for Operation	00-26
Precautions to Prevent Fire.....	00-34
Procedures If Fire Occurs	00-36
Precautions for Disposing of Waste Materials	00-37
Procedures for Exhaust Gas Regulations.....	00-38
Precautions for DEF.....	00-39
Store DEF	00-40
Precautions When You Handle Hydraulic Equipment.....	00-41
Precautions When You Disconnect and Connect Pipings.....	00-44
Precautions When You Handle Electrical Equipment	00-51
Precautions When You Handle Fuel System Equipment	00-53
Precautions When You Handle Intake System Equipment	00-54
Practical Use of KOMTRAX	00-55
Disconnect and Connect Push-Pull Type Coupler	00-56
Precautions for Disconnection and Connection of Connectors	00-60
How to Disconnect and Connect Deutsch Connector	00-64
How to Disconnect and Connect Slide Lock Type Connector	00-65
How to Disconnect and Connect Connector with Lock to Pull	00-67
How to Disconnect and Connect Connector with Lock to Push	00-68
How to Disconnect and Connect Connector with Housing to Rotate	00-70
How to Read the Codes for Electric Cable	00-71
Explanation of Terms for Maintenance Standard	00-75
Standard Tightening Torque Table.....	00-78
Conversion Table	00-85
01 Specifications	01-1
Table of Contents	01-2
Specifications	01-3
Specification Drawing.....	01-3
Specifications.....	01-6
Weight Table	01-17
Table of Fuel, Coolant, and Lubricants	01-21
10 Structure and Function	10-1
Table of Contents	10-2
Urea SCR System.....	10-5
Layout Drawing of Urea SCR System	10-5
Urea SCR System Diagram	10-8
Function of Urea SCR System	10-9
Component Parts of Urea SCR System	10-25
Boot-up System	10-34
Layout Drawing of Boot-up System	10-34
System Operating Lamp System.....	10-35
Battery Disconnect Switch.....	10-37
Engine System.....	10-39
Layout Drawing of Engine System	10-39
Engine Control System	10-41
Automatic Idle Stop System	10-46
Component Parts of Engine System	10-49
Cooling System.....	10-68
Layout Drawing of Cooling System	10-68
Cooling Fan Control System	10-70
Component Parts of Cooling System	10-73
Control System	10-90

Layout Drawing of Control System	10-90
Machine Monitor System.....	10-91
KOMTRAX System	10-93
Component Parts of Control System	10-94
Hydraulic System	10-125
Layout Drawing of Hydraulic System.....	10-125
CLSS	10-126
Component Parts of Hydraulic System.....	10-129
Power Train System	10-187
Layout Drawing of Power Train System	10-187
Operation of Power Train System	10-189
Transmission, Steering, and Brake Control	10-190
Palm Command Control System	10-193
HSS System.....	10-197
Centralized Pressure Pickup Port.....	10-200
Component Parts of Power Train System.....	10-202
Work Equipment System	10-267
Work Equipment Control	10-267
Layout Drawing of Front Work Equipment.....	10-270
Layout Drawing of Fixed Multi-Shank Ripper	10-271
Component Parts of Work Equipment System	10-272
ICT System	10-294
Layout Drawing of ICT System.....	10-294
System Diagram of ICT Control System.....	10-296
Blade Control System	10-298
Smooth Start System	10-304
Slip Control System.....	10-306
Assist Control System	10-308
Component Parts of ICT System.....	10-310
Undercarriage and Frame	10-333
Main Frame.....	10-333
Suspension	10-334
Track Frame and Idler Cushion	10-338
Work Equipment	10-340
Structure of Front Work Equipment	10-340
Structure of Cylinder Stay	10-342
Structure of Fixed Multi-Shank Ripper.....	10-343
CAB Related Parts	10-344
ROPS CAB	10-344
CAB Mount	10-346
20 Standard Value Table	20-1
Table of Contents	20-2
Standard Value Table for Engine	20-3
Standard Value Table for Engine: D85EXI-18.....	20-3
Standard Value Table for Engine: D85PXI-18.....	20-7
Standard Value Table for Machine.....	20-11
Standard Value Table for Machine: D85EXI-18	20-11
Standard Value Table for Machine: D85PXI-18	20-29
Machine Posture and Procedures to Measure Performance	20-45
Standard Value Table for Electricity	20-48
Standard Value Table for Electricity	20-48
30 Testing and Adjusting	30-1
Table of Contents	30-2
Precautions Before Work	30-6
Related Information on Testing and Adjusting	30-7
Tools for Testing and Adjusting.....	30-7
Sketch of Tools for Testing and Adjusting	30-15
Engine and Cooling System	30-18

It's a preview. You can download the full file by
clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$