

# Shop Manual

BULLDOZER

***D85EXi -18E0***

***D85PXi -18E0***

SERIAL NUMBERS 25001 and up

**KOMATSU**



---

# 00 Index and Foreword

---

# Index

00 Index and Foreword .....	00-1
Abbreviation List .....	00-22
Foreword, Safety, Basic Information .....	00-25
How to Read the Shop Manual .....	00-25
Safety Notice for Operation .....	00-27
Precautions to Prevent Fire .....	00-35
Procedures If Fire Occurs .....	00-37
Precautions When You Discard Waste Materials .....	00-38
Procedures for Exhaust Gas Regulations .....	00-39
Precautions for DEF .....	00-40
Store DEF .....	00-41
Precautions When You Handle Hydraulic Equipment .....	00-42
Precautions When You Disconnect and Connect Pipings .....	00-45
Precautions When You Handle Electrical Equipment .....	00-51
Precautions When You Handle Fuel System Equipment .....	00-53
Precautions When You Handle Intake System Equipment .....	00-54
Practical Use of KOMTRAX .....	00-55
Disconnect and Connect Push-Pull Type Coupler .....	00-56
Precautions for Disconnection and Connection of Connectors .....	00-60
How to Disconnect and Connect Deutsch Connector .....	00-64
How to Disconnect and Connect Slide Lock Type Connector .....	00-65
How to Disconnect and Connect Connector with Lock to Pull .....	00-67
How to Disconnect and Connect Connector with Lock to Push .....	00-68
How to Disconnect and Connect Connector with Housing to Rotate .....	00-70
How to Read the Codes for Electric Cable .....	00-71
Explanation of Terms for Maintenance Standard .....	00-75
Standard Tightening Torque Table .....	00-78
Conversion Table .....	00-85
01 Specifications .....	01-1
Table of Contents .....	01-2
Specifications .....	01-3
Specification Drawing .....	01-3
Specifications .....	01-6
Weight Table .....	01-16
Fuel, Coolant, Lubricant .....	01-20
10 Structure and Function .....	10-1
Table of Contents .....	10-2
Urea SCR System .....	10-6
Layout Drawing of Urea SCR System .....	10-6
Urea SCR System Diagram .....	10-9
Function of Urea SCR System .....	10-10
Component Parts of Urea SCR System .....	10-27
Boot-up System .....	10-36
Layout Drawing of Boot-up System .....	10-36
System Operating Lamp System .....	10-37
Battery Disconnect Switch .....	10-38
Engine System .....	10-40
Layout Drawing of Engine System .....	10-40
Engine Control System .....	10-42
Automatic Idle Stop System .....	10-47
Component Parts of Engine System .....	10-50
Cooling System .....	10-69
Layout Drawing of Cooling System .....	10-69
Cooling Fan Control System .....	10-71
Component Parts of Cooling System .....	10-74
Control System .....	10-91

Layout Drawing of Control System .....	10-91
Machine Monitor System.....	10-92
KOMTRAX System .....	10-94
Component Parts of Control System .....	10-95
Hydraulic System .....	10-128
Layout Drawing of Hydraulic System.....	10-128
CLSS .....	10-129
Component Parts of Hydraulic System.....	10-132
Power Train System .....	10-186
Layout Drawing of Power Train System .....	10-186
Operation of Power Train System .....	10-188
Transmission, Steering, and Brake Control .....	10-189
Palm Command Control System .....	10-192
HSS System.....	10-196
Centralized Pressure Pickup Port.....	10-199
Component Parts of Power Train System.....	10-201
Work Equipment System .....	10-262
Work Equipment Control .....	10-262
Layout Drawing of Front Work Equipment.....	10-265
Layout Drawing of Fixed Multi-Shank Ripper .....	10-266
Component Parts of Work Equipment System .....	10-267
ICT System .....	10-289
Layout Drawing of ICT System.....	10-289
System Diagram of ICT Control System.....	10-291
Blade Control System .....	10-293
Smooth Start System .....	10-310
Slip Control System.....	10-312
Assist Control System .....	10-314
Back Grade Mode System .....	10-316
Straight Travel Correction System.....	10-318
Quick Surface Control System .....	10-322
System of Triangulated Surface from AS-BUILT.....	10-324
2 Surfaces Selection Control System .....	10-326
Lift Layer Control System .....	10-328
Component Parts of ICT System.....	10-330
Undercarriage and Frame .....	10-351
Main Frame.....	10-351
Suspension .....	10-352
Track Frame and Idler Cushion .....	10-356
Work Equipment .....	10-358
Structure of Front Work Equipment .....	10-358
Structure of Cylinder Stay .....	10-360
Structure of Fixed Multi-Shank Ripper.....	10-361
CAB Related Parts.....	10-362
ROPS CAB .....	10-362
CAB Mount .....	10-364
20 Standard Value Table .....	20-1
Table of Contents .....	20-2
Standard Value Table for Engine .....	20-3
Standard Value Table for Engine: D85EXI-18E0 .....	20-3
Standard Value Table for Engine: D85PXI-18E0 .....	20-7
Standard Value Table for Machine.....	20-11
Standard Value Table for Machine: D85EXI-18E0 .....	20-11
Standard Value Table for Machine: D85PXI-18E0 .....	20-29
Machine Posture and Procedures to Measure Performance .....	20-45
30 Testing and Adjusting .....	30-1
Table of Contents .....	30-2
Precautions Before Work .....	30-6

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$