

Shop Manual

HYDRAULIC
EXCAVATOR

HB365LC-3

SERIAL NUMBERS 5001 and up

Hybrid

KOMATSU

00 Index and Foreword

Index

00 Index and Foreword	00-1
Abbreviation List	00-22
Foreword, Safety, Basic Information.....	00-25
How to Read the Shop Manual	00-25
Safety Notice for Operation	00-27
Precautions Particularly for Hybrid Machines	00-35
Precautions to Prevent Fire.....	00-36
Procedures If Fire Occurs	00-38
Precautions for Disposing of Waste Materials	00-39
Procedures for Exhaust Gas Regulations.....	00-40
Precautions for DEF.....	00-41
Store DEF	00-42
Precautions When You Handle Hydraulic Equipment	00-43
Precautions When You Disconnect and Connect Pipings.....	00-46
Precautions When You Handle Electrical Equipment	00-53
Precautions for Maintenance of Hybrid System.....	00-55
Precautions Against High Voltage and High Temperature	00-56
Precautions for Normal Check and Maintenance	00-57
Precautions for the Machine Not to be Tipped over and for Hybrid Components Not to be Damaged	00-58
Precautions for Machine Not to be Put in Water.....	00-59
In Cold Weather	00-60
Precautions When You Handle Fuel System Equipment.....	00-61
Precautions When You Handle Intake System Equipment	00-62
Practical Use of KOMTRAX	00-63
Disconnect and Connect Push-Pull Type Coupler	00-64
Precautions for Disconnection and Connection of Connectors	00-68
How to Disconnect and Connect Deutsch Connector	00-72
How to Disconnect and Connect Slide Lock Type Connector	00-73
How to Disconnect and Connect Connector with Lock to Pull	00-75
How to Disconnect and Connect Connector with Lock to Push	00-76
How to Disconnect and Connect Connector with Housing to Rotate	00-78
How to Read the Codes for Electric Cable	00-79
Explanation of Terms for Maintenance Standard	00-85
Standard Tightening Torque Table.....	00-88
Conversion Table	00-95
01 Specifications	01-1
Table of Contents	01-2
Specifications	01-3
Specification Drawing.....	01-3
Working Range Drawings.....	01-5
Specifications.....	01-6
Weight Table	01-10
Table of Fuel, Coolant, and Lubricants	01-12
10 Structure and Function	10-1
Table of Contents	10-2
Urea SCR System.....	10-6
Layout Drawing of Urea SCR System	10-6
Urea SCR System Diagram	10-10
Function of Urea SCR System	10-11
Component Parts of Urea SCR System	10-22
Boot-up System	10-31
Layout Drawing of Boot-up System	10-31
System Operating Lamp System.....	10-33
Battery Disconnect Switch.....	10-34
Engine System.....	10-35

Layout Drawing of Engine System	10-35
Engine Control System	10-37
Auto-Deceleration System.....	10-40
Engine Automatic Warm-up System.....	10-42
Overheat Prevention System	10-44
Turbocharger Protection System.....	10-47
Automatic Idle Stop System	10-49
Component Parts of Engine System	10-53
Cooling System.....	10-69
Layout Drawing of Cooling System	10-69
Hybrid System.....	10-71
Layout Drawing of Hybrid System	10-71
System Diagram of Hybrid System.....	10-72
Structure of Hybrid System	10-73
Hybrid Protection System.....	10-74
Cooling System of Hybrid Components.....	10-76
Interlock System of Hybrid Components	10-77
Worker Protection System for When You Disassemble Hybrid Components	10-78
Component Parts of Hybrid System	10-80
Control System	10-87
Layout Drawing of Control System	10-87
Machine Monitor System.....	10-90
KomVision System	10-92
KOMTRAX System	10-96
Component Parts of Control System	10-97
Hydraulic System	10-137
Layout Drawing of Hydraulic System.....	10-137
CLSS	10-140
Engine and Pump Combined Control System	10-163
Pump and Valve Control System.....	10-169
Component Parts of Hydraulic System.....	10-172
Work Equipment System	10-258
Layout Drawing of Work Equipment System	10-258
Structure of Valve Control	10-264
One-Touch Power Maximizing System	10-265
Machine Push-up System	10-267
PPC Lock System	10-269
Work Equipment and Travel Automatic Lock System	10-270
Attachment Oil Flow Adjuster System	10-272
Tool Control System	10-274
Component Parts of Work Equipment System	10-276
Swing System	10-308
Layout Drawing of Swing System.....	10-308
Swing Control System Diagram	10-311
Component Parts of Swing System.....	10-314
Travel System	10-318
Layout Drawing of Travel System.....	10-318
System Diagram of Travel Control System.....	10-322
Component Parts of Travel System.....	10-324
Undercarriage and Frame	10-344
Layout Drawing of Undercarriage.....	10-344
Work Equipment	10-346
Structure of Work Equipment	10-346
Function of Work Equipment	10-347
Work Equipment Clearance Adjustment Shim	10-348
Bucket Clearance Adjustment Shim	10-349
CAB Related Parts	10-350
ROPS CAB	10-350

It's a preview. You can download the full file by
clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$