

Shop Manual

HYDRAULIC
EXCAVATOR

PC130-11

SERIAL NUMBERS 90001 and up

KOMATSU

00 INDEX AND FOREWORD

INDEX

00 INDEX AND FOREWORD	00-1
FOREWORD, SAFETY, BASIC INFORMATION	00-20
HOW TO READ THE SHOP MANUAL	00-20
SAFETY NOTICE FOR OPERATION	00-22
PRECAUTIONS TO PREVENT FIRE	00-30
ACTIONS IF FIRE OCCURS	00-32
PRECAUTIONS FOR DISPOSING OF WASTE MATERIALS	00-33
ACTIONS TAKEN TO MEET EXHAUST GAS REGULATIONS	00-34
PRECAUTIONS FOR DEF	00-35
STORE AdBlue/DEF	00-36
PRECAUTIONS FOR HANDLING HYDRAULIC EQUIPMENT	00-37
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF PIPINGS	00-40
PRECAUTIONS FOR HANDLING ELECTRICAL EQUIPMENT	00-47
PRECAUTIONS FOR HANDLING FUEL SYSTEM EQUIPMENT	00-49
PRECAUTIONS FOR HANDLING INTAKE SYSTEM EQUIPMENT	00-50
PRACTICAL USE OF KOMTRAX	00-51
DISCONNECT AND CONNECT PUSH-PULL TYPE COUPLER	00-52
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF CONNECTORS	00-56
METHOD FOR DISCONNECTING AND CONNECTING DEUTSCH CONNECTOR	00-60
METHOD FOR DISCONNECTING AND CONNECTING SLIDE LOCK TYPE CONNECTOR	00-61
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PULL ..	00-63
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PUSH ..	00-64
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH HOUSING TO ROTATE .	00-66
HOW TO READ ELECTRICAL WIRE CODE	00-67
EXPLANATION OF TERMS FOR MAINTENANCE STANDARD	00-71
STANDARD TIGHTENING TORQUE TABLE	00-74
CONVERSION TABLE	00-81
ABBREVIATION LIST	00-86
01 SPECIFICATIONS	01-1
CONTENTS	01-2
SPECIFICATIONS	01-3
SPECIFICATION DRAWING	01-3
WORKING RANGE DRAWINGS	01-5
SPECIFICATIONS	01-6
WEIGHT TABLE	01-9
FUEL, COOLANT, LUBRICANT	01-11
10 STRUCTURE AND FUNCTION	10-1
CONTENTS	10-2
UREA SCR SYSTEM	10-5
LAYOUT DRAWING OF UREA SCR SYSTEM	10-5
UREA SCR SYSTEM DIAGRAM	10-8
FUNCTION OF UREA SCR SYSTEM	10-9
COMPONENT PARTS OF UREA SCR SYSTEM	10-21
BOOT-UP SYSTEM	10-30
LAYOUT DRAWING OF BOOT-UP SYSTEM (SERIAL NO.: 90001 TO 92188)	10-30
LAYOUT DRAWING OF BOOT-UP SYSTEM (SERIAL NO.: 92189 AND UP)	10-31
SYSTEM OPERATING LAMP SYSTEM	10-32
BATTERY DISCONNECT SWITCH	10-34
ENGINE SYSTEM	10-36
LAYOUT DRAWING OF ENGINE SYSTEM	10-36
ENGINE CONTROL SYSTEM	10-38
AUTO-DECELERATION SYSTEM	10-41
ENGINE AUTOMATIC WARM-UP SYSTEM	10-43
OVERHEAT PREVENTION SYSTEM	10-45
TURBOCHARGER PROTECTION SYSTEM	10-47

AUTOMATIC IDLE STOP SYSTEM	10-48
COMPONENT PARTS OF ENGINE SYSTEM	10-51
COOLING SYSTEM.....	10-68
LAYOUT DRAWING OF COOLING SYSTEM	10-68
FAN SPEED CONTROL SYSTEM OF FAN CLUTCH	10-70
ENGINE OUTPUT CONTROL SYSTEM OF FAN CLUTCH.....	10-72
COMPONENT PARTS OF COOLING SYSTEM.....	10-74
CONTROL SYSTEM.....	10-75
LAYOUT DRAWING OF CONTROL SYSTEM	10-75
MACHINE MONITOR SYSTEM	10-77
KomVision SYSTEM	10-79
KOMTRAX SYSTEM.....	10-82
COMPONENT PARTS OF CONTROL SYSTEM.....	10-83
HYDRAULIC SYSTEM.....	10-119
LAYOUT DRAWING OF HYDRAULIC SYSTEM	10-119
CLSS	10-121
ENGINE AND PUMP COMBINED CONTROL SYSTEM.....	10-124
COMPONENT PARTS OF HYDRAULIC SYSTEM	10-129
WORK EQUIPMENT SYSTEM	10-216
LAYOUT DRAWING OF WORK EQUIPMENT SYSTEM	10-216
STRUCTURE OF VALVE CONTROL.....	10-218
PPC LOCK SYSTEM	10-219
WORK EQUIPMENT AND TRAVEL AUTOMATIC LOCK SYSTEM	10-220
COMPONENT PARTS OF WORK EQUIPMENT SYSTEM.....	10-222
SWING SYSTEM.....	10-246
LAYOUT DRAWING OF SWING SYSTEM	10-246
SWING CONTROL SYSTEM DIAGRAM	10-248
COMPONENT PARTS OF SWING SYSTEM.....	10-251
TRAVEL SYSTEM.....	10-262
LAYOUT DRAWING OF TRAVEL SYSTEM.....	10-262
SYSTEM DIAGRAM OF TRAVEL CONTROL SYSTEM.....	10-264
COMPONENT PARTS OF TRAVEL SYSTEM	10-268
UNDERCARRIAGE AND FRAME.....	10-284
LAYOUT DRAWING OF UNDERCARRIAGE	10-284
IDLER CUSHION.....	10-285
WORK EQUIPMENT.....	10-286
STRUCTURE OF WORK EQUIPMENT	10-286
FUNCTION OF WORK EQUIPMENT	10-287
WORK EQUIPMENT CLEARANCE ADJUSTMENT SHIM.....	10-288
BUCKET CLEARANCE ADJUSTMENT SHIM	10-289
CAB AND ITS ATTACHMENTS	10-290
ROPS CAB	10-290
CAB MOUNT	10-291
CAB TIPPING STOPPER	10-292
20 STANDARD VALUE TABLE	20-1
CONTENTS	20-2
STANDARD VALUE TABLE FOR ENGINE	20-3
STANDARD VALUE TABLE FOR ENGINE: PC130-11.....	20-3
STANDARD VALUE TABLE FOR MACHINE.....	20-6
STANDARD VALUE TABLE FOR MACHINE: PC130-11	20-6
MACHINE POSTURE AND PROCEDURES TO MEASURE PERFORMANCE	20-20
30 TESTING AND ADJUSTING	30-1
CONTENTS	30-2
RELATED INFORMATION ON TESTING AND ADJUSTING	30-5
TOOLS FOR TESTING AND ADJUSTING.....	30-5
SKETCH OF TOOLS FOR TESTING AND ADJUSTING	30-12
ENGINE AND COOLING SYSTEM.....	30-14
TEST ENGINE SPEED	30-14

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$