

Shop Manual

HYDRAULIC
EXCAVATOR

PC138US-11

SERIAL NUMBERS 51618 and up

KOMATSU

00 Index and Foreword

Index

00 Index and Foreword	00-1
Abbreviation List	00-19
Foreword, Safety, Basic Information	00-25
How to Read the Shop Manual	00-25
Safety Notice for Operation	00-27
Precautions to Prevent Fire	00-35
Procedures If Fire Occurs	00-37
Precautions When You Discard Waste Materials	00-38
Procedures for Exhaust Gas Regulations	00-39
Precautions for DEF	00-40
Store DEF	00-41
Precautions When You Handle Hydraulic Equipment	00-42
Precautions When You Disconnect and Connect Pipings	00-45
Precautions When You Handle Electrical Equipment	00-52
Precautions When You Handle Fuel System Equipment	00-54
Precautions When You Handle Intake System Equipment	00-55
Practical Use of KOMTRAX	00-56
Disconnect and Connect Push-Pull Type Coupler	00-57
Precautions for Disconnection and Connection of Connectors	00-61
Disconnect and Connect Deutsch Connector	00-65
How to Disconnect and Connect Slide Lock Type Connector	00-66
Disconnect and Connect Connector with Lock to Pull	00-68
Disconnect and Connect Connector with Lock to Push	00-69
Disconnect and Connect Connector with Housing to Rotate	00-71
How to Read the Codes for Electric Cable	00-72
Explanation of Terms for Maintenance Standard	00-76
Standard Tightening Torque Table	00-79
Conversion Table	00-86
01 Specification	01-1
Table of Contents	01-2
Abbreviation List	01-3
Specifications	01-9
Specification Drawing	01-9
Working Range Drawings	01-11
Specifications	01-12
Weight Table	01-16
Table of Fuel, Coolant, and Lubricants	01-18
10 Structure and Function	10-1
Table of Contents	10-2
Abbreviation List	10-5
Urea SCR System	10-11
Layout Drawing of Urea SCR System	10-11
Urea SCR System Diagram	10-13
Function of Urea SCR System	10-14
Component Parts of Urea SCR System	10-36
Boot-up System	10-45
Layout Drawing of Boot-up System	10-45
System Operating Lamp System	10-46
Battery Disconnect Switch	10-49
Engine System	10-50
Layout Drawing of Engine System	10-50
Engine Control System	10-52
Auto-Deceleration System	10-58
Engine Automatic Warm-up System	10-60
Overheat Prevention System	10-62
Turbocharger Protection System	10-64

Automatic Idle Stop System	10-65
Component Parts of Engine System	10-69
Cooling System.....	10-85
Layout Drawing of Cooling System	10-85
Control System	10-87
Layout Drawing of Control System (Machine with KOMTRAX Terminal)	10-87
Layout Drawing of Control System (Machine with Gateway Function Controller)	10-89
Machine Monitor System.....	10-91
KomVision System.....	10-94
KOMTRAX System	10-98
Component Parts of Control System	10-100
Hydraulic System	10-139
Layout Drawing of Hydraulic System.....	10-139
CLSS	10-141
Engine and Pump Combined Control System	10-144
Component Parts of Hydraulic System.....	10-149
Work Equipment System.....	10-232
Layout Drawing of Work Equipment System	10-232
Structure of Valve Control	10-235
PPC Lock System	10-236
Work Equipment and Travel Automatic Lock System	10-237
Attachment Oil Flow Adjuster System	10-239
Quick Coupler Control Valve System.....	10-241
Component Parts of Work Equipment System	10-242
Swing System	10-267
Layout Drawing of Swing System.....	10-267
Swing Control System Diagram	10-269
Component Parts of Swing System.....	10-272
Travel System	10-284
Layout Drawing of Travel System.....	10-284
System Diagram of Travel Control System.....	10-286
Component Parts of Travel System.....	10-290
Undercarriage and Frame	10-309
Layout Drawing of Undercarriage.....	10-309
Idler Cushion.....	10-310
Work Equipment	10-311
Structure of Work Equipment	10-311
Function of Work Equipment.....	10-312
Work Equipment Clearance Adjustment Shim.....	10-313
Bucket Clearance Adjustment Shim	10-314
CAB Related Parts.....	10-315
ROPS CAB	10-315
CAB Mount	10-317
Remove Wiring Harness Out of Cab	10-319
20 Standard Value Table	20-1
Table of Contents	20-2
Abbreviation List	20-3
Standard Value Table for Engine	20-9
Standard Value Table for Engine: PC138US-11	20-9
Standard Value Table for Machine.....	20-13
Standard Value Table for Machine: PC138US-11	20-13
Machine Posture and Procedures to Measure Performance	20-27
30 Testing and Adjusting	30-1
Table of Contents	30-2
Precautions Before Work	30-5
Abbreviation List	30-6
Related Information on Testing and Adjusting	30-12
Differences In Machine Monitor Symbols	30-12

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$