

Shop Manual

HYDRAULIC
EXCAVATOR

PC210LC-11

SERIAL NUMBERS 500001 and up

KOMATSU

00 Index and Foreword

Index

00 Index and Foreword	00-1
Abbreviation List	00-19
Foreword, Safety, Basic Information.....	00-22
How to Read the Shop Manual	00-22
Safety Notice for Operation	00-24
Precautions to Prevent Fire.....	00-32
Procedures If Fire Occurs	00-34
Precautions for Disposing of Waste Materials	00-35
Procedures for Exhaust Gas Regulations.....	00-36
Precautions for DEF.....	00-37
Precautions When You Handle Hydraulic Equipment	00-38
Precautions When You Disconnect and Connect Pipings.....	00-41
Precautions When You Handle Electrical Equipment	00-48
Precautions When You Handle Fuel System Equipment	00-50
Precautions When You Handle Intake System Equipment	00-51
Practical Use of KOMTRAX	00-52
Disconnect and Connect Push-Pull Type Coupler	00-53
Precautions for Disconnection and Connection of Connectors	00-57
How to Disconnect and Connect Deutsch Connector	00-61
How to Disconnect and Connect Slide Lock Type Connector	00-62
How to Disconnect and Connect Connector with Lock to Pull	00-64
How to Disconnect and Connect Connector with Lock to Push	00-65
How to Disconnect and Connect Connector with Housing to Rotate	00-67
How to Read the Codes for Electric Cable	00-68
Explanation of Terms for Maintenance Standard	00-72
Standard Tightening Torque Table.....	00-75
Conversion Table	00-82
01 Specifications.....	01-1
Table of Contents	01-2
Specifications.....	01-3
Specification Drawing.....	01-3
Working Range Drawings.....	01-5
Specifications.....	01-6
Weight Table	01-9
Table of Fuel, Coolant, and Lubricants	01-11
Fuel, Coolant, Lubricant	01-12
10 Structure and Function	10-1
Table of Contents	10-2
Urea SCR System.....	10-5
Layout Drawing of Urea SCR System	10-6
Urea SCR System Diagram	10-11
Function of Urea SCR System	10-12
Component Parts of Urea SCR System	10-28
Boot-up System	10-37
Layout Drawing of Boot-up System	10-37
System Operating Lamp System.....	10-39
Battery Disconnect Switch.....	10-41
Engine System.....	10-42
Layout Drawing of Engine System	10-42
Engine Control System	10-44
Auto-Deceleration System.....	10-47
Engine Automatic Warm-up System.....	10-49
Overheat Prevention System	10-51
Turbocharger Protection System.....	10-54
Automatic Idle Stop System	10-56
Component Parts of Engine System	10-59

Cooling System	10-78
Layout Drawing of Cooling System	10-78
Fan Speed Control System of Fan Clutch	10-80
Engine Output Control System of Fan Clutch	10-82
Component Parts of Cooling System	10-84
Control System	10-85
Layout Drawing of Control System	10-85
Machine Monitor System	10-88
KomVision System	10-89
KOMTRAX System	10-93
Component Parts of Control System	10-94
Hydraulic System	10-131
Layout Drawing of Hydraulic System	10-131
CLSS	10-137
Engine and Pump Combined Control System	10-160
Pump and Valve Control System	10-166
Component Parts of Hydraulic System	10-169
Work Equipment System	10-256
Layout Drawing of Work Equipment System	10-256
Structure of Valve Control	10-261
One-Touch Power Maximizing System	10-263
PPC Lock System	10-265
Work Equipment and Travel Automatic Lock System	10-266
Attachment Oil Flow Adjuster System	10-268
Tool Control System	10-270
Component Parts of Work Equipment System	10-272
Swing System	10-314
Layout Drawing of Swing System	10-314
Swing Control System Diagram	10-318
Component Parts of Swing System	10-322
Travel System	10-337
Layout Drawing of Travel System	10-337
System Diagram of Travel Control System	10-341
Component Parts of Travel System	10-343
Undercarriage and Frame	10-364
Layout Drawing of Undercarriage	10-364
Work Equipment	10-366
Structure of Work Equipment	10-366
Function of Work Equipment	10-366
Work Equipment Clearance Adjustment Shim	10-367
Bucket Clearance Adjustment Shim	10-367
CAB Related Parts	10-368
ROPS CAB	10-368
CAB Mount	10-369
CAB Tipping Stopper	10-370
20 Standard Value Table	20-1
Table of Contents	20-2
Standard Value Table for Engine	20-3
Standard Value Table for Engine: PC210LC-11	20-3
Standard Value Table for Machine	20-7
Standard Value Table for Machine: PC210LC-11	20-7
Machine Posture and Procedures to Measure Performance	20-20
Standard Value Table for Electricity	20-24
Standard Value Table for Electricity	20-24
30 Testing and Adjusting	30-1
Table of Contents	30-2
Precautions Before Work	30-5
Related Information on Testing and Adjusting	30-6

It's a preview. You can download the full file by
clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$