

# Shop Manual

HYDRAULIC  
EXCAVATOR

***PC240LC-11***

SERIAL NUMBERS 95321 and up

**KOMATSU**



---

# 00 Index and Foreword

---

# Index

00 Index and Foreword .....	00-1
Abbreviation List .....	00-19
Foreword, Safety, Basic Information .....	00-22
How to Read the Shop Manual .....	00-22
Safety Notice for Operation .....	00-24
Precautions to Prevent Fire .....	00-32
Procedures If Fire Occurs .....	00-34
Precautions for Disposing of Waste Materials .....	00-35
Procedures for Exhaust Gas Regulations .....	00-36
Precautions for DEF .....	00-37
Store DEF .....	00-38
Precautions When You Handle Hydraulic Equipment .....	00-39
Precautions When You Disconnect and Connect Pipings .....	00-42
Precautions When You Handle Electrical Equipment .....	00-49
Precautions When You Handle Fuel System Equipment .....	00-51
Precautions When You Handle Intake System Equipment .....	00-52
Practical Use of KOMTRAX .....	00-53
Disconnect and Connect Push-Pull Type Coupler .....	00-54
Precautions for Disconnection and Connection of Connectors .....	00-58
How to Disconnect and Connect Deutsch Connector .....	00-62
How to Disconnect and Connect Slide Lock Type Connector .....	00-63
How to Disconnect and Connect Connector with Lock to Pull .....	00-65
How to Disconnect and Connect Connector with Lock to Push .....	00-66
How to Disconnect and Connect Connector with Housing to Rotate .....	00-68
How to Read the Codes for Electric Cable .....	00-69
Explanation of Terms for Maintenance Standard .....	00-73
Standard Tightening Torque Table .....	00-76
Conversion Table .....	00-83
01 Specifications .....	01-1
Table of Contents .....	01-2
Specifications .....	01-3
Specification Drawing .....	01-3
Working Range Drawings .....	01-5
Specifications .....	01-6
Weight Table .....	01-9
Table of Fuel, Coolant, and Lubricants .....	01-11
10 Structure and Function .....	10-1
Table of Contents .....	10-2
Urea SCR System .....	10-5
Layout Drawing of Urea SCR System .....	10-6
Urea SCR System Diagram .....	10-11
Function of Urea SCR System .....	10-12
Component Parts of Urea SCR System .....	10-22
Boot-up System .....	10-31
Layout Drawing of Boot-up System .....	10-31
System Operating Lamp System .....	10-33
Battery Isolator .....	10-35
Engine System .....	10-36
Layout Drawing of Engine System .....	10-36
Engine Control System .....	10-38
Auto-Deceleration System .....	10-42
Engine Automatic Warm-up System .....	10-44
Overheat Prevention System .....	10-46
Turbocharger Protection System .....	10-49
Automatic Idle Stop System .....	10-51
Component Parts of Engine System .....	10-54

Cooling System.....	10-72
Layout Drawing of Cooling System .....	10-72
Control System .....	10-74
Layout Drawing of Control System .....	10-74
Machine Monitor System.....	10-77
KomVision System.....	10-79
KOMTRAX System .....	10-83
PPC Levers.....	10-84
Automatic Grease System.....	10-86
Component Parts of Control System .....	10-98
Hydraulic System .....	10-135
Layout Drawing of Hydraulic System.....	10-135
CLSS .....	10-141
Engine and Pump Combined Control System .....	10-163
Pump and Valve Control System.....	10-169
Component Parts of Hydraulic System.....	10-172
Work Equipment System.....	10-263
Layout Drawing of Work Equipment System .....	10-263
Structure of Valve Control .....	10-268
One-Touch Power Maximizing System .....	10-270
PPC Lock System .....	10-272
Work Equipment and Travel Automatic Lock System .....	10-273
Attachment Oil Flow Adjuster System .....	10-275
Tool Control System.....	10-277
Component Parts of Work Equipment System .....	10-279
Swing System .....	10-311
Layout Drawing of Swing System.....	10-311
Swing Control System Diagram .....	10-315
Component Parts of Swing System.....	10-319
Travel System .....	10-333
Layout Drawing of Travel System.....	10-333
System Diagram of Travel Control System.....	10-337
Component Parts of Travel System.....	10-339
Undercarriage and Frame .....	10-360
Layout Drawing of Undercarriage.....	10-360
Work Equipment .....	10-362
Structure of Work Equipment .....	10-362
Function of Work Equipment.....	10-363
Work Equipment Clearance Adjustment Shim.....	10-364
Bucket Clearance Adjustment Shim .....	10-365
CAB Related Parts.....	10-366
ROPS CAB .....	10-366
CAB Mount .....	10-367
CAB Tipping Stopper .....	10-368
20 Standard Value Table .....	20-1
Table of Contents .....	20-2
Standard Value Table for Engine .....	20-3
Standard Value Table for Engine: PC240LC-11 .....	20-3
Standard Value Table for Machine.....	20-7
Standard Value Table for Machine: PC240LC-11.....	20-7
Machine Posture and Procedures to Measure Performance .....	20-20
Standard Value Table for Electricity.....	20-24
Standard Value Table for Electricity.....	20-24
30 Testing and Adjusting .....	30-1
Table of Contents .....	30-2
Precautions Before Work .....	30-5
Related Information on Testing and Adjusting .....	30-6
Tools for Testing and Adjusting.....	30-6

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$