

# Shop Manual

HYDRAULIC  
EXCAVATOR

**PC270 -8**

**PC270LC-8**

**PC290LC-8**

SERIAL NUMBERS	PC270- 20001	and up
	PC270LC-20001	
	PC290LC-30941	

**ecot3**

**KOMATSU**



---

# 00 Index and foreword

---

## Table of contents

00 Index and foreword	
Foreword and general information .....	00-9
Safety notice .....	00-9
How to read the shop manual .....	00-14
Explanation of terms for maintenance standard .....	00-16
Handling of electric equipment and hydraulic component .....	00-18
Handling of connectors newly used for engines .....	00-27
How to read electric wire code .....	00-30
Precautions when carrying out operation.....	00-33
Method of disassembling and connecting push-pull type coupler.....	00-36
Standard tightening torque table .....	00-39
Conversion table .....	00-43
01 Specification	
Specification and technical data.....	01-3
Specification dimension drawings .....	01-3
Working range diagram.....	01-4
Specifications .....	01-5
Weight table .....	01-7
Table of fuel, coolant and lubricants.....	01-9
10 Structure, function and maintenance standard	
Engine and cooling system .....	10-3
Engine related parts .....	10-3
Radiator, oil cooler, aftercooler and fuel cooler.....	10-4
Power train.....	10-5
Power train.....	10-5
Final drive .....	10-6
Swing machinery.....	10-8
Swing circle.....	10-10
Undercarriage and frame .....	10-11
Track frame and recoil spring.....	10-11
Idler .....	10-13
Carrier roller .....	10-15
Track roller .....	10-16
Track shoe .....	10-17
Hydraulic system.....	10-20
Hydraulic equipment layout drawing .....	10-20
Hydraulic tank and filter .....	10-22
Hydraulic pump .....	10-24
Pilot oil filter.....	10-46
Control valve .....	10-47
CLSS.....	10-58
Functions and operation by valve .....	10-62
Swing motor .....	10-100
Center swivel joint.....	10-108
Travel motor .....	10-110
PPC valve .....	10-122
Valve control .....	10-142
Solenoid valve.....	10-144
PPC accumulator.....	10-146
Anti-drop valve for boom.....	10-147
Anti-drop valve for arm.....	10-153
Return oil filter .....	10-159
Attachment circuit selector valve .....	10-160

Hydraulic cylinder .....	10-162
Work equipment.....	10-164
Dimensions of components .....	10-164
Cab and its attachments .....	10-170
Air conditioner piping .....	10-170
Electrical system.....	10-171
Engine control.....	10-171
Electrical control system .....	10-179
Monitor system .....	10-202
Sensor .....	10-228
KOMTRAX system.....	10-231
20 Standard value table	
Standard service value table.....	20-3
Standard value table for engine related parts .....	20-3
Standard value table for chassis related parts .....	20-4
30 Testing and adjusting	
Related information on testing and adjusting.....	30-3
Tools for testing, adjusting, and troubleshooting.....	30-3
Sketch of special tool.....	30-7
Engine and cooling system .....	30-8
Testing engine speed.....	30-8
Testing intake air pressure (boost pressure).....	30-9
Checking exhaust gas color.....	30-10
Adjusting valve clearance .....	30-11
Testing compression pressure .....	30-13
Testing blow-by pressure .....	30-15
Testing engine oil pressure .....	30-16
Handling fuel system parts.....	30-17
Releasing residual pressure from fuel system .....	30-17
Testing fuel pressure.....	30-18
Testing fuel delivery, return and leak amount.....	30-21
Bleeding air from fuel circuit .....	30-24
Checking fuel circuit for leakage.....	30-25
Checking and adjusting air conditioner compressor belt tension.....	30-26
Replacing fan belt .....	30-27
Power train.....	30-28
Testing swing circle bearing clearance .....	30-28
Undercarriage and frame.....	30-29
Checking and adjusting track shoe tension .....	30-29
Hydraulic system .....	30-31
Testing and adjusting oil pressure in work equipment, swing, and travel circuits .....	30-31
Testing control circuit basic pressure.....	30-34
Testing and adjusting oil pressure in pump PC control circuit .....	30-35
Testing and adjusting oil pressure in pump LS control circuit .....	30-38
Testing solenoid valve output pressure.....	30-43
Testing PPC valve output pressure.....	30-46
Adjusting play of work equipment and swing PPC valves .....	30-48
Checking parts which cause hydraulic drift of work equipment .....	30-49
Releasing residual pressure from hydraulic circuit .....	30-51
Testing oil leakage .....	30-52
Bleeding air from each part.....	30-55
Checking cab tipping stopper .....	30-57
Installation and adjustment of mirrors .....	30-58
Electrical system.....	30-61
Special functions of machine monitor .....	30-61
Handling voltage circuit of engine controller .....	30-116

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$