

Shop Manual

HYDRAULIC
EXCAVATOR

PC360LC-11

SERIAL NUMBERS 90825 and up

KOMATSU

00 Index and Foreword

Index

00 Index and Foreword	00-1
Abbreviation List	00-19
Foreword, Safety, Basic Information.....	00-22
How to Read the Shop Manual	00-22
Safety Notice for Operation	00-24
Precautions to Prevent Fire.....	00-32
Procedures If Fire Occurs	00-34
Precautions for Disposing of Waste Materials	00-35
Procedures for Exhaust Gas Regulations.....	00-36
Precautions for DEF.....	00-37
Store DEF	00-38
Precautions When You Handle Hydraulic Equipment.....	00-39
Precautions When You Disconnect and Connect Pipings.....	00-42
Precautions When You Handle Electrical Equipment	00-49
Precautions When You Handle Fuel System Equipment	00-51
Precautions When You Handle Intake System Equipment	00-52
Practical Use of KOMTRAX	00-53
Disconnect and Connect Push-Pull Type Coupler	00-54
Precautions for Disconnection and Connection of Connectors	00-58
How to Disconnect and Connect Deutsch Connector	00-62
How to Disconnect and Connect Slide Lock Type Connector	00-63
How to Disconnect and Connect Connector with Lock to Pull	00-65
How to Disconnect and Connect Connector with Lock to Push	00-66
How to Disconnect and Connect Connector with Housing to Rotate	00-68
How to Read the Codes for Electric Cable	00-69
Explanation of Terms for Maintenance Standard	00-73
Standard Tightening Torque Table.....	00-76
Conversion Table	00-83
01 Specifications	01-1
Table of Contents	01-2
Specifications	01-3
Specification Drawing.....	01-3
Working Range Drawings.....	01-5
Specifications.....	01-6
Weight Table	01-9
Table of Fuel, Coolant, and Lubricants	01-11
10 Structure and Function	10-1
Table of Contents	10-2
Urea SCR System.....	10-5
Layout Drawing of Urea SCR System (Applicable Machine: 90156 to 92053).....	10-5
Layout Drawing of Urea SCR System (Applicable Machine: 92054 and up).....	10-10
Urea SCR System Diagram	10-14
Function of Urea SCR System	10-15
Component Parts of Urea SCR System	10-27
Boot-up System	10-37
Layout Drawing of Boot-up System	10-37
System Operating Lamp System.....	10-39
Battery Isolator	10-41
Engine System	10-42
Layout Drawing of Engine System	10-42
Engine Control System	10-44
Auto-Deceleration System.....	10-48
Engine Automatic Warm-up System	10-50
Overheat Prevention System	10-52
Turbocharger Protection System.....	10-54
Automatic Idle Stop System	10-56

Component Parts of Engine System	10-59
Cooling System.....	10-75
Layout Drawing of Cooling System	10-75
Control System	10-77
Layout Drawing of Control System	10-77
Machine Monitor System.....	10-80
KomVision System	10-82
KOMTRAX System	10-86
PPC Levers.....	10-87
Automatic Grease System.....	10-89
Component Parts of Control System	10-101
Hydraulic System	10-139
Layout Drawing of Hydraulic System.....	10-139
CLSS	10-142
Engine and Pump Combined Control System	10-165
Pump and Valve Control System.....	10-171
Component Parts of Hydraulic System.....	10-174
Work Equipment System.....	10-265
Layout Drawing of Work Equipment System	10-265
Structure of Valve Control	10-271
One-Touch Power Maximizing System	10-273
Machine Push-up System	10-275
PPC Lock System	10-277
Work Equipment and Travel Automatic Lock System	10-278
Attachment Oil Flow Adjuster System	10-280
Component Parts of Work Equipment System	10-282
Swing System	10-309
Layout Drawing of Swing System.....	10-309
Swing Control System Diagram	10-312
Component Parts of Swing System.....	10-316
Travel System	10-330
Layout Drawing of Travel System.....	10-330
System Diagram of Travel Control System.....	10-334
Component Parts of Travel System.....	10-336
Undercarriage and Frame	10-356
Layout Drawing of Undercarriage.....	10-356
Work Equipment	10-358
Structure of Work Equipment	10-358
Function of Work Equipment	10-359
Work Equipment Clearance Adjustment Shim.....	10-360
Bucket Clearance Adjustment Shim	10-361
CAB Related Parts	10-362
ROPS CAB	10-362
CAB Mount	10-363
CAB Tipping Stopper	10-364
20 Standard Value Table	20-1
Table of Contents	20-2
Standard Value Table for Engine	20-3
Standard Value Table for Engine: PC360LC-11	20-3
Standard Value Table for Machine.....	20-8
Standard Value Table for Machine: PC360LC-11.....	20-8
Machine Posture and Procedures to Measure Performance	20-23
Standard Value Table for Electricity	20-27
Standard Value Table for Electricity	20-27
30 Testing and Adjusting	30-1
Table of Contents	30-2
Precautions Before Work	30-5
Related Information on Testing and Adjusting	30-6

It's a preview. You can download the full file by
clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$