

Shop Manual

HYDRAULIC
EXCAVATOR

PC490LC-11

SERIAL NUMBERS 85001 and up

KOMATSU

00 Index and Foreword

Index

00 Index and Foreword	00-1
Abbreviation List	00-19
Foreword, Safety, Basic Information.....	00-22
How to Read the Shop Manual	00-22
Safety Notice for Operation	00-24
Precautions to Prevent Fire.....	00-32
Procedures If Fire Occurs	00-34
Precautions for Disposing of Waste Materials	00-35
Procedures for Exhaust Gas Regulations.....	00-36
Precautions for DEF.....	00-37
Store DEF	00-38
Precautions When You Handle Hydraulic Equipment.....	00-39
Precautions When You Disconnect and Connect Pipings.....	00-42
Precautions When You Handle Electrical Equipment	00-49
Precautions When You Handle Fuel System Equipment	00-51
Precautions When You Handle Intake System Equipment	00-52
Practical Use of KOMTRAX	00-53
Disconnect and Connect Push-Pull Type Coupler	00-54
Precautions for Disconnection and Connection of Connectors	00-58
How to Disconnect and Connect Deutsch Connector	00-62
How to Disconnect and Connect Slide Lock Type Connector	00-63
How to Disconnect and Connect Connector with Lock to Pull	00-64
How to Disconnect and Connect Connector with Lock to Push	00-65
How to Disconnect and Connect Connector with Housing to Rotate	00-67
How to Read the Codes for Electric Cable	00-68
Explanation of Terms for Maintenance Standard	00-72
Standard Tightening Torque Table.....	00-75
Conversion Table	00-82
01 Specifications	01-1
Table of Contents	01-2
Specifications	01-3
Specification Drawing.....	01-3
Working Range Drawings.....	01-5
Specifications.....	01-6
Weight Table	01-9
Table of Fuel, Coolant, and Lubricants	01-11
10 Structure and Function	10-1
Table of Contents	10-2
Urea SCR System.....	10-6
Layout Drawing of Urea SCR System	10-6
Urea SCR System Diagram	10-10
Function of Urea SCR System	10-11
Component Parts of Urea SCR System	10-28
Boot-up System	10-37
Layout Drawing of Boot-up System	10-37
System Operating Lamp System.....	10-39
Battery Disconnect Switch.....	10-41
Engine System.....	10-42
Layout Drawing of Engine System	10-42
Engine Control System	10-45
Auto-Deceleration System.....	10-48
Engine Automatic Warm-up System.....	10-50
Overheat Prevention System	10-52
Turbocharger Protection System.....	10-55
Automatic Idle Stop System	10-57
Component Parts of Engine System	10-60

Cooling System	10-76
Layout Drawing of Cooling System	10-76
Fan Speed Control System of Hydraulic Fan	10-79
Engine Output Control System of Hydraulic Fan	10-81
Fan Reverse Rotation System of Hydraulic Fan.....	10-84
Component Parts of Cooling System	10-85
Control System	10-99
Layout Drawing of Control System	10-99
Machine Monitor System.....	10-102
KomVision System	10-103
KOMTRAX System	10-107
Component Parts of Control System	10-108
Hydraulic System	10-144
Layout Drawing of Hydraulic System.....	10-144
CLSS	10-146
Engine and Pump Combined Control System	10-169
Pump and Valve Control System.....	10-176
Component Parts of Hydraulic System.....	10-179
Work Equipment System.....	10-270
Layout Drawing of Work Equipment System	10-270
Structure of Valve Control	10-275
One-Touch Power Maximizing System.....	10-276
Machine Push-up System	10-278
PPC Lock System	10-280
Work Equipment and Travel Automatic Lock System	10-281
Attachment Oil Flow Adjuster System	10-283
Tool Control System	10-285
Component Parts of Work Equipment System	10-287
Swing System	10-318
Layout Drawing of Swing System.....	10-318
Swing Control System Diagram	10-324
Component Parts of Swing System.....	10-328
Travel System	10-343
Layout Drawing of Travel System.....	10-343
System Diagram of Travel Control System.....	10-347
Component Parts of Travel System.....	10-349
Undercarriage and Frame	10-370
Layout Drawing of Undercarriage.....	10-370
Work Equipment	10-371
Structure of Work Equipment	10-371
Function of Work Equipment	10-372
Work Equipment Clearance Adjustment Shim.....	10-373
Bucket Clearance Adjustment Shim	10-374
CAB Related Parts	10-375
ROPS CAB	10-375
CAB Mount	10-376
CAB Tipping Stopper	10-377
20 Standard Value Table	20-1
Table of Contents	20-2
Standard Value Table for Engine	20-3
Standard Value Table for Engine: PC490LC-11	20-3
Standard Value Table for Machine.....	20-6
Standard Value Table for Machine: PC490LC-11.....	20-6
Machine Posture and Procedures to Measure Performance	20-22
Standard Value Table for Electricity	20-26
Standard Value Table for Electricity.....	20-26
30 Testing and Adjusting	30-1
Table of Contents	30-2

It's a preview. You can download the full file by
clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$