

# Shop Manual

BULLDOZER

***D85EX -18***

***D85PX -18***

SERIAL NUMBERS 22001 and up

**KOMATSU**



---

# 00 Index and Foreword

---

# Index

00 Index and Foreword .....	00-1
Abbreviation List .....	00-19
Foreword, Safety, Basic Information .....	00-22
How to Read the Shop Manual .....	00-22
Safety Notice for Operation .....	00-24
Precautions to Prevent Fire .....	00-32
Procedures If Fire Occurs .....	00-34
Precautions for Disposing of Waste Materials .....	00-35
Procedures for Exhaust Gas Regulations .....	00-36
Precautions for DEF .....	00-37
Store DEF .....	00-38
Precautions When You Handle Hydraulic Equipment .....	00-39
Precautions When You Disconnect and Connect Pipings .....	00-42
Precautions When You Handle Electrical Equipment .....	00-49
Precautions When You Handle Fuel System Equipment .....	00-51
Precautions When You Handle Intake System Equipment .....	00-52
Practical Use of KOMTRAX .....	00-53
Disconnect and Connect Push-Pull Type Coupler .....	00-54
Precautions for Disconnection and Connection of Connectors .....	00-58
How to Disconnect and Connect Deutsch Connector .....	00-62
How to Disconnect and Connect Slide Lock Type Connector .....	00-63
How to Disconnect and Connect Connector with Lock to Pull .....	00-65
How to Disconnect and Connect Connector with Lock to Push .....	00-66
How to Disconnect and Connect Connector with Housing to Rotate .....	00-68
How to Read the Codes for Electric Cable .....	00-69
Explanation of Terms for Maintenance Standard .....	00-73
Standard Tightening Torque Table .....	00-76
Conversion Table .....	00-83
01 Specifications .....	01-1
Table of Contents .....	01-2
Specifications .....	01-3
Specification Drawing .....	01-3
Specifications .....	01-7
Weight Table .....	01-20
Table of Fuel, Coolant, and Lubricants .....	01-26
10 Structure and Function .....	10-1
Table of Contents .....	10-2
Urea SCR System .....	10-5
Layout Drawing of Urea SCR System .....	10-5
Urea SCR System Diagram .....	10-8
Function of Urea SCR System .....	10-9
Component Parts of Urea SCR System .....	10-26
Boot-up System .....	10-35
Layout Drawing of Boot-up System .....	10-35
System Operating Lamp System .....	10-36
Battery Disconnect Switch .....	10-38
Engine System .....	10-40
Layout Drawing of Engine System .....	10-40
Engine Control System .....	10-42
Automatic Idle Stop System .....	10-47
Component Parts of Engine System .....	10-50
Cooling System .....	10-69
Layout Drawing of Cooling System .....	10-69
Cooling Fan Control System .....	10-71
Component Parts of Cooling System .....	10-74
Control System .....	10-91

Layout Drawing of Control System .....	10-91
Machine Monitor System.....	10-92
KOMTRAX System .....	10-94
Component Parts of Control System .....	10-95
Hydraulic System .....	10-124
Layout Drawing of Hydraulic System.....	10-124
CLSS .....	10-125
Component Parts of Hydraulic System.....	10-128
Power Train System.....	10-179
Layout Drawing of Power Train System .....	10-179
Operation of Power Train System .....	10-181
Transmission, Steering, and Brake Control .....	10-182
Palm Command Control System .....	10-185
HSS System.....	10-189
Centralized Pressure Pickup Port.....	10-192
Component Parts of Power Train System.....	10-194
Work Equipment System.....	10-255
Work Equipment Control .....	10-255
Layout Drawing of Front Work Equipment.....	10-258
Layout Drawing of Fixed Multi-Shank Ripper .....	10-259
Layout Drawing of Variable Multi-Shank Ripper .....	10-260
Component Parts of Work Equipment System .....	10-261
Undercarriage and Frame .....	10-284
Main Frame.....	10-284
Suspension .....	10-285
Track Frame and Idler Cushion .....	10-289
Work Equipment .....	10-291
Structure of Front Work Equipment .....	10-291
Structure of Cylinder Stay .....	10-293
Structure of Fixed Multi-Shank Ripper.....	10-294
Structure of Variable Multi-Shank Ripper.....	10-295
CAB Related Parts.....	10-296
ROPS CAB .....	10-296
CAB Mount .....	10-298
20 Standard Value Table .....	20-1
Table of Contents .....	20-2
Standard Value Table for Engine .....	20-3
Standard Value Table for Engine: D85EX-18.....	20-3
Standard Value Table for Engine: D85PX-18.....	20-6
Standard Value Table for Machine.....	20-9
Standard Value Table for Machine: D85EX-18 .....	20-9
Standard Value Table for Machine: D85PX-18 .....	20-26
Machine Posture and Procedures to Measure Performance .....	20-41
Standard Value Table for Electricity.....	20-44
Standard Value Table for Electricity .....	20-44
30 Testing and Adjusting .....	30-1
Table of Contents .....	30-2
Precautions Before Work .....	30-5
Related Information on Testing and Adjusting .....	30-6
Tools for Testing and Adjusting.....	30-6
Sketch of Tools for Testing and Adjusting .....	30-13
Engine and Cooling System .....	30-14
Examine Engine Speed.....	30-14
Examine Boost Pressure.....	30-18
Examine Exhaust Gas Temperature .....	30-20
Examine Exhaust Gas Color .....	30-22
Examine Mass Air Flow and Temperature Sensor .....	30-25
Examine and Adjust Valve Clearance.....	30-27

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$