

SHOP MANUAL

HYDRAULIC EXCAVATOR

HB205-1M0

HB215LC-1M0

Machine model	Serial number
HB205-1M0	10001 and up
HB215LC-1M0	10001 and up

00 Index and foreword

Table of Contents

00 Index and Foreword	
Table of Contents.....	00- 2
Table of Contents.....	00- 2
Foreword and general information	00- 14
Safety notice	00- 14
How to read the shop manual	00- 21
Explanation of terms for maintenance standard	00- 23
Handling equipment of fuel system devices.....	00- 25
Handling of hydraulic components.....	00- 26
Method of disconnecting and connecting push-pull type coupler	00- 28
Handling of electric equipment.....	00- 31
How to read electric wire code.....	00- 41
Precautions when performing work.....	00- 46
Handling of hybrid devices and high-voltage wirings	00- 49
Standard tightening torque table.....	00- 57
List of Abbreviation	00- 61
Conversion table	00- 65
01 Specifications	
Specifications.....	01- 3
Outline of hybrid system	01- 3
Specification dimension drawing.....	01- 4
Working range diagram.....	01- 5
Specifications.....	01- 6
Weight table	01- 9
Table of fuel, coolant and lubricants	01- 11
10 Structure and function	
Engine and cooling system	10- 3
Engine related parts.....	10- 3
Cooling system	10- 4
Hybrid relation.....	10- 6
Configuration and safety functions of hybrid system	10- 6
Cooling system of hybrid component.....	10- 10
Motor-generator	10- 12
Swing electric motor.....	10- 13
Electric control unit.....	10- 14
High-voltage wiring (power cable).....	10- 15
Water pump	10- 16
Power train system	10- 18
Power train.....	10- 18
Swing circle.....	10- 19
Swing machinery and swing brake	10- 20
Final drive	10- 22
Undercarriage and frame	10- 24
Track frame and idler cushion.....	10- 24
Hydraulic system.....	10- 26
Hydraulic components layout drawing	10- 26
Valve control	10- 28
Hydraulic tank	10- 29
CLSS.....	10- 30
Main pump	10- 34

Control valve.....	10- 56
Functions and operation by valve	10- 68
Travel motor.....	10-107
PPC valve	10-117
Solenoid valve	10-136
Attachment circuit selector valve	10-138
Center swivel joint.....	10-140
Accumulator.....	10-141
Work equipment.....	10-142
Work equipment.....	10-142
Shims for work equipment	10-143
Shims to adjust play of bucket	10-144
Electrical system	10-146
Electrical control system	10-146
Machine monitor system.....	10-175
KOMTRAX system.....	10-198
Sensors.....	10-204
20 Standard value table	
Standard service value table	20- 3
Standard value table for engine.....	20- 3
Standard value table for machine	20- 4
30 Testing and adjusting	
Tools for testing, adjusting and troubleshooting	30- 4
Tools for testing, adjusting, and troubleshooting	30- 4
Sketch of tools for testing and adjusting	30- 7
Engine and cooling system.....	30- 9
Testing and adjusting engine speed	30- 9
Testing boost pressure	30- 11
Testing exhaust gas color.....	30- 12
Adjusting valve clearance	30- 13
Testing compression pressure.....	30- 15
Testing blowby pressure.....	30- 18
Testing engine oil pressure.....	30- 19
Handling equipment of fuel system devices	30- 20
Releasing remaining pressure from fuel system.....	30- 20
Testing fuel pressure	30- 21
Testing fuel discharge, return and leakage.....	30- 24
Bleeding air from fuel circuit	30- 28
Testing fuel circuit for leakage	30- 29
Handling cylinder cutout mode operation	30- 30
Handling No-injection cranking operation	30- 30
Handling engine controller high voltage circuit	30- 31
Testing and adjusting air conditioner compressor belt tension.....	30- 32
Replacing fan belt	30- 33
Swing circle and undercarriage	30- 34
Testing swing circle bearing clearance	30- 34
Testing and adjusting track tension	30- 35
Hydraulic system	30- 37
Testing source pressure of control circuit	30- 37
Testing and adjusting oil pressure in work equipment and travel circuits.....	30- 38
Testing and adjusting oil pressure in pump PC control circuit	30- 41
Testing and adjusting oil pressure in pump LS control circuit.....	30- 44

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$