

Shop Manual

HYDRAULIC
EXCAVATOR

PC170LC-11

SERIAL NUMBERS 35001 and up

KOMATSU

00 Index and Foreword

Index

00 Index and Foreword	00-1
Abbreviation List	00-18
Foreword, Safety, Basic Information.....	00-21
How to Read the Shop Manual	00-21
Safety Notice for Operation	00-23
Precautions to Prevent Fire.....	00-31
Procedures If Fire Occurs	00-33
Precautions for Disposing of Waste Materials	00-34
Procedures for Exhaust Gas Regulations.....	00-35
Precautions for DEF.....	00-36
Store DEF	00-37
Precautions When You Handle Hydraulic Equipment.....	00-38
Precautions When You Disconnect and Connect Pipings.....	00-41
Precautions When You Handle Electrical Equipment	00-48
Precautions When You Handle Fuel System Equipment	00-50
Precautions When You Handle Intake System Equipment	00-51
Practical Use of KOMTRAX	00-52
Disconnect and Connect Push-Pull Type Coupler	00-53
Precautions for Disconnection and Connection of Connectors	00-57
How to Disconnect and Connect Deutsch Connector	00-61
How to Disconnect and Connect Slide Lock Type Connector	00-62
How to Disconnect and Connect Connector with Lock to Pull	00-64
How to Disconnect and Connect Connector with Lock to Push	00-65
How to Disconnect and Connect Connector with Housing to Rotate	00-67
How to Read the Codes for Electric Cable	00-68
Explanation of Terms for Maintenance Standard	00-72
Standard Tightening Torque Table.....	00-75
Conversion Table	00-82
01 Specifications	01-1
Table of Contents	01-2
Specifications	01-3
Specification Drawing.....	01-3
Working Range Drawings.....	01-5
Specifications.....	01-6
Weight Table	01-9
Table of Fuel, Coolant, and Lubricants	01-11
10 Structure and Function	10-1
Table of Contents	10-2
Urea SCR System.....	10-5
Layout Drawing of Urea SCR System	10-5
Urea SCR System Diagram	10-10
Function of Urea SCR System	10-11
Component Parts of Urea SCR System	10-30
Boot-up System	10-39
Layout Drawing of Boot-up System	10-39
System Operating Lamp System.....	10-41
Battery Disconnect Switch.....	10-42
Engine System.....	10-43
Layout Drawing of Engine System	10-43
Engine Control System	10-45
Auto-Deceleration System.....	10-48
Engine Automatic Warm-up System.....	10-50
Overheat Prevention System	10-52
Turbocharger Protection System.....	10-55
Automatic Idle Stop System	10-57
Component Parts of Engine System	10-60

Cooling System.....	10-76
Layout Drawing of Cooling System	10-76
Fan Speed Control System of Fan Clutch	10-78
Engine Output Control System of Fan Clutch	10-80
Component Parts of Cooling System	10-82
Control System	10-83
Layout Drawing of Control System	10-83
Machine Monitor System.....	10-86
KomVision System	10-88
KOMTRAX System	10-92
Component Parts of Control System	10-93
Hydraulic System	10-131
Layout Drawing of Hydraulic System.....	10-131
CLSS	10-135
Engine and Pump Combined Control System	10-138
Pump and Valve Control System.....	10-144
Component Parts of Hydraulic System.....	10-147
Work Equipment System.....	10-235
Layout Drawing of Work Equipment System	10-235
One-Touch Power Maximizing System	10-239
PPC Lock System	10-241
Work Equipment and Travel Automatic Lock System	10-242
Attachment Oil Flow Adjuster System	10-244
Component Parts of Work Equipment System	10-246
Swing System	10-280
Layout Drawing of Swing System.....	10-280
Swing Control System Diagram	10-284
Component Parts of Swing System.....	10-287
Travel System	10-295
Layout Drawing of Travel System.....	10-295
System Diagram of Travel Control System.....	10-298
Component Parts of Travel System.....	10-300
Undercarriage and Frame	10-320
Layout Drawing of Undercarriage.....	10-320
Work Equipment	10-322
Structure of Work Equipment	10-322
Function of Work Equipment	10-323
Work Equipment Clearance Adjustment Shim.....	10-324
Bucket Clearance Adjustment Shim	10-325
CAB Related Parts	10-326
ROPS CAB	10-326
CAB Mount	10-327
CAB Tipping Stopper	10-328
20 Standard Value Table	20-1
Table of Contents	20-2
Standard Value Table for Engine	20-3
Standard Value Table for Engine: PC170LC-11	20-3
Standard Value Table for Machine.....	20-7
Standard Value Table for Machine: PC170LC-11.....	20-7
Machine Posture and Procedures to Measure Performance	20-20
30 Testing and Adjusting	30-1
Table of Contents	30-2
Precautions Before Work	30-5
Related Information on Testing and Adjusting	30-6
Tools for Testing and Adjusting.....	30-6
Sketch of Tools for Testing and Adjusting	30-13
Engine and Cooling System.....	30-15
Examine Engine Speed.....	30-15

It's a preview. You can download the full file by
clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$