

Shop Manual

**HYDRAULIC
EXCAVATOR**

PC210 -11

PC210LC-11

PC210NLC-11

PC230NHD-11

SERIAL NUMBERS 500007 and up

K70001 and up

KOMATSU

00 INDEX AND FOREWORD

INDEX

00 INDEX AND FOREWORD	00-1
ABBREVIATION LIST	00-19
FOREWORD, SAFETY, BASIC INFORMATION	00-24
HOW TO READ THE SHOP MANUAL.....	00-24
SAFETY NOTICE FOR OPERATION.....	00-26
PRECAUTIONS TO PREVENT FIRE.....	00-34
ACTIONS IF FIRE OCCURS	00-36
PRECAUTIONS FOR DISPOSING OF WASTE MATERIALS	00-37
ACTIONS TAKEN TO MEET EXHAUST GAS REGULATIONS.....	00-38
PRECAUTIONS FOR DEF.....	00-39
STORE AdBlue/DEF	00-40
PRECAUTIONS FOR HANDLING HYDRAULIC EQUIPMENT	00-41
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF PIPINGS.....	00-44
PRECAUTIONS FOR HANDLING ELECTRICAL EQUIPMENT.....	00-50
PRECAUTIONS FOR HANDLING FUEL SYSTEM EQUIPMENT	00-52
PRECAUTIONS FOR HANDLING INTAKE SYSTEM EQUIPMENT	00-53
PRACTICAL USE OF KOMTRAX	00-54
DISCONNECT AND CONNECT PUSH-PULL TYPE COUPLER	00-55
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF CONNECTORS	00-59
METHOD FOR DISCONNECTING AND CONNECTING DEUTSCH CONNECTOR	00-63
METHOD FOR DISCONNECTING AND CONNECTING SLIDE LOCK TYPE CONNECTOR	00-64
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PULL ..	00-66
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PUSH ..	00-67
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH HOUSING TO ROTATE .	00-69
HOW TO READ ELECTRICAL WIRE CODE	00-70
EXPLANATION OF TERMS FOR MAINTENANCE STANDARD.....	00-74
STANDARD TIGHTENING TORQUE TABLE.....	00-77
CONVERSION TABLE	00-84
01 SPECIFICATIONS	01-1
CONTENTS	01-2
ABBREVIATION LIST	01-3
SPECIFICATIONS	01-8
SPECIFICATION DRAWING.....	01-8
WORKING RANGE DRAWINGS	01-9
SPECIFICATIONS	01-10
WEIGHT TABLE	01-13
TABLE OF FUEL, COOLANT, AND LUBRICANTS	01-15
10 STRUCTURE AND FUNCTION	10-1
CONTENTS	10-2
ABBREVIATION LIST	10-6
UREA SCR SYSTEM.....	10-11
LAYOUT DRAWING OF UREA SCR SYSTEM	10-12
UREA SCR SYSTEM DIAGRAM	10-17
FUNCTION OF UREA SCR SYSTEM.....	10-18
COMPONENT PARTS OF UREA SCR SYSTEM.....	10-28
BOOT-UP SYSTEM	10-37
LAYOUT DRAWING OF BOOT-UP SYSTEM.....	10-37
SYSTEM OPERATING LAMP SYSTEM	10-39
BATTERY DISCONNECT SWITCH	10-40
ENGINE SYSTEM	10-41
LAYOUT DRAWING OF ENGINE SYSTEM.....	10-41
ENGINE CONTROL SYSTEM	10-43
AUTO-DECELERATION SYSTEM.....	10-46
ENGINE AUTOMATIC WARM-UP SYSTEM.....	10-48
OVERHEAT PREVENTION SYSTEM.....	10-50

TURBOCHARGER PROTECTION SYSTEM	10-53
AUTOMATIC IDLE STOP SYSTEM	10-55
COMPONENT PARTS OF ENGINE SYSTEM	10-58
COOLING SYSTEM.....	10-75
LAYOUT DRAWING OF COOLING SYSTEM	10-75
FAN SPEED CONTROL SYSTEM OF FAN CLUTCH	10-77
ENGINE OUTPUT CONTROL SYSTEM OF FAN CLUTCH.....	10-79
COMPONENT PARTS OF COOLING SYSTEM.....	10-81
CONTROL SYSTEM.....	10-82
LAYOUT DRAWING OF CONTROL SYSTEM	10-82
MACHINE MONITOR SYSTEM	10-85
KOMTRAX SYSTEM.....	10-86
PPC LEVERS	10-87
AUTOMATIC GREASE SYSTEM	10-89
COMPONENT PARTS OF CONTROL SYSTEM.....	10-104
SENSOR.....	10-134
HYDRAULIC SYSTEM.....	10-137
LAYOUT DRAWING OF HYDRAULIC SYSTEM	10-137
CLSS	10-143
ENGINE AND PUMP COMBINED CONTROL SYSTEM.....	10-161
PUMP AND VALVE CONTROL SYSTEM	10-167
COMPONENT PARTS OF HYDRAULIC SYSTEM	10-170
WORK EQUIPMENT SYSTEM	10-254
LAYOUT DRAWING OF WORK EQUIPMENT SYSTEM	10-254
STRUCTURE OF VALVE CONTROL	10-259
ONE-TOUCH POWER MAXIMIZING SYSTEM	10-261
PPC LOCK SYSTEM	10-263
WORK EQUIPMENT AND TRAVEL AUTOMATIC LOCK SYSTEM	10-264
OIL FLOW ADJUSTER SYSTEM FOR ATTACHMENT.....	10-266
COMPONENT PARTS OF WORK EQUIPMENT SYSTEM.....	10-269
SWING SYSTEM.....	10-295
LAYOUT DRAWING OF SWING SYSTEM	10-295
SWING CONTROL SYSTEM DIAGRAM	10-299
COMPONENT PARTS OF SWING SYSTEM.....	10-303
TRAVEL SYSTEM.....	10-317
LAYOUT DRAWING OF TRAVEL SYSTEM.....	10-317
TRAVEL CONTROL SYSTEM DIAGRAM.....	10-321
COMPONENT PARTS OF TRAVEL SYSTEM	10-323
UNDERCARRIAGE AND FRAME.....	10-344
LAYOUT DRAWING OF UNDERCARRIAGE	10-344
WORK EQUIPMENT.....	10-346
STRUCTURE OF WORK EQUIPMENT	10-346
FUNCTION OF WORK EQUIPMENT	10-347
WORK EQUIPMENT CLEARANCE ADJUSTMENT SHIM.....	10-348
BUCKET CLEARANCE ADJUSTMENT SHIM	10-349
CAB AND ITS ATTACHMENTS	10-350
ROPS CAB	10-350
CAB MOUNT	10-351
CAB TIPPING STOPPER	10-352
20 STANDARD VALUE TABLE	20-1
CONTENTS	20-2
ABBREVIATION LIST	20-3
STANDARD VALUE TABLE FOR ENGINE	20-8
STANDARD VALUE TABLE FOR MACHINE.....	20-9
STANDARD VALUE TABLE FOR MACHINE: PC210-11, PC210LC-11.....	20-9
MACHINE POSTURE AND PROCEDURE FOR MEASURING PERFORMANCE	20-22
STANDARD VALUE TABLE FOR ELECTRICAL	20-26
STANDARD VALUE TABLE FOR ELECTRICAL	20-26

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$