

# Shop Manual

HYDRAULIC  
EXCAVATOR

***PC360LC-11***

SERIAL NUMBERS 90001 and up

**KOMATSU**



---

# 00 Index and Foreword

---

# Index

00 Index and Foreword .....	00-1
Abbreviation List .....	00-18
Foreword, Safety, Basic Information .....	00-21
How to Read the Shop Manual .....	00-21
Safety Notice for Operation .....	00-23
Precautions to Prevent Fire .....	00-31
Procedures If Fire Occurs .....	00-33
Precautions for Disposing of Waste Materials .....	00-34
Procedures for Exhaust Gas Regulations .....	00-35
Precautions for DEF .....	00-36
Store DEF .....	00-37
Precautions When You Handle Hydraulic Equipment .....	00-38
Precautions When You Disconnect and Connect Pipings .....	00-41
Precautions When You Handle Electrical Equipment .....	00-48
Precautions When You Handle Fuel System Equipment .....	00-50
Precautions When You Handle Intake System Equipment .....	00-51
Practical Use of KOMTRAX .....	00-52
Disconnect and Connect Push-Pull Type Coupler .....	00-53
Precautions for Disconnection and Connection of Connectors .....	00-57
How to Disconnect and Connect Deutsch Connector .....	00-61
How to Disconnect and Connect Slide Lock Type Connector .....	00-62
How to Disconnect and Connect Connector with Lock to Pull .....	00-64
How to Disconnect and Connect Connector with Lock to Push .....	00-65
How to Disconnect and Connect Connector with Housing to Rotate .....	00-67
How to Read the Codes for Electric Cable .....	00-68
Explanation of Terms for Maintenance Standard .....	00-72
Standard Tightening Torque Table .....	00-75
Conversion Table .....	00-82
01 Specifications .....	01-1
Table of Contents .....	01-2
Specifications .....	01-3
Specification Drawing .....	01-3
Working Range Drawings .....	01-5
Specifications .....	01-6
Weight Table .....	01-9
Table of Fuel, Coolant, and Lubricants .....	01-11
10 Structure and Function .....	10-1
Table of Contents .....	10-2
Urea SCR System .....	10-5
Layout Drawing of Urea SCR System .....	10-5
Urea SCR System Diagram .....	10-9
Function of Urea SCR System .....	10-10
Component Parts of Urea SCR System .....	10-26
Boot-up System .....	10-35
Layout Drawing of Boot-up System .....	10-35
System Operating Lamp System .....	10-37
Battery Isolator .....	10-39
Engine System .....	10-40
Layout Drawing of Engine System .....	10-40
Engine Control System .....	10-42
Auto-Deceleration System .....	10-46
Engine Automatic Warm-up System .....	10-48
Overheat Prevention System .....	10-50
Turbocharger Protection System .....	10-52
Automatic Idle Stop System .....	10-54
Component Parts of Engine System .....	10-57

Cooling System.....	10-73
Layout Drawing of Cooling System .....	10-73
Control System .....	10-75
Layout Drawing of Control System .....	10-75
Machine Monitor System.....	10-78
KomVision System.....	10-80
KOMTRAX System .....	10-84
Component Parts of Control System .....	10-85
Hydraulic System .....	10-120
Layout Drawing of Hydraulic System.....	10-120
CLSS .....	10-123
Engine and Pump Combined Control System .....	10-146
Pump and Valve Control System.....	10-152
Component Parts of Hydraulic System.....	10-155
Work Equipment System.....	10-244
Layout Drawing of Work Equipment System .....	10-244
Structure of Valve Control .....	10-250
One-Touch Power Maximizing System .....	10-252
Machine Push-up System .....	10-254
PPC Lock System .....	10-256
Work Equipment and Travel Automatic Lock System .....	10-257
Attachment Oil Flow Adjuster System .....	10-259
Component Parts of Work Equipment System .....	10-261
Swing System .....	10-288
Layout Drawing of Swing System.....	10-288
Swing Control System Diagram .....	10-291
Component Parts of Swing System.....	10-295
Travel System .....	10-309
Layout Drawing of Travel System.....	10-309
System Diagram of Travel Control System.....	10-313
Component Parts of Travel System.....	10-315
Undercarriage and Frame .....	10-335
Layout Drawing of Undercarriage.....	10-335
Work Equipment .....	10-337
Structure of Work Equipment .....	10-337
Function of Work Equipment.....	10-338
Work Equipment Clearance Adjustment Shim.....	10-339
Bucket Clearance Adjustment Shim .....	10-340
CAB Related Parts.....	10-341
ROPS CAB .....	10-341
CAB Mount .....	10-342
CAB Tipping Stopper .....	10-343
20 Standard Value Table .....	20-1
Table of Contents .....	20-2
Standard Value Table for Engine .....	20-3
Standard Value Table for Engine: PC360LC-11 .....	20-3
Standard Value Table for Machine.....	20-8
Standard Value Table for Machine: PC360LC-11.....	20-8
Machine Posture and Procedures to Measure Performance .....	20-23
Standard Value Table for Electricity.....	20-27
Standard Value Table for Electricity.....	20-27
30 Testing and Adjusting .....	30-1
Table of Contents .....	30-2
Precautions Before Work .....	30-5
Related Information on Testing and Adjusting .....	30-6
Tools for Testing and Adjusting.....	30-6
Sketch of Tools for Testing and Adjusting .....	30-13
Engine and Cooling System .....	30-15

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$