

Shop Manual

HYDRAULIC
EXCAVATOR

PC210-10

PC210LC-10

Serial Numbers

450120 and up
K60001 and up
450120 and up
K60001 and up

HYDRAULIC EXCAVATOR

PC210-10

PC210LC-10

Model	Serial Number
PC210-10	450120 and up K60001 and up
PC210LC-10	450120 and up K60001 and up

00 Index and foreword

00 Index and foreword

Index

Index (ALL-0310-001-A-00-A)

00 Index and foreword	00-1
Index	00-2
Foreword, safety and general information	00-14
Important safety notice	00-14
How to read the shop manual	00-21
Explanation of terms for maintenance standard	00-23
Handling equipment of fuel system devices	00-25
Handling of intake system parts	00-26
Handling of hydraulic equipment	00-27
Method of disconnecting and connecting of push-pull type coupler	00-29
Handling of electrical equipment	00-32
How to read electric wire code	00-40
Precautions when performing operation	00-43
Practical use of KOMTRAX	00-47
Standard tightening torque table	00-48
List of abbreviation	00-52
Conversion table	00-57
01 Specification	01-1
Table of contents	01-2
Specifications	01-3
Specification drawing	01-3
Working range drawings	01-4
Specifications	01-5
Weight table	01-8
Table of fuel, coolant, and lubricants	01-9
10 Structure and function	10-1
Table of contents	10-2
Engine and cooling system	10-3
Engine related parts	10-3
KVTG	10-5
EGR system piping drawing	10-12
EGR system circuit diagram	10-14
EGR valve	10-16
EGR cooler	10-18
KCCV layout drawing	10-19
KCCV ventilator	10-21
KDPF	10-23
Cooling system	10-27
Power train	10-29
Power train system	10-29
Swing circle	10-31
Swing machinery	10-32
Final drive	10-34
Undercarriage and frame	10-36
Track frame and idler cushion	10-36
Hydraulic system	10-38
Hydraulic equipment layout drawing	10-38
Valve control	10-40
Hydraulic tank	10-42
CLSS	10-44
Main pump	10-49
Control valve	10-75
Swing motor	10-130
Travel motor	10-142
PPC valve	10-155
Solenoid valve	10-177
Attachment circuit selector valve (for low pressure circuit)	10-180

Center swivel joint	10-183
Accumulator	10-185
ATT EPC valve assembly	10-186
Return oil filter	10-188
Quick coupler control valve	10-189
Work equipment	10-192
Work equipment	10-192
Work equipment shim	10-193
Bucket play adjustment shim	10-194
Cab and its attachments	10-195
Cab mount and cab tipping stopper	10-195
ROPS cab	10-196
Electrical system	10-197
Electrical control system	10-197
Machine monitor system	10-249
KOMTRAX system	10-271
Sensor	10-274
PPC levers	10-295
Auto grease system	10-297
20 Standard value tables	20-1
Table of contents	20-2
Standard service value table	20-3
Standard value table for engine	20-3
Standard value table for machine	20-5
Standard value table for electrical system	20-18
30 Testing and adjusting	30-1
Table of contents	30-2
General information on testing and adjusting	30-3
Tools for testing and adjusting	30-3
Sketch of tools for testing and adjusting	30-7
Engine and cooling system	30-8
Testing engine speed	30-8
Testing boost pressure	30-9
Testing exhaust gas color	30-11
Measuring and adjusting valve clearance	30-13
Testing compression pressure	30-16
Testing blowby pressure	30-20
Testing engine oil pressure	30-21
Testing EGR valve and KVGT oil pressures	30-22
Measuring fuel pressure	30-23
Measuring fuel delivery, return and leakage	30-29
Bleeding air from fuel system	30-34
Checking fuel circuit for leakage	30-36
Handling cylinder cutout mode operation	30-37
Handling no injection cranking operation	30-38
Checking and adjusting air conditioner compressor belt tension	30-39
Replacing fan belt	30-41
Power train	30-42
Testing swing circle bearing clearance	30-42
Undercarriage and frame	30-43
Testing and adjusting track shoe tension	30-43
Hydraulic system	30-44
Releasing remaining pressure from hydraulic circuit	30-44
Testing and adjusting oil pressure in work equipment, swing, and travel circuits	30-45
Testing oil pressure of control circuit	30-49
Testing and adjusting oil pressure in pump PC control circuit	30-52
Testing and adjusting oil pressure in pump LS control circuit	30-55
Testing output pressure of solenoid valve	30-60
Testing PPC valve output pressure	30-64

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$