

Shop Manual

ENGINE

SAA6D107E-1-A

SAA6D107E-1-B

Engine

SAA6D107E-1-A

SAA6D107E-1-B

Lift truck model Serial number

FD100-8	7001 and up
FD115-8	7001 and up
FD135-8	7001 and up
FD150E-8	7001 and up
FD160E-8	7001 and up
FD200-7	2601 and up
FD250-7	3601 and up

00 Index and foreword

Table of contents.....	00-2
Safety notice	00-5
How to read the shop manual	00-10
Explanation of terms for maintenance standard	00-12
Handling of electric equipment and hydraulic component	00-14
Handling of connectors newly used for engines	00-23
How to read electric wire code.....	00-26
Precautions when carrying out operation.....	00-29
Method of disassembling and connecting push-pull type coupler.....	00-32
Standard tightening torque table	00-35
Conversion table	00-39

Table of contents

00 Index and foreword	
Table of contents.....	00-2
Safety notice	00-5
How to read the shop manual	00-10
Explanation of terms for maintenance standard	00-12
Handling of electric equipment and hydraulic component	00-14
Handling of connectors newly used for engines	00-23
How to read electric wire code.....	00-26
Precautions when carrying out operation	00-29
Method of disassembling and connecting push-pull type coupler	00-32
Standard tightening torque table.....	00-35
Conversion table.....	00-39
01 Specification	
General	01-2
Specifications	01-3
General view	01-6
Engine performance curve.....	01-11
10 Structure, function and maintenance standard	
Air intake and exhaust units	10-4
Intake system	10-6
Exhaust system	10-7
Turbocharger	10-10
Lubricating oil system.....	10-13
Cooling system.....	10-17
Fuel system	10-18
Main moving parts	10-22
Cylinder head	10-26
Cylinder block.....	10-31
Crankshaft.....	10-34
Piston, piston ring and piston pin	10-36
Connecting rod.....	10-37
Vibration damper	10-38
Timing gear.....	10-39
Front cover	10-41
Camshaft.....	10-42
Valve system	10-44
Valve and valve guide	10-48
Rocker arm, shaft and tappet	10-50
Oil pump	10-52
Oil pan	10-54
Flywheel and flywheel housing.....	10-55
Oil filter	10-60
Oil cooler	10-61
Regulator valve and safety valve	10-62
Cylinder block.....	10-63
Fuel system diagram	10-64
Fuel supply pump	10-65
Fuel filter.....	10-68
Water pump drive and fan drive	10-69

Water pump.....	10-70
Alternator.....	10-71
Starting motor.....	10-73
Electric heater.....	10-75
20 Standard value table	
Standard value table for testing, adjusting and troubleshooting.....	20-2
Run-in standard and performance test criteria.....	20-4
30 Testing and adjusting	
Precautions Before Work.....	30-2
Testing and adjusting tools list.....	30-3
Testing air boost pressure.....	30-5
Adjustment of valve clearance.....	30-6
Testing compression pressure.....	30-8
Testing blow-by pressure.....	30-11
Testing engine oil pressure.....	30-12
Handling fuel system parts.....	30-13
Releasing residual pressure in fuel system.....	30-13
Testing fuel pressure.....	30-14
Reduced cylinder mode operation.....	30-16
No-injection cranking.....	30-16
Testing leakage from pressure limiter and return rate from injector.....	30-17
Bleeding air from fuel circuit.....	30-21
Testing fuel system for leakage.....	30-22
Replacing the fan belt.....	30-23
Handling controller high-voltage circuit.....	30-23
Functions of troubleshooting tool and check of failure code.....	30-25
40 Troubleshooting	
Precautions Before Work.....	40-3
General information on troubleshooting.....	40-4
Failure code table.....	40-5
Information in troubleshooting table.....	40-7
Method of using troubleshooting charts.....	40-9
Troubleshooting for mechanical system (S mode).....	40-12
S-1 Starting performance is poor.....	40-12
S-2 Engine does not start.....	40-13
S-3 Engine does not pick up smoothly.....	40-16
S-4 Engine stops during operations.....	40-17
S-5 Engine does not rotate smoothly.....	40-18
S-6 Engine lacks output (or lacks power).....	40-19
S-7 Exhaust smoke is black (incomplete combustion).....	40-20
S-8 Oil consumption is excessive (or exhaust smoke is blue).....	40-21
S-9 Oil becomes contaminated quickly.....	40-22
S-10 Fuel consumption is excessive.....	40-23
S-11 Oil is in coolant (or coolant spurts back or coolant level goes down).....	40-24
S-12 Oil pressure drops.....	40-25
S-13 Oil level rises (Entry of coolant or fuel).....	40-26
S-14 Coolant temperature becomes too high (overheating).....	40-27
S-15 Abnormal noise is made.....	40-28
S-16 Vibration is excessive.....	40-29
Troubleshooting for electrical system (E mode).....	40-30
E-1 Failure code [111] Abnormality in engine controller.....	40-30
E-2 Failure code [115] Engine Ne or Bkup speed sensor error.....	40-31
E-3 Failure code [122] Abnormally high level in charge pressure sensor.....	40-32
E-4 Failure code [123] Abnormally low level in charge pressure sensor.....	40-34
E-5 Failure code [131] Throttle sensor high error.....	40-36

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$