

Shop Manual

ENGINE

107E -2 SERIES

KOMATSU

ENGINE

107E-2 SERIES

Model Serial Number

107E-2
SERIES

00 Index and foreword

00 Index and foreword

Index

Index (ALL-0310-001-A-00-A)

00 Index and foreword	00-1
Index	00-2
Foreword, safety and general information	00-5
Important safety notice	00-5
How to read the shop manual	00-12
Explanation of terms for maintenance standard	00-14
Handling equipment of fuel system devices	00-16
Handling of intake system parts	00-17
Handling of hydraulic equipment	00-18
Method of disconnecting and connecting of push-pull type coupler	00-20
Handling of electrical equipment	00-23
How to read electric wire code	00-31
Precautions when performing operation	00-34
Standard tightening torque table	00-39
List of abbreviation	00-45
Conversion table	00-50
01 Specification	01-1
Table of contents	01-2
General information	01-3
Exhaust gas regulation	01-3
Specifications	01-9
Applicable machines	01-9
Specifications	01-10
General view	01-20
Engine performance curve	01-53
10 Structure and function	10-1
Table of contents	10-2
Components layout	10-4
Components layout drawing (4D107)	10-4
Components layout drawing (6D107)	10-6
Intake and exhaust system parts	10-8
Intake and exhaust system layout drawing (4D107)	10-8
Intake and exhaust system layout drawing (6D107)	10-9
Intake and exhaust system circuit diagram (4D107)	10-10
Intake and exhaust system circuit diagram (6D107)	10-12
Air cleaner (4D107)	10-14
Air cleaner (6D107)	10-15
VFT (4D107)	10-17
VGT(6D107)	10-21
Aftercooler	10-29
EGR system piping drawing (4D107)	10-30
EGR system piping drawing (6D107)	10-32
EGR system circuit diagram (4D107)	10-34
EGR system circuit diagram (6D107)	10-36
EGR valve (4D107)	10-38
EGR valve (6D107)	10-40
EGR cooler	10-42
Layout of KCCV (4D107)	10-43
Layout of KCCV (6D107)	10-46
KCCV ventilator	10-48
KDOC muffler (4D107)	10-52
KDPF (6D107)	10-54
Engine main body parts	10-59
Cylinder head	10-59
Cylinder block	10-61
Main moving parts	10-63
Vibration damper (6D107)	10-67

Timing gear	10-68
Front cover	10-69
Valve system	10-70
Flywheel	10-73
Lubrication system	10-75
Lubrication system parts layout drawing (4D107)	10-75
Lubrication system parts layout drawing (6D107)	10-77
Lubrication system circuit diagram (4D107)	10-79
Lubrication system circuit diagram (6D107)	10-80
Oil pump	10-81
Boost oil pump (6D107)	10-82
Oil filter	10-83
Oil cooler	10-84
Regulator valve	10-85
Safety valve	10-86
Oil pan	10-87
Fuel system	10-88
Fuel system parts layout drawing	10-88
Fuel system circuit diagram	10-91
Supply pump	10-95
Fuel cooler	10-96
Pre-filter	10-97
Main filter	10-98
Cooling system	10-99
Cooling system parts layout drawing	10-99
Cooling system circuit diagram (4D107)	10-100
Cooling system circuit diagram (6D107)	10-101
Drive pulley	10-102
Water pump	10-107
Thermostat	10-108
Electrical equipment	10-109
Alternator	10-109
Starting motor	10-117
Intake air heater	10-121
Engine wiring harness (4D107)	10-122
Engine wiring harness (6D107)	10-124
Engine controller (4D107)	10-126
Engine controller (6D107)	10-132
Sensor	10-138
20 Standard value tables	20-1
Table of contents	20-2
Standard service value table	20-3
Standard value table for engine	20-3
Running-in standard and performance test standard	20-33
50 Disassembly and assembly	50-1
Table of contents	50-2
Precautions before work	50-2-1
Related information on disassembly and assembly	50-3
How to read this manual	50-3
Coating materials list	50-5
Special tool list	50-9
Sketch of special tool	50-11
Disassembly and assembly	50-12
General disassembly of engine	50-12
General assembly of engine	50-34
Removal and installation procedure of supply pump unit alone	50-75
Engine front oil seal replacement procedure	50-79
Engine rear oil seal replacement procedure	50-82
60 Maintenance standard	60-1
Table of contents	60-2

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$