

2018 HARLEY-DAVIDSON® ELECTRICAL DIAGNOSTIC MANUAL: HARLEY-DAVIDSON STREET™ MODELS

- Foreword
 - Foreword
 - General
 - How To Use Your Manual
 - Preparation For Service
 - Service Bulletins
 - Use Genuine Replacement Parts
 - Warnings and Cautions
 - Product References
 - Product Registered Marks
 - H-D U.S.A., LLC Trademark Information
 - Contents
- Initial Diagnostics
 - Specifications
 - Specifications
 - Initial Diagnostics
 - Description and Operation
 - Initial Diagnostics
 - Diagnostics
 - Retrieving Trouble Codes
 - Odometer Self-Diagnostics
 - Code Types
 - Multiple Trouble Codes
 - Clearing DTCs
 - Security Lamp
 - Check Engine Lamp
 - Symptoms
 - DIAGNOSTIC TOOLS
 - How To Use Diagnostic Tools
 - DIAGNOSTICS AND TROUBLESHOOTING
 - Voltage Drop
 - Wiggle Test
 - Relay Diagnostics
- Serial Data
 - CAN DATA COMMUNICATION
 - Description and Operation
 - Components
 - Communication DTCs and Error Messages
 - DTC U0001
 - Description and Operation
 - DTC U0001
 - NO VEHICLE POWER OR LOST COMMUNICATION DTCS
 - Description and Operation
 - DTC U0100
 - DTC U0121
 - DTC U0002
 - SCM Inoperative: DTC U0168
 - Speedometer Inoperative: DTC U0156
 - DTC U0300
- Starting and Charging
 - BATTERY TESTING

- General
 - Voltmeter Test
 - Battery Diagnostic Test
 - Load Test
- STARTING SYSTEM
 - Description and Operation
 - Components
 - Starter Testing
 - Nothing Clicks
 - Start Relay Clicks
 - Starter Solenoid Clicks
 - Starter Spins, But Does Not Engage
 - Starter Stalls or Spins Too Slowly
- TESTING STARTER ON MOTORCYCLE
 - Starter Current Draw Test
- STARTER CIRCUIT DIAGNOSTICS
 - Description and Operation
 - DTC P0512
 - DTC P0616
 - DTC P0617
- TESTING STARTER ON BENCH
 - Free Running Current Draw Test
- CLUTCH SWITCH DIAGNOSTICS
 - Description and Operation
 - DTC P0704
- CHARGING SYSTEM
 - Description and Operation
 - Troubleshooting
 - Low or No Charging
 - Overcharging
 - Low Battery After Extended IGN OFF
 - Battery Runs Down During Use
 - Battery Charging Tests
- ECM VOLTAGE DIAGNOSTICS
 - Description and Operation
 - DTC P0562, P0563
- BATTERY AND SYSTEM VOLTAGE DIAGNOSTICS
 - Description and Operation
 - DTC P0562
 - DTC P0563
 - DTC B2272
- Instruments
 - SPEEDOMETER
 - Description and Operation
 - Speedometer Theory of Operation
 - Instrument Diagnostics
 - FUEL LEVEL DIAGNOSTICS
 - Description and Operation
 - DTC B1210
 - DTC B1211
 - Trip Odometer Functions Inoperative: DTC B2255
 - Description and Operation
 - Trip Odometer Functions Inoperative: DTC B2255
 - NEUTRAL SWITCH DIAGNOSTICS
 - Description and Operation

DTC P0851 Neutral Switch Input Circuit Low

- NO SPEEDOMETER POWER DIAGNOSTICS
 - Description and Operation
 - No Instrument Power
 - DTC B1200
- INDICATOR LAMPS
 - Description and Operation
 - Oil Pressure Lamp Always On
 - Oil Pressure Lamp Inoperative
 - Neutral Lamp Always On
 - Neutral Lamp Inoperative
 - High Beam Indicator Always On
 - High Beam Indicator Inoperative
 - Low Fuel Lamp Inoperative
 - Turn Signal Indicator Inoperative
 - Turn Signal Indicator Always On
- Horn, Lighting and Turn Signals
 - HORN DIAGNOSTICS
 - Description and Operation
 - Components
 - Symptoms
 - Horn Always On
 - Horn Inoperative
 - HEADLAMP DIAGNOSTICS
 - Description and Operation
 - Headlamp Inoperative
 - STOP LAMP DIAGNOSTICS
 - Description and Operation
 - Stop Lamp Always On
 - Stop Lamp Inoperative
 - TURN SIGNAL DIAGNOSTICS
 - Description and Operation
 - All Turn Signals Inoperative +[2018 STREET 750 (XG750)]
 - Any Front Turn Signal Inoperative
 - Any Rear Turn Signal Inoperative
 - Left Turn Signals Inoperative
 - Right Turn Signals Inoperative
 - RUNNING LAMP DIAGNOSTICS
 - Description and Operation
 - Position Lamp Inoperative: If Equipped
 - Front Running Lamps Inoperative
 - Tail Lamp Inoperative
 - LP Lamp Inoperative
 - SECURITY SYSTEM
 - Security Lamp
 - Security Immobilization
 - Security System Features
 - Security System Warnings
 - Arming
 - Disarming
 - DTC B2400
 - Alarm
 - KEY FOB
 - Description and Operation
 - Fob Assignment

SIREN

- Description and Operation
- Siren Chirp Mode Confirmation
- SERVICE AND EMERGENCY FUNCTIONS AND CONFIGURATIONS
 - Actuation
 - Selecting a PIN
 - Initial PIN Entry
 - Changing the PIN
 - Transport Mode
 - Service Mode
- ALARM DIAGNOSTICS
 - Description and Operation
- SECURITY ANTENNA DIAGNOSTICS
 - Description and Operation
 - DTC B2176
 - DTC B2177
 - DTC B2178
 - Fails to Disarm
- Engine Management
 - EFI SYSTEM
 - General
 - Electronic Control Module
 - General
 - SENSORS AND DRIVERS
 - Description and Operation
 - Sensors
 - Drivers
 - TMAP SENSOR DIAGNOSTICS
 - Description and Operation
 - DTC P0107
 - DTC P0108
 - DTC P0112
 - DTC P0113
 - TPS DIAGNOSTICS
 - Description and Operation
 - DTC P0122
 - DTC P0123
 - HO2S DIAGNOSTICS
 - Description and Operation
 - DTC P0031
 - DTC P0032
 - DTC P0051
 - DTC P0052
 - DTC P0131
 - DTC P0132
 - DTC P0134
 - DTC P0151
 - DTC P0152
 - DTC P0154
 - FUEL INJECTOR DIAGNOSTICS
 - Description and Operation
 - DTC P0261
 - DTC P0262
 - DTC P0264
 - DTC P0265

- CKP SENSOR DIAGNOSTICS
 - Description and Operation
 - DTC P0371, P0374
- PURGE SOLENOID DIAGNOSTICS
 - Description and Operation
 - DTC P0444
 - DTC P0445
- VSS DIAGNOSTICS
 - Description and Operation
 - DTC P0502
 - DTC P0503
- IDLE SPEED CONTROL DIAGNOSTICS
 - Description and Operation
 - DTC P0506, P0507
- ECT SENSOR DIAGNOSTICS
 - Description and Operation
 - DTC P0117
 - DTC P0118
- SYSTEM RELAY DIAGNOSTICS
 - Description and Operation
 - DTC P1001
 - DTC P1002
- ECM INTERNAL DIAGNOSTICS
 - Description and Operation
 - DTC P0603
 - DTC P0605
 - DTC U0300
- DTC P0641
 - Description and Operation
 - DTC P0641
- BANK ANGLE SENSOR DIAGNOSTICS
 - Description and Operation
 - DTC P1151
 - DTC P1152
- DTC P1009
 - General
 - DTC P1009
- COMBUSTION EFFICIENCY DIAGNOSTICS
 - Description and Operation
 - DTC P1353, P1356
- COOLING FAN DIAGNOSTICS
 - Description and Operation
 - DTC P0691
 - DTC P0692
 - Fan Inoperative, No DTCs
 - Fan Runs Continually, No DTCs
- JSS DIAGNOSTICS
 - Description and Operation
 - DTC P1501
 - DTC P1502
- Will Only Crank in Neutral
 - Description and Operation
 - Will Only Crank in Neutral
- ENGINE PERFORMANCE DIAGNOSTICS
 - Description and Operation

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$