

Shop Manual

BULLDOZER

D65EXi -18
D65PXi -18

SERIAL NUMBERS D65EXi-90023 and up
 D65PXi-90023

00 INDEX AND FOREWORD

INDEX

00 INDEX AND FOREWORD	00-1
ABBREVIATION LIST	00-23
FOREWORD, SAFETY, BASIC INFORMATION	00-29
HOW TO READ THE SHOP MANUAL.....	00-29
SAFETY NOTICE FOR OPERATION.....	00-31
PRECAUTIONS TO PREVENT FIRE.....	00-39
ACTIONS IF FIRE OCCURS	00-40
PRECAUTIONS FOR DISPOSING OF WASTE MATERIALS	00-40
ACTIONS TAKEN TO MEET EXHAUST GAS REGULATIONS.....	00-41
PRECAUTIONS FOR DEF.....	00-42
STORE AdBlue/DEF	00-43
PRECAUTIONS FOR HANDLING HYDRAULIC EQUIPMENT	00-44
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF PIPINGS.....	00-47
PRECAUTIONS FOR HANDLING ELECTRICAL EQUIPMENT.....	00-54
PRECAUTIONS FOR HANDLING FUEL SYSTEM EQUIPMENT	00-56
PRECAUTIONS FOR HANDLING INTAKE SYSTEM EQUIPMENT	00-57
PRACTICAL USE OF KOMTRAX	00-58
DISCONNECT AND CONNECT PUSH-PULL TYPE COUPLER	00-59
PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF CONNECTORS	00-63
METHOD FOR DISCONNECTING AND CONNECTING DEUTSCH CONNECTOR	00-67
METHOD FOR DISCONNECTING AND CONNECTING SLIDE LOCK TYPE CONNECTOR	00-68
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PULL ...	00-70
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH LOCK TO PUSH ..	00-71
METHOD FOR DISCONNECTING AND CONNECTING CONNECTOR WITH HOUSING TO ROTATE .	00-73
HOW TO READ ELECTRICAL WIRE CODE	00-74
EXPLANATION OF TERMS FOR MAINTENANCE STANDARD.....	00-78
STANDARD TIGHTENING TORQUE TABLE.....	00-81
CONVERSION TABLE	00-88
01 SPECIFICATIONS	01-1
CONTENTS	01-2
ABBREVIATION LIST	01-3
SPECIFICATIONS	01-9
SPECIFICATION DRAWING	01-9
SPECIFICATIONS	01-13
WEIGHT TABLE	01-27
TABLE OF FUEL, COOLANT, AND LUBRICANTS	01-33
10 STRUCTURE AND FUNCTION	10-1
CONTENTS	10-2
ABBREVIATION LIST	10-6
UREA SCR SYSTEM.....	10-12
LAYOUT DRAWING OF UREA SCR SYSTEM	10-12
UREA SCR SYSTEM DIAGRAM	10-14
FUNCTION OF UREA SCR SYSTEM.....	10-15
COMPONENT PARTS OF UREA SCR SYSTEM.....	10-31
BOOT-UP SYSTEM	10-40
LAYOUT DRAWING OF BOOT-UP SYSTEM.....	10-40
SYSTEM OPERATING LAMP SYSTEM	10-42
BATTERY DISCONNECT SWITCH	10-44
ENGINE SYSTEM	10-46
LAYOUT DRAWING OF ENGINE SYSTEM.....	10-46
ENGINE CONTROL SYSTEM	10-48
AUTOMATIC IDLE STOP SYSTEM	10-53
COMPONENT PARTS OF ENGINE SYSTEM	10-56
COOLING SYSTEM.....	10-76
LAYOUT DRAWING OF COOLING SYSTEM	10-76

COOLING FAN CONTROL SYSTEM.....	10-78
COMPONENT PARTS OF COOLING SYSTEM.....	10-81
CONTROL SYSTEM.....	10-98
LAYOUT DRAWING OF CONTROL SYSTEM	10-98
MACHINE MONITOR SYSTEM	10-99
KOMTRAX SYSTEM.....	10-101
COMPONENT PARTS OF CONTROL SYSTEM.....	10-102
HYDRAULIC SYSTEM.....	10-131
LAYOUT DRAWING OF HYDRAULIC SYSTEM	10-131
CLSS	10-132
COMPONENT PARTS OF HYDRAULIC SYSTEM	10-135
POWER TRAIN SYSTEM	10-189
LAYOUT DRAWING OF POWER TRAIN SYSTEM.....	10-189
OPERATION OF POWER TRAIN SYSTEM.....	10-191
TRANSMISSION, STEERING, AND BRAKE CONTROL	10-192
PALM COMMAND CONTROL SYSTEM.....	10-194
HSS SYSTEM.....	10-198
CENTRALIZED PRESSURE PICKUP PORT.....	10-201
COMPONENT PARTS OF POWER TRAIN SYSTEM.....	10-202
WORK EQUIPMENT SYSTEM	10-272
WORK EQUIPMENT CONTROL	10-272
LAYOUT OF TILT DOZER AND POWER TILT PITCH DOZER SERIES	10-275
LAYOUT OF POWER ANGLE POWER TILT DOZER SERIES	10-276
LAYOUT OF FIXED MULTI-SHANK RIPPER.....	10-277
COMPONENT PARTS OF WORK EQUIPMENT SYSTEM.....	10-278
ICT SYSTEM	10-307
LAYOUT DRAWING OF ICT SYSTEM.....	10-307
ICT CONTROL SYSTEM DIAGRAM.....	10-310
BLADE CONTROL SYSTEM	10-312
SMOOTH START SYSTEM	10-318
SLIP CONTROL SYSTEM	10-320
ASSIST CONTROL SYSTEM	10-322
COMPONENT PARTS OF ICT SYSTEM	10-324
UNDERCARRIAGE AND FRAME.....	10-355
MAIN FRAME	10-355
SUSPENSION	10-357
TRACK FRAME AND IDLER CUSHION	10-360
WORK EQUIPMENT.....	10-363
STRUCTURE OF FRONT WORK EQUIPMENT (FOR TILT DOZER AND POWER TILT PITCH DOZER SERIES).....	10-363
STRUCTURE OF FRONT WORK EQUIPMENT (FOR POWER ANGLE POWER TILT DOZER SERIES).....	10-364
STRUCTURE OF FIXED MULTI-SHANK RIPPER.....	10-365
CAB AND ITS ATTACHMENTS	10-366
ROPS CAB	10-366
CAB MOUNT	10-368
20 STANDARD VALUE TABLE	20-1
CONTENTS	20-2
ABBREVIATION LIST	20-3
STANDARD VALUE TABLE FOR ENGINE	20-9
STANDARD VALUE TABLE FOR ENGINE: D65EXI-18	20-9
STANDARD VALUE TABLE FOR ENGINE: D65PXI-18	20-14
STANDARD VALUE TABLE FOR MACHINE.....	20-19
STANDARD VALUE TABLE FOR MACHINE: D65EXI-18	20-19
STANDARD VALUE TABLE FOR MACHINE: D65PXI-18	20-36
MACHINE POSTURE AND PROCEDURE FOR MEASURING PERFORMANCE	20-54
STANDARD VALUE TABLE FOR ELECTRICAL	20-57
STANDARD VALUE TABLE FOR ELECTRICITY	20-57

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$