

# Shop Manual

HYDRAULIC  
EXCAVATOR

**HB215LC-2**

SERIAL NUMBERS 50001 and up

Hybrid

**KOMATSU**



# **SHOP MANUAL**

# **HYDRAULIC EXCAVATOR**

## **HB215LC-2**

Model              Serial Number

HB215LC-2        50001 and up

---

---

## **00 Index and foreword**

---

---

**Index**

00 Index and foreword .....	00-1
Index .....	00-2
Foreword, safety and general information .....	00-16
Important safety notice (Hybrid).....	00-16
How to read the shop manual.....	00-23
Explanation of terms for maintenance standard .....	00-25
Handling equipment of fuel system devices .....	00-27
Handling of intake system parts.....	00-28
Handling of hydraulic equipment.....	00-29
Method of disconnecting and connecting of push-pull type coupler .....	00-31
Handling of electrical equipment.....	00-34
How to read electric wire code (Hybrid) .....	00-42
Precautions when performing operation .....	00-47
Practical use of KOMTRAX .....	00-52
Handling hybrid components and high voltage wiring harness .....	00-53
Standard tightening torque table .....	00-56
List of abbreviation .....	00-62
Conversion table .....	00-67
01 Specification.....	01-1
Table of contents .....	01-2
Specifications .....	01-3
Specification drawing .....	01-3
Working range drawings .....	01-4
Specifications .....	01-5
Weight table .....	01-9
Table of fuel, coolant, and lubricants .....	01-11
10 Structure and function .....	10-1
Table of contents .....	10-2
Engine and cooling system .....	10-3
Engine related parts .....	10-3
VFT .....	10-5
EGR system piping drawing .....	10-9
EGR system circuit diagram.....	10-11
EGR valve.....	10-12
EGR cooler.....	10-14
KCCV layout drawing .....	10-16
KCCV ventilator .....	10-18
KDOC muffler .....	10-20
Cooling system .....	10-22
Hybrid system .....	10-24
Outline of hybrid system .....	10-24
Configuration of hybrid system .....	10-25
Protective function of hybrid component.....	10-26
Protection function for workers when disassembling hybrid component.....	10-28
Cooling system of hybrid component .....	10-30
Interlock function.....	10-31
Motor-generator .....	10-32
Electric swing motor .....	10-34
Electric control unit.....	10-36
High voltage wiring harness (power cable) .....	10-37
Water pump .....	10-38
Power train.....	10-39
Power train system.....	10-39
Swing circle .....	10-41
Swing machinery with swing brake .....	10-42
Final drive .....	10-44
Undercarriage and frame.....	10-46
Track frame and idler cushion .....	10-46

Hydraulic system .....	10-48
Hydraulic component layout.....	10-48
Valve control.....	10-50
Hydraulic tank.....	10-52
CLSS .....	10-54
Main pump .....	10-59
Control valve .....	10-89
Travel motor .....	10-144
PPC valve .....	10-157
Solenoid valve .....	10-180
Attachment circuit selector valve (for high pressure circuit) .....	10-183
Attachment circuit selector valve (for low pressure circuit).....	10-185
Center swivel joint.....	10-188
Accumulator .....	10-190
Work equipment .....	10-191
Work equipment.....	10-191
Work equipment shim.....	10-192
Bucket play adjustment shim.....	10-193
Cab and its attachments .....	10-194
Cab mount and cab tipping stopper .....	10-194
ROPS cab .....	10-195
Electrical system .....	10-196
Electrical control system .....	10-196
Machine monitor system .....	10-253
KOMTRAX system.....	10-277
Sensor .....	10-280
20 Standard value tables.....	20-1
Table of contents .....	20-2
Standard service value table.....	20-3
Standard value table for engine .....	20-3
Standard value table for machine .....	20-5
Standard value table for electrical system.....	20-20
30 Testing and adjusting .....	30-1
Table of contents .....	30-2
Related information on testing and adjusting .....	30-3
Tools for testing and adjusting .....	30-3
Sketch of tools for testing and adjusting .....	30-6
Engine and cooling system .....	30-8
Testing engine speed .....	30-8
Testing boost pressure .....	30-10
Testing exhaust gas color .....	30-13
Testing and adjusting valve clearance .....	30-14
Testing compression pressure.....	30-17
Testing blowby pressure .....	30-21
Testing engine oil pressure .....	30-22
Testing fuel pressure .....	30-23
Testing fuel discharge, return and leakage.....	30-28
Bleeding air from fuel system .....	30-30
Testing fuel circuit for leakage .....	30-32
Handling cylinder cutout mode operation.....	30-33
Handling no-injection cranking operation .....	30-34
Testing and adjusting air conditioner compressor belt tension .....	30-35
Replacing fan belt .....	30-36
Hybrid system .....	30-37
Precautions related to hybrid equipment .....	30-37
Bleeding air from hybrid cooling system .....	30-38
Testing water pressure of hybrid coolant.....	30-40
Testing swing parking brake .....	30-42
Cleaning and replacing oil filter of electric swing motor .....	30-43

It's a preview. You can download the full file by  
clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$