

Shop Manual

PC75R-2

HYDRAULIC EXCAVATOR

SERIAL NUMBERS PC75R-2 - 22E5200001 and up

This material is proprietary to Komatsu America International Company and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu America International Company.

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or add improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, periodic revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.

CONTENTS

10 STRUCTURE AND FUNCTION	10-1
20 TESTING AND ADJUSTING.....	20-1
30 REMOVAL AND INSTALLATION	30-1
40 MAINTENANCE STANDARD	40-1

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to table below.

Mark	Indication	Action required
○	Page to be newly	Add
●	Page to be replaced	Replace
()	Page to be delete	Discard

Pages having no marks are those previously revised or made additions.

LIST OF REVISED PAGES



Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
	00-1			10-25			10-66			10-107			20-30	
	00-2			10-26			10-67			10-108			20-31	
	00-2-1			10-27			10-68			10-109			20-32	
	00-2-2			10-28			10-69			10-110			20-33	
	00-3			10-29			10-70			10-111			20-34	
	00-4			10-30			10-71			10-112			20-35	
	00-5			10-31			10-72			10-113			20-36	
	00-6			10-32			10-73			10-114			20-37	
	00-7			10-33			10-74			10-115			20-38	
	00-8			10-34			10-75			10-116			20-39	
	00-9			10-35			10-76			10-117			20-40	
	00-10			10-36			10-77						20-41	
	00-11			10-37			10-78			20-1			20-42	
	00-12			10-38			10-79			20-2			20-43	
	00-13			10-39			10-80			20-3			20-44	
	00-14			10-40			10-81			20-4			20-45	
				10-41			10-82			20-5			20-46	
	10-1			10-42			10-83			20-6			20-47	
	10-2			10-43			10-84			20-7			20-48	
	10-3			10-44			10-85			20-8			20-49	
	10-4			10-45			10-86			20-9			20-50	
	10-5			10-46			10-87			20-10			20-51	
	10-6			10-47			10-88			20-11			20-52	
	10-7			10-48			10-89			20-12			20-53	
	10-8			10-49			10-90			20-13			20-54	
	10-9			10-50			10-91			20-14			20-55	
	10-10			10-51			10-92			20-15			20-56	
	10-11			10-52			10-93			20-16			20-57	
	10-12			10-53			10-94			20-17			20-58	
	10-13			10-54			10-95			20-18			20-59	
	10-14			10-55			10-96			20-19			20-60	
	10-15			10-56			10-97			20-20			20-61	
	10-16			10-57			10-98			20-21				
	10-17			10-58			10-99			20-22			30-1	
	10-18			10-59			10-100			20-23			30-2	
	10-19			10-60			10-101			20-24			30-3	
	10-20			10-61			10-102			20-25			30-4	
	10-21			10-62			10-103			20-26			30-5	
	10-22			10-63			10-104			20-27			30-6	
	10-23			10-64			10-105			20-28			30-7	
	10-24			10-65			10-106			20-29			30-8	

Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
	30-9			30-66			30-123							
	30-10			30-67			30-124							
	30-11			30-68										
	30-12			30-69			40-1							
	30-13			30-70			40-2							
	30-14			30-71			40-3							
	30-15			30-72			40-4							
	30-16			30-73			40-5							
	30-17			30-74			40-6							
	30-18			30-75			40-7							
	30-19			30-76			40-8							
	30-20			30-77			40-9							
	30-21			30-78			40-10							
	30-22			30-79			40-11							
	30-23			30-80			40-12							
	30-24			30-81			40-13							
	30-25			30-82			40-14							
	30-26			30-83			40-15							
	30-27			30-84			40-16							
	30-28			30-85			40-17							
	30-29			30-86			40-18							
	30-30			30-87			40-19							
	30-31			30-88			40-20							
	30-32			30-89			40-21							
	30-33			30-90			40-22							
	30-34			30-91			40-23							
	30-35			30-92			40-24							
	30-36			30-93			40-25							
	30-37			30-94			40-26							
	30-38			30-95			40-27							
	30-39			30-96			40-28							
	30-40			30-97			40-29							
	30-41			30-98			40-30							
	30-42			30-99			40-31							
	30-43			30-100			40-32							
	30-44			30-101			40-33							
	30-45			30-102			40-34							
	30-46			30-103			40-35							
	30-47			30-104			40-36							
	30-48			30-105			40-37							
	30-49			30-106			40-38							
	30-50			30-107										
	30-51			30-108										
	30-52			30-109										
	30-53			30-110										
	30-54			30-111										
	30-55			30-112										
	30-56			30-113										
	30-57			30-114										
	30-58			30-115										
	30-59			30-116										
	30-60			30-117										
	30-61			30-118										
	30-62			30-119										
	30-63			30-120										
	30-64			30-121										
	30-65			30-122										



IMPORTANT SAFETY NOTICE

Proper service and repair is extremely important for the safe operation of your machine. The service and repair techniques recommended by Komatsu and describe in this manual are both effective and safe methods of operation. Some of these operations require the use of tools specially designed by Komatsu for the purpose.

To prevent injury to workers, the symbols  and  are used to mark safety precautions in this manual. The cautions accompanying these symbols should always be carefully followed. If any danger arises or may possibly arise, first consider safety, and take necessary steps to face.



SAFETY

GENERAL PRECAUTIONS

Mistakes in operation extremely dangerous.
Read all the Operation and Maintenance Manual carefully BEFORE operating the machine.

1. Before carrying out any greasing or repairs, read all the precautions written on the decals which are stuck on the machine.
2. When carrying out any operation, always wear safety shoes and helmet. Do not wear loose work clothes, or clothes with buttons missing.
 - Always wear safety glasses when hitting parts with a hammer.
 - Always wear safety glasses when grinding parts with a grinder, etc.
3. If welding repairs are needed, always have a trained, experienced welder carry out the work. When carrying out welding work, always wear welding gloves, apron, glasses, cap and other clothes suited for welding work.
4. When carrying out any operation with two or more workers, always agree on the operating procedure before starting. Always inform your fellow workers before starting any step of the operation. Before starting work, hang UNDER REPAIR signs on the controls in the operator's compartment.
5. Keep all tools in good condition and learn the correct way to use them.
6. Decide a place in the repair workshop to keep tools and removed parts. Always keep the tools and parts in their correct places. Always keep the work area clean and make sure that there is no dirt or oil on the floor.
Smoke only in the areas provided for smoking.
Never smoke while working.

PREPARATIONS FOR WORK

7. Before adding or making any repairs, park the machine on hard, level ground, and block the tracks to prevent the machine from moving.
8. Before starting work, lower blade, bucket or any other work equipment to the ground. If this is not possible, use blocks to prevent the work equipment from falling down. In addition, be sure to lock all the control levers and hang warning sign on them.
9. When disassembling or assembling, support the machine with blocks, jacks or stands before starting work.
10. Remove all mud and oil from the steps or other places used to get on and off the machine. Always use the handrails, ladders or steps when getting on or off the machine.
Never jump on or off the machine.
If it is impossible to use the handrails, ladders or steps, use a stand to provide safe footing.

PRECAUTIONS DURING WORK

11. When removing the oil filler cap, drain plug or hydraulic pressure measuring plugs, loosen them slowly to prevent the oil from spurting out.
Before disconnecting or removing components of the hydraulic circuit and engine cooling circuit, first remove the pressure completely from the circuit.
12. The water and oil in the circuits are not hot when the engine is stopped, so be careful not to get burned.
Wait for the oil water to cool before carrying out any work on the cooling water circuits.

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$