

Shop Manual

ENGINE

125E -6 SERIES

KOMATSU

SHOP MANUAL

ENGINE

125E-6 SERIES

Model Serial Number

125E-6
SERIES

00 Index and foreword

00 Index and foreword

Index

Index (ALL-0310-001-A-00-A)

00 Index and foreword	00-1
Index	00-2
Foreword, safety and general information	00-5
Important safety notice	00-5
How to read the shop manual	00-12
Explanation of terms for maintenance standard	00-13
Handling equipment of fuel system devices	00-15
Handling of intake system parts	00-16
Handling of hydraulic equipment	00-17
Method of disconnecting and connecting of push-pull type coupler	00-19
Handling of electrical equipment	00-22
How to read electric wire code	00-30
Precautions when performing operation	00-33
Standard tightening torque table	00-37
List of abbreviation	00-41
Conversion table	00-46
01 Specification	01-1
Table of contents	01-2
Specifications	01-3
Exhaust gas regulation	01-3
Applicable machines	01-6
Specifications	01-7
General view	01-10
Weight table	01-24
Engine performance curve	01-25
10 Structure and function	10-1
Table of contents	10-2
Components layout	10-3
Components layout drawing	10-3
Intake and exhaust system parts	10-6
Intake and exhaust system layout drawing	10-6
Intake and exhaust system circuit diagram	10-7
Air cleaner	10-9
KVG T	10-10
Aftercooler	10-16
EGR system piping drawing	10-17
EGR system circuit diagram	10-19
EGR valve	10-20
EGR cooler	10-22
Mixing connector	10-24
KCCV layout drawing	10-25
KCCV ventilator	10-27
KDPF	10-31
Engine main body parts	10-35
Cylinder head	10-35
Cylinder block	10-37
Main moving parts	10-39
Vibration damper	10-42
Timing gear	10-43
Front cover	10-45
Valve system	10-46
Flywheel and flywheel housing	10-49
Lubrication system	10-50
Lubrication system parts layout drawing	10-50
Lubrication system diagram	10-51
Oil pump	10-52
Boost oil pump	10-53
Oil filter	10-54

Oil cooler.....	10-55
Oil cooler thermo-valve.....	10-56
Oil pan.....	10-57
Fuel system.....	10-58
Fuel system parts layout drawing.....	10-58
Fuel system circuit diagram.....	10-60
Outline of CRI system.....	10-63
Fuel dozing.....	10-76
Fuel cooler.....	10-79
Pre-filter.....	10-80
Main filter.....	10-81
Cooling system.....	10-82
Cooling system parts layout drawing.....	10-82
Cooling system circuit diagram.....	10-83
Water pump.....	10-84
Thermostat.....	10-85
Electrical equipment.....	10-87
Alternator.....	10-87
Alternator mounting.....	10-91
Starting motor.....	10-92
Fuel feed pump.....	10-96
Fuel feed pump switch.....	10-97
Engine wiring harness.....	10-98
Engine controller.....	10-100
Sensor.....	10-106
20 Standard value table.....	20-1
Table of contents.....	20-2
Standard service value table.....	20-3
Standard value table for engine.....	20-3
Running-in standard and performance test standard.....	20-9
50 Disassembly and assembly.....	50-1
Table of contents.....	50-2
General information on disassembly and assembly.....	50-3
How to read this manual.....	50-3
Coating materials list.....	50-5
Special tool list.....	50-9
Sketch of special tool.....	50-11
Disassembly and assembly.....	50-14
General disassembly of engine.....	50-14
General assembly of engine.....	50-35
Removal and installation procedure of supply pump as single component.....	50-80
Engine front oil seal replacement procedure.....	50-85
Engine rear oil seal replacement procedure.....	50-88
60 Maintenance standard.....	60-1
Table of contents.....	60-2
Intake and exhaust system parts.....	60-3
KVTG.....	60-3
Engine main body parts.....	60-4
Cylinder head.....	60-4
Cylinder block.....	60-5
Cylinder liner.....	60-7
Crankshaft.....	60-8
Cam follower and push rod.....	60-9
Piston.....	60-11
Connecting rod.....	60-13
Vibration damper.....	60-15
Timing gear.....	60-16
Camshaft.....	60-17
Valve and valve guide.....	60-18

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$