

SERVICE MANUAL

NEF Tier 4A (interim) and Stage IIIB Engine

See the following page for engine model numbers



SERVICE MANUAL

**F4DFE413A*A, F4DFE413B*A, F4DFE413C*A, F4DFE413D*A, F4DFE413E*A,
F4DFE6132*A, F4DFE613A*A, F4DFE613B*A, F4DFE613C*A, F4DFE613D*A,
F4DFE613E*A, F4DFE613F*A, F4DFE613G*A, F4DFE613H*A, F4DFE613J*A,
F4DFE613K*A, F4DFE613L*A, F4HFE413A*A005, F4HFE413C*A,
F4HFE413D*A008, F4HFE413H*A, F4HFE413J*A, F4HFE413L*A007,
F4HFE413M*A005, F4HFE413P*A001, F4HFE6131*A, F4HFE6132*A004,
F4HFE6138*A002, F4HFE613F*A002, F4HFE613G*A, F4HFE613H*A,
F4HFE613J*A007, F4HFE613J*A, F4HFE613K*A, F4HFE613P*A,
F4HFE613R*A, F4HFE613T*A004, F4HFE613T*A005, F4HFE613U*A005,
F4HFE613U*A006, F4HFE613V*A003, F4HFE613X*A, F4HFE613Y*A,
F4HFE613Z*A005, F4HFE613Z*A006, F4HFE614E*A001**

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
[10.102] Pan and covers	10.2
[10.106] Valve drive and gears	10.3
[10.101] Cylinder heads	10.4
[10.105] Connecting rods and pistons.....	10.5
[10.103] Crankshaft and flywheel.....	10.6
[10.110] Balancer and damper	10.7
[10.114] Pump drives	10.8
[10.210] Lift pump and lines	10.9
[10.206] Fuel filters	10.10
[10.218] Fuel injection system.....	10.11
[10.250] Turbocharger and lines.....	10.12
[10.254] Intake and exhaust manifolds and muffler	10.13
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment	10.14
[10.400] Engine cooling system	10.15
[10.414] Fan and drive	10.16
[10.304] Engine lubrication system.....	10.17
[10.408] Oil cooler and lines.....	10.18
Electrical systems.....	55
[55.015] Engine control system.....	55.1
[55.201] Engine starting system.....	55.2
[55.301] Alternator.....	55.3
[55.202] Cold start aid	55.4
[55.010] Fuel injection system.....	55.5
[55.014] Engine intake and exhaust system.....	55.6

[55.988] Selective Catalytic Reduction (SCR) electrical system	55.7
[55.012] Engine cooling system	55.8
[55.013] Engine oil system	55.9

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$