

Puma 170 CVX
Puma 185 CVX
Puma 200 CVX
Puma 215 CVX
Puma 230 CVX
Puma 170
Puma 185
Puma 200
Puma 215
Tractor

SERVICE MANUAL

Part number 47524320

English

May 2013

Copyright © 2013 CNH Europe Holding S.A. All Rights Reserved.

CASE II
AGRICULTURE



SERVICE MANUAL



**PUMA 170 CVX , PUMA 170 , PUMA 185 CVX , PUMA 185 , PUMA 200 CVX ,
PUMA 200 , PUMA 215 CVX , PUMA 215 , PUMA 230 CVX**

Link Product / Engine

Product	Market Product	Engine
PUMA 170	North America	F4DFE613L*A
PUMA 170	Europe	F4DFE613L*A
PUMA 170	International Region	F4DFE613L*A
PUMA 185	International Region	F4DFE613K*A
PUMA 185	North America	F4DFE613K*A
PUMA 185	Europe	F4DFE613K*A
PUMA 200	Europe	F4DFE613J*A
PUMA 200	North America	F4DFE613J*A
PUMA 200	International Region	F4DFE613J*A
PUMA 215	North America	F4DFE613H*A
PUMA 215	International Region	F4DFE613H*A
PUMA 215	Europe	F4DFE613H*A
PUMA 170 CVX	International Region	F4DFE613L*A
PUMA 170 CVX	Europe	F4DFE613L*A
PUMA 185 CVX	Europe	F4DFE613K*A
PUMA 185 CVX	International Region	F4DFE613K*A
PUMA 200 CVX	Europe	F4DFE613J*A
PUMA 200 CVX	International Region	F4DFE613J*A
PUMA 215 CVX	Europe	F4DFE613H*A
PUMA 215 CVX	International Region	F4DFE613H*A
PUMA 230 CVX	Europe	F4DFE613G*A
PUMA 230 CVX	International Region	F4DFE613G*A

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
[10.102] Pan and covers	10.2
[10.216] Fuel tanks	10.3
[10.210] Lift pump and lines	10.4
[10.218] Fuel injection system.....	10.5
[10.250] Turbocharger and lines.....	10.6
[10.254] Intake and exhaust manifolds and muffler	10.7
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.8
[10.400] Engine cooling system	10.9
[10.414] Fan and drive	10.10
[10.408] Oil cooler and lines.....	10.11
Transmission.....	21
[21.113] Powershift transmission	21.1
[21.155] Powershift transmission internal components.....	21.2
[21.160] Creeper	21.3
[21.166] Overdrive.....	21.4
[21.504] Continuously Variable Transmission (CVT)	21.5
[21.505] Continuously Variable Transmission (CVT) external controls.....	21.6
[21.506] Continuously Variable Transmission (CVT) lubrication system	21.7
[21.507] Continuously Variable Transmission (CVT) internal components	21.8
[21.109] Transmission cooler and lines.....	21.9
Four-Wheel Drive (4WD) system	23
[23.202] Electro-hydraulic control	23.1
[23.314] Drive shaft.....	23.2
Front axle system	25

[25.100] Powered front axle	25.1
[25.102] Front bevel gear set and differential	25.2
[25.108] Final drive hub, steering knuckles, and shafts	25.3
[25.122] Axle suspension control	25.4
Rear axle system.....	27
[27.100] Powered rear axle.....	27.1
[27.106] Rear bevel gear set and differential.....	27.2
[27.120] Planetary and final drives	27.3
Power Take-Off (PTO).....	31
[31.101] Rear mechanical control	31.1
[31.104] Rear electro-hydraulic control.....	31.2
[31.114] Two-speed rear Power Take-Off (PTO)	31.3
[31.116] Three-speed rear Power Take-Off (PTO)	31.4
[31.119] Four-speed rear Power Take-Off (PTO).....	31.5
[31.146] Front Power Take-Off (PTO)	31.6
Brakes and controls	33
[33.202] Hydraulic service brakes	33.1
[33.110] Parking brake or parking lock	33.2
[33.220] Trailer brake hydraulic control.....	33.3
[33.224] Trailer brake pneumatic control	33.4
[33.350] Anti-lock Brake System (ABS)	33.5
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.300] Reservoir, cooler, and filters.....	35.2
[35.106] Variable displacement pump	35.3
[35.102] Pump control valves.....	35.4
[35.105] Charge pump.....	35.5
[35.322] Regulated/Low pressure system	35.6

It's a preview. You can download the full file by clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$