



Section 1

General Information

Service Manual - Side Engine Loadalls - SH,SL Engines - from May 2014

[Section 1 - General Information](#)

[Section 2 - Operator's Manual](#)

[Section B - Body and Framework](#)

[Section C - Electrics](#)

[Section E - Hydraulics](#)

[Section F - Transmission](#)

[Section G - Brakes](#)

[Section H - Steering](#)

[Section K - Engine](#)

[Section M - Electrical and Electronic Data Systems](#)



Publication No.
9813-4500-2



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

World Class
Customer Support



Section 1 - General Information

Notes:



Section 1 - General Information

Contents	Page No.
Introduction	
Identifying Your Machine	1-1-1
Applications	
Introduction	1-2-1
Tables	1-2-2
Use	
Introduction	1-3-1
Scope	1-3-2
Format	1-3-3
Left and Right Sides	1-3-4
Hydraulic Schematic Codes	1-3-5
Routine Maintenance	
Maintenance Schedules	1-4-1
General Procedures	
Introduction	1-5-1
Related Topics	1-5-3
Parking the Machine and Making it Safe	1-5-4
Boom Safety Strut (P1)	1-5-6
Boom Safety Strut (P2)	1-5-9
Venting the Hydraulic Pressure	1-5-12
Venting the Brake System Pressure	1-5-14
Connecting/Disconnecting Hydraulic Hoses	1-5-15
Quick Release Couplings	1-5-16
Hydraulic Contamination	1-5-18
Battery Disconnection/Connection	1-5-20
Battery Charging System Precautions	1-5-21
Removing and Replacing Components	1-5-22
Hydraulic Rams	1-5-24
Gas Hydraulic Bladder Accumulators	1-5-26
Safety Notices	
Introduction	1-6-1
Important Information	1-6-2
Safety Check List	1-6-3
Safety Decals	1-6-16
Torque Settings	
Introduction	1-7-1
Zinc Plated Fasteners and Dacromet Fasteners	1-7-2
Hydraulic Connections	1-7-6
`Positional Type' Hydraulic Adaptors	1-7-13
Service Tools	
Introduction	1-8-1
Numerical List	1-8-2
Tool Detail Reference	1-8-5
Rivet Nuts	1-8-28
Slide Hammer Kit	1-8-30
Service Consumables	
Introduction	1-9-1



Section 1 - General Information

Contents	Page No.
Sealing and Retaining Compounds	1-9-2
 Fuel	
Introduction	1-10-1
Related Topics	1-10-2
Acceptable and Unacceptable Fuels	1-10-3
 Stall Speed Combinations	
Introduction	1-11-1
Related Topics	1-11-2
Specifications	1-11-3



Introduction

Identifying Your Machine

For information about identifying your machine and its main components, refer to **Section 2, About the Machine, Machine and Component Identification.**

It's a preview. You can download the full file by
clicking the link below.

<https://shopservicemanual.com/>

Service Manuals from 2\$